
Set up SLS/IM2 for EIP

Network

- Need IP address on the same network as the PLC to be connected to.
- Ethernet cable to be connected to the RJ45 Ethernet/IP port (this may be labeled Options).

Log In

Log in in with "24816".



Settings

Click <Settings>




LAN Settings

- •Click <LAN Settings>
- •Enter the Ethernet/IP settings under the "Real Time LAN Settings" section and save.



Settings

- •Click <Settings>
- •The program with the light bulb is the active program
- Select the active program and click <Edit>









Settings Overview

- If the EtherNet/IP module is installed and configured correctly, the EthernNet/IP selection will be available in the "Communication" section under the "Available" Tab.
- Click the edit icon on the right side of the "EtherNet/IP" item in the list.



EtherNet/IP Communication

- Under the "EtherNet/IP Configuration: section, check the checkbox "Use Registers".
- Select "Low byte first" in the first dropdown combobox in the "Telegram" section.
- Select "Single precision Float" in the second dropdown combobox in the "Telegram" section.
- Click <Done> to save and exit when that is completed.




EtherNet/IP Activation

- Check the "EtherNet/IP line item in the "Communication" section to activate it.
- Add comments to the "Comments" textbox to describe the changes made.
- Click <Save> to save the changes.




Save to Set

- Click <Save> to save the new program in the same set of programs as the program you started with.
- •The original program will not be affected by this action.



Activating the New Program

- The program with the EtherNet/IP configuration has been saved but not activated.
- The current activated program is still the original program with the light bulb indicator displayed beside it.
- To activate the new program, check the checkbox on the new program and click the <Activate> button.
- This will activate the new program.



Completion

 If the activation process is successful, the light bulb indicator will be present on the line item of the new program

