3GPP TS 38.306 V15.10.0 (2020-07)

Technical Specification

3rd Generation Partnership Project; Technical Specification Group Radio Access Network; NR; User Equipment (UE) radio access capabilities (Release 15)





3GPP

Postal address

3GPP support office address

650 Route des Lucioles - Sophia Antipolis Valbonne - FRANCE Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Internet

http://www.3gpp.org

Copyright Notification

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© 2020, 3GPP Organizational Partners (ARIB, ATIS, CCSA, ETSI, TSDSI, TTA, TTC). All rights reserved.

UMTSTM is a Trade Mark of ETSI registered for the benefit of its members 3GPPTM is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners LTETM is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners GSM® and the GSM logo are registered and owned by the GSM Association

Contents

Forev	word	5
1	Scope	6
2	References	<i>6</i>
3	Definitions, symbols and abbreviations	7
3.1	Definitions	
3.2	Symbols	
3.3	Abbreviations.	
4	UE radio access capability parameters	8
4.1	Supported max data rate	8
4.1.1	General	8
4.1.2	Supported max data rate	8
4.1.3	Void	9
4.1.4	Total layer 2 buffer size	9
4.2	UE Capability Parameters	10
4.2.1	Introduction	
4.2.2	General parameters	
4.2.3	SDAP Parameters	
4.2.4	PDCP Parameters	
4.2.5	RLC parameters	
4.2.6	MAC parameters	
4.2.7	Physical layer parameters	
4.2.7.		
4.2.7.	1	
4.2.7.	1	
4.2.7.		
4.2.7.		
4.2.7.	1	
4.2.7.	•	
4.2.7.		
4.2.7.	<u>.</u>	
4.2.7.		
4.2.7.	·	
4.2.7.		
4.2.7.		
4.2.8	Void	
4.2.9		
4.2.10		
4.2.10	1	
4.2.10		
4.2.10		
4.2.11		
4.2.12		
4.2.13		
5	Optional features without UE radio access capability parameters	
5.1	PWS features	
5.2	UE receiver features	
5.3	RRC connection	57

6	Condition	onally mandatory features without UE radio access capability parameters	57
7	Void		58
8	UE Cap	ability Constraints	58
Anne	x A (nor	mative): Differentiation of capabilities	59
Annex	κ A.1:	TDD/FDD differentiation of capabilities in TDD-FDD CA	59
Annex	x A.2:	FR1/FR2 differentiation of capabilities in FR1-FR2 CA	60
Anne	x B: UE	capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations	61
Anne	x C (info	ormative): Change history	63

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

[18]

[19]

1 Scope

The present document defines the NR UE Radio Access Capability Parameters.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.

Performance requirements".

procedures".

- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.
- [1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications". [2] 3GPP TS 38.101-1: "NR; User Equipment (UE) radio transmission and reception Part 1: Range 1 Standalone". 3GPP TS 38.101-2: "NR; User Equipment (UE) radio transmission and reception Part 2: Range 2 [3] Standalone". 3GPP TS 38.101-3: "NR; User Equipment (UE) radio transmission and reception Part 3: Range 1 [4] and Range 2 Interworking operation with other radios". 3GPP TS 38.133: "NR; Requirements for support of radio resource management". [5] [6] 3GPP TS 38.211: "NR; Physical channels and modulation". [7] 3GPP TS 37.340: "Evolved Universal Terrestrial Radio Access (E-UTRA) and NR Multiconnectivity". 3GPP TS 38.321: "NR; Medium Access Control (MAC) protocol specification". [8] [9] 3GPP TS 38.331: "NR; Radio Resource Control (RRC) protocol specification". [10] 3GPP TS 38.212: "NR; Multiplexing and channel coding". 3GPP TS 38.213: "NR; Physical layer procedures for control". [11][12] 3GPP TS 38.214: "NR; Physical layer procedures for data". [13] 3GPP TS 38.215: "NR; Physical layer measurements". [14] 3GPP TS 36.101: "Evolved Universal Terrestrial Radio Access (E-UTRA) radio transmission and reception". [15] 3GPP TS 36.306: "Evolved Universal Terrestrial Radio Access (E-UTRA) User Equipment (UE) radio access capabilities". [16] 3GPP TS 38.323: "NR; Packet Data Convergence Protocol (PDCP) specification". 3GPP TS 36.331: "Evolved Universal Terrestrial Radio Access (E-UTRA) Radio Resource [17] Control (RRC); Protocol Specification".

3GPP TS 38.101-4: "NR; User Equipment (UE) radio transmission and reception Part 4:

3GPP TS 36.213: "Evolved Universal Terrestrial Radio Access (E-UTRA); Physical layer

[20] 3GPP TS 38.304: "User Equipment (UE) procedures in Idle mode and RRC Inactive state".

3 Definitions, symbols and abbreviations

3.1 Definitions

For the purposes of the present document, the terms and definitions given in TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in TR 21.905 [1].

Fallback band combination: A band combination that would result from another band combination by releasing at least one SCell or uplink configuration of SCell, or SCG. An intra-band non-contiguous band combination is not considered to be a fallback band combination of an intra-band contiguous band combination.

Fallback per band feature set: A feature set per band that has same or lower values than the reported values from the reported feature set per band for a given band.

Fallback per CC feature set: A feature set per CC that has lower value of UE supported MIMO layers and BW while keeping the numerology and other parameters the same from the reported feature set per CC for a given carrier per band.

3.2 Symbols

For the purposes of the present document, the following symbols apply:

MaxDLDataRate: Maximum DL data rate

MaxDLDataRate_MN: Maximum DL data rate in the MN MaxDLDataRate_SN: Maximum DL data rate in the SN

MaxULDataRate: Maximum UL data rate

3.3 Abbreviations

For the purposes of the present document, the abbreviations given in TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in TR 21.905 [1].

BC Band Combination

DL Downlink FS Feature Set

FSPC Feature Set Per Component-carrier

MAC Medium Access Control
MCG Master Cell Group
MN Master Node

MR-DC Multi-RAT Dual Connectivity
PDCP Packet Data Convergence Protocol

RLC Radio Link Control
RTT Round Trip Time
SCG Secondary Cell Group

SDAP Service Data Adaptation Protocol

SN Secondary Node

UL Uplink

4 UE radio access capability parameters

4.1 Supported max data rate

4.1.1 General

The DL and UL max data rate supported by the UE is calculated by band or band combinations supported by the UE. A UE supporting NR (NR SA, MR-DC) shall support the calculated DL and UL max data rate defined in 4.1.2.

4.1.2 Supported max data rate

For NR, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

data rate (in Mbps) =
$$10^{-6} \cdot \sum_{j=1}^{J} \left(v_{Layers}^{(j)} \cdot Q_m^{(j)} \cdot f^{(j)} \cdot R_{max} \cdot \frac{N_{PRB}^{BW(j),\mu} \cdot 12}{T_s^{\mu}} \cdot (1 - OH^{(j)}) \right)$$

wherein

J is the number of aggregated component carriers in a band or band combination

 $R_{max} = 948/1024$

For the j-th CC,

 $v_{Layers}^{(j)}$ is the maximum number of supported layers given by higher layer parameter maxNumberMIMO-

LayersPDSCH for downlink and maximum of higher layer parameters *maxNumberMIMO-LayersCB-PUSCH* and *maxNumberMIMO-LayersNonCB-PUSCH* for uplink.

 $Q_m^{(j)}$ is the maximum supported modulation order given by higher layer parameter supportedModulationOrderDL for downlink and higher layer parameter supportedModulationOrderUL for uplink.

 $f^{(j)}$ is the scaling factor given by higher layer parameter *scalingFactor* and can take the values 1, 0.8, 0.75, and 0.4.

 μ is the numerology (as defined in TS 38.211 [6])

 T_s^{μ} is the average OFDM symbol duration in a subframe for numerology t^{μ} , i.e. $t^{\mu} = \frac{10^{-3}}{14 \cdot 2^{\mu}}$. Note that normal cyclic prefix is assumed.

 $N_{PRB}^{BW(j),\mu}$ is the maximum RB allocation in bandwidth $BW^{(j)}$ with numerology μ , as defined in 5.3 TS 38.101-1 [2] and 5.3 TS 38.101-2 [3], where $BW^{(j)}$ is the UE supported maximum bandwidth in the given band or band combination.

 $OH^{(j)}$ is the overhead and takes the following values

0.14, for frequency range FR1 for DL

0.18, for frequency range FR2 for DL

0.08, for frequency range FR1 for UL

0.10, for frequency range FR2 for UL

NOTE: Only one of the UL or SUL carriers (the one with the higher data rate) is counted for a cell operating SUL.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For single carrier NR SA operation, the UE shall support a data rate for the carrier that is no smaller than the data rate computed using the above formula, with J = 1 CC and component $v_{Layers}^{(j)} \cdot Q_m^{(j)} \cdot f^{(j)}$ is no smaller than 4.

NOTE: As an example, the value 4 in the component above can correspond to $v_{Layers}^{(j)} = 1$, $Q_m^{(j)} = 4$ and $f^{(j)} = 1$.

For EUTRA in case of MR-DC, the approximate data rate for a given number of aggregated carriers in a band or band combination is computed as follows.

Data rate (in Mbps) =
$$10^{-3} \cdot \sum_{j=1}^{J} TBS_j$$

wherein

J is the number of aggregated EUTRA component carriers in MR-DC band combination

TBS_j is the total maximum number of DL-SCH transport block bits received or the total maximum number of UL-SCH transport block bits transmitted, within a 1ms TTI for j-th CC, as derived from TS36.213 [19] based on the UE supported maximum MIMO layers for the j-th CC, and based on the maximum modulation order for the j-th CC and number of PRBs based on the bandwidth of the j-th CC according to indicated UE capabilities.

The approximate maximum data rate can be computed as the maximum of the approximate data rates computed using the above formula for each of the supported band or band combinations.

For MR-DC, the approximate maximum data rate is computed as the sum of the approximate maximum data rates from NR and EUTRA.

4.1.3 Void

4.1.4 Total layer 2 buffer size

The total layer 2 buffer size is defined as the sum of the number of bytes that the UE is capable of storing in the RLC transmission windows and RLC reception and reordering windows and also in PDCP reordering windows for all radio bearers.

The required total layer 2 buffer size in MR-DC and NR-DC is the maximum value of the calculated values based on the following equations:

- MaxULDataRate_MN * RLCRTT_MN + MaxULDataRate_SN * RLCRTT_SN + MaxDLDataRate_SN * RLCRTT_SN + MaxDLDataRate_MN * (RLCRTT_SN + X2/Xn delay + Queuing in SN)
- MaxULDataRate_MN * RLCRTT_MN + MaxULDataRate_SN * RLCRTT_SN + MaxDLDataRate_MN * RLCRTT_MN + MaxDLDataRate_SN * (RLCRTT_MN + X2/Xn delay + Queuing in MN)

Otherwise it is calculated by MaxDLDataRate * RLC RTT + MaxULDataRate * RLC RTT.

NOTE: Additional L2 buffer required for preprocessing of data is not taken into account in above formula.

The required total layer 2 buffer size is determined as the maximum total layer 2 buffer size of all the calculated ones for each band combination and the applicable Feature Set combination in the supported MR-DC or NR band combinations. The RLC RTT for NR cell group corresponds to the smallest SCS numerology supported in the band combination and the applicable Feature Set combination.

wherein

X2/Xn delay + Queuing in SN = 25ms if SCG is NR, and 55ms if SCG is EUTRA

X2/Xn delay + Queuing in MN = 25ms if MCG is NR, and 55ms if MCG is EUTRA

RLC RTT for EUTRA cell group = 75ms

RLC RTT for NR cell group is defined in Table 4.1.4-1

Table 4.1.4-1: RLC RTT for NR cell group per SCS

SCS (KHz)	RLC RTT (ms)
15KHz	50
30KHz	40
60KHz	30
120KHz	20

4.2 UE Capability Parameters

4.2.1 Introduction

The following clauses define the UE radio access capability parameters. Only parameters for which there is the possibility for UEs to signal different values are considered as UE radio access capability parameters. Therefore, mandatory features without capability parameters that are the same for all UEs are not listed here.

The network needs to respect the signalled UE radio access capability parameters when configuring the UE and when scheduling the UE.

The UE may support different functionalities between FDD and TDD, and/or between FR1 and FR2. The UE shall indicate the UE capabilities as follows. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "FDD-TDD DIFF" and "FR1-FR2 DIFF" indicates the UE capability field can have a different value for between FDD and TDD or between FR1 and FR2 and "No" indicates if it cannot. "FD" in the column indicates to refer the associated field description. "FR1 only" or "FR2 only" in the column indicates the associated feature is only supported in FR1 or FR2 and "TDD only" indicates the associated feature is only supported in TDD. "N/A" in the column indicates it is not applicable to the feature (e,g. the signaling supports the UE to have different values between FDD and TDD or between FR1 and FR2).

- 1> set all fields of UE-NR/MRDC-Capability except fdd-Add-UE-NR/MRDC-Capabilities, tdd-Add-UE-NR/MRDC-Capabilities, fr1-Add-UE-NR/MRDC-Capabilities and fr2-Add-UE-NR/MRDC-Capabilities, to include the values applicable for all duplex mode(s) and frequency range(s) that the UE supports;
- 1> if UE supports both FDD and TDD and if (some of) the UE capability fields have a different value for FDD and TDD
 - 2> if for FDD, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field fdd-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FDD;
 - 2> if for TDD, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field tdd-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for TDD;
- 1> if UE supports both FR1 and FR2 and if (some of) the UE capability fields have a different value for FR1 and FR2:
 - 2> if for FR1, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:
 - 3> include field fr1-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR1;
 - 2> if for FR2, the UE supports additional functionality compared to what is indicated by the previous fields of UE-NR/MRDC-Capability:

3> include field fr2-Add-UE-NR/MRDC-Capabilities and set it to include fields reflecting the additional functionality applicable for FR2;

NOTE 1: The fields which indicate "shall be set to 1" or "shall be set to *supported*" in the following tables means these features are purely mandatory and are assumed they are the same as mandatory without capability signaling.

NOTE 2: For the case where the UE is allowed to support different functionality between FDD and TDD and between FR1 and FR2 according to the specification, the UE capability indication is clarified in Annex B.For optional features, the UE radio access capability parameter indicates whether the feature has been implemented and successfully tested. For mandatory features with the UE radio access capability parameter, the parameter indicates whether the feature has been successfully tested. In the table of UE capability parameter in subsequent clauses, "Yes" in the column by "M" indicates the associated feature is mandatory and "No" indicates the associated feature is optional. "CY" in the column indicates the associated feature is conditional mandatory and the condition is described in the field description and the associated feature is considered mandatory with capability parameter, when the described condition is satisfied. "FD" in the column indicates to refer the associated field description. Some parameters in subsequent clauses are not related to UE features and in the case, "N/A" is indicated in the column.

UE capability parameters have hierarchical structure. In the table of UE capability parameter in subsequent clauses, "Per" indicates the level the associated parameter is included. "UE" in the column indicates the associated parameter is signalled per UE, "Band" indicates it is signalled per band, "BC" indicates it is signalled per band combination, "FS" indicates it is signalled per feature set (per band per band combination), "FSPC" indicates it is signalled per feature set per component carrier (per CC per band per band combination), and "FD" in the column indicates to refer the associated field description.

4.2.2 General parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
accessStratumRelease Indicates the access stratum release the UE supports as specified in TS 38.331 [9].	UE	Yes	No	No
delayBudgetReporting Indicates whether the UE supports delay budget reporting as specified in TS 38.331 [9].	UE	No	No	No
inactiveState Indicates whether the UE supports RRC_INACTIVE as specified in TS 38.331 [9].	UE	Yes	No	No
overheatingInd Indicates whether the UE supports overheating assistance information.	UE	No	No	No
reducedCP-Latency Indicates whether the UE supports reduced control plane latency as defined in TS 38.331 [9]	UE	No	No	No
splitSRB-WithOneUL-Path Indicates whether the UE supports UL transmission via MCG path and DL reception via either MCG path or SCG path, as specified for the split SRB in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in UE-MRDC-CapabilityAddXDD-Mode).	UE	No	No	No
splitDRB-withUL-Both-MCG-SCG Indicates whether the UE supports UL transmission via both MCG path and SCG path for the split DRB as specified in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in UE-MRDC-CapabilityAddXDD-Mode).	UE	Yes	No	No
srb3 Indicates whether the UE supports direct SRB between the SN and the UE as specified in TS 37.340 [7]. The UE shall not set the FDD/TDD specific fields for this capability (i.e. it shall not include this field in UE-MRDC-CapabilityAddXDD-Mode). This field is not applied to NE-DC.	UE	Yes	No	No
v2x-EUTRA Indicates whether the UE supports EUTRA V2X according to UE-EUTRA-Capability as defined in TS 36.331 [17], independent of the configured EN-DC band combination. This field is only applied to EN-DC. In UE-NR-Capability, this field is not used, and UE does not include the field.	UE	No	Yes	No

4.2.3 SDAP Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
as-ReflectiveQoS	UE	No	No
Indicates whether the UE supports AS reflective QoS.			

4.2.4 PDCP Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
continueROHC-Context Defines whether the UE supports ROHC context continuation operation where the UE does not reset the current ROHC context upon PDCP re-establishment, as specified in TS 38.323 [16].	UE	No	No
maxNumberROHC-ContextSessions Defines the maximum number of header compression context sessions supported by the UE, excluding context sessions that leave all headers uncompressed.	UE	No	No
outOfOrderDelivery Indicates whether UE supports out of order delivery of data to upper layers by PDCP.	UE	No	No
pdcp-DuplicationMCG-OrSCG-DRB Indicates whether the UE supports CA-based PDCP duplication over MCG or SCG DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSplitDRB Indicates whether the UE supports PDCP duplication over split DRB as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSplitSRB Indicates whether the UE supports PDCP duplication over split SRB1/2 as specified in TS 38.323 [16].	UE	No	No
pdcp-DuplicationSRB Indicates whether the UE supports CA-based PDCP duplication over SRB1/2 and/or, if EN-DC is supported, SRB3 as specified in TS 38.323 [16].	UE	No	No
shortSN Indicates whether the UE supports 12 bit length of PDCP sequence number.	UE	Yes	No
supportedROHC-Profiles Defines which ROHC profiles from the list below are supported by the UE: - 0x0000 ROHC No compression (RFC 5795) - 0x0001 ROHC RTP/UDP/IP (RFC 3095, RFC 4815) - 0x0002 ROHC UDP/IP (RFC 3095, RFC 4815) - 0x0003 ROHC ESP/IP (RFC 3095, RFC 4815) - 0x0004 ROHC IP (RFC 3843, RFC 4815) - 0x0006 ROHC TCP/IP (RFC 6846) - 0x0101 ROHC RTP/UDP/IP (RFC 5225) - 0x0102 ROHC UDP/IP (RFC 5225) - 0x0103 ROHC ESP/IP (RFC 5225) - 0x0104 ROHC IP (RFC 5225) A UE that supports one or more of the listed ROHC profiles shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795). An IMS voice capable UE shall indicate support of ROHC profiles 0x0000, 0x0001, 0x00002 and be able to compress and decompress headers of PDCP SDUs at a PDCP	UE	No	No
SDU rate corresponding to supported IMS voice codecs. uplinkOnlyROHC-Profiles Indicates the ROHC profile(s) that are supported in uplink-only ROHC operation by the UE. - 0x0006 ROHC TCP (RFC 6846) A UE that supports uplink-only ROHC profile(s) shall support ROHC profile 0x0000 ROHC uncompressed (RFC 5795).	UE	No	No

4.2.5 RLC parameters

Definitions for parameters	Per	M	FDD- TDD DIFF
am-WithShortSN	UE	Yes	No
Indicates whether the UE supports AM DRB with 12 bit length of RLC sequence number.			
um-WithLongSN	UE	Yes	No
Indicates whether the UE supports UM DRB with 12 bit length of RLC sequence number.			
um-WithShortSN	UE	Yes	No
Indicates whether the UE supports UM DRB with 6 bit length of RLC sequence number.			

4.2.6 MAC parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
Ich-ToSCellRestriction Indicates whether the UE supports restricting data transmission from a given LCH to a configured (sub-) set of serving cells (see allowedServingCells in LogicalChannelConfig). A UE supporting pdcp-DuplicationMCG-OrSCG-DRB or pdcp-DuplicationSRB (see PDCP-Config) shall also support Ich-ToSCellRestriction.	UE	No	No	No
Icp-Restriction Indicates whether UE supports the selection of logical channels for each UL grant based on RRC configured restriction.	UE	No	No	No
Indicates whether the UE supports the logicalChannelSR-DelayTimer as specified in TS 38.321 [8].	UE	No	Yes	No
Indicates whether UE supports long DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
multipleConfiguredGrants Indicates whether UE supports more than one configured grant configurations (including both Type 1 and Type 2) in a cell group. For each cell, the UE supports at most one configured grant per BWP and the maximum number of configured grant configurations per cell group is 2. If absent, for each configured cell group, the UE only supports one configured grant configuration on one serving cell.	UE	No	Yes	No
multipleSR-Configurations Indicates whether the UE supports 8 SR configurations per PUCCH cell group as specified in TS 38.321 [8].	UE	No	Yes	No
recommendedBitRate Indicates whether the UE supports the bit rate recommendation message from the gNB to the UE as specified in TS 38.321 [8].	UE	No	No	No
recommendedBitRateQuery Indicates whether the UE supports the bit rate recommendation query message from the UE to the gNB as specified in TS 38.321 [8]. This field is only applicable if the UE supports recommendedBitRate.	UE	No	No	No
shortDRX-Cycle Indicates whether UE supports short DRX cycle as specified in TS 38.321 [8].	UE	Yes	Yes	No
SkipUplinkTxDynamic Indicates whether the UE supports skipping of UL transmission for an uplink grant indicated on PDCCH if no data is available for transmission as specified in TS 38.321 [8].	UE	No	Yes	No

- 4.2.7 Physical layer parameters
- 4.2.7.1 BandCombinationList parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
bandEUTRA Defines supported EUTRA frequency band by NR frequency band number, as specified in TS 36.101 [14].	Band	Yes	N/A	N/A
bandList Each entry of the list should include at least one bandwidth class for UL or DL.	ВС	Yes	N/A	N/A
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
ca-BandwidthClassDL-EUTRA Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-DownlinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassDL-NR Defines for DL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetDownlinkld:s in the corresponding FeatureSetsPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-BandwidthClassUL-EUTRA Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 36.101 [14]. When all FeatureSetEUTRA-UplinkId:s in the corresponding FeatureSetsPerBand are zero, this field is absent.	Band	No	N/A	N/A
ca-BandwidthClassUL-NR Defines for UL, the class defined by the aggregated transmission bandwidth configuration and maximum number of component carriers supported by the UE, as specified in TS 38.101-1 [2] and TS 38.101-2 [3]. When all FeatureSetUplinkId:s in the corresponding FeatureSetSetPerBand are zero, this field is absent. For FR1, the value 'F' shall not be used as it is invalidated in TS 38.101-1 [2].	Band	No	N/A	N/A
ca-ParametersEUTRA Contains the EUTRA part of band combination parameters for a given (NG)EN-DC/NE-DC band combination.	ВС	No	N/A	N/A
ca-ParametersNR Contains the NR band combination parameters for a given (NG)EN-DC/NE-DC and/or NR CA band combination.	ВС	No	N/A	N/A
ca-ParametersNRDC Indicates whether the UE supports NR-DC for the band combination. It contains the NR band combination parameters applicable across MCG and SCG. In this version of the standard, a UE indicating support for NR-DC supports only configuration where all serving cells of the MCG are in FR1 and all serving cells of the SCG are in FR2.	ВС	No	N/A	N/A
featureSetCombination Indicates the feature set that the UE supports on the NR and/or MR-DC band combination by FeatureSetCombinationId.	BC	N/A	N/AN o	N/A
mrdc-Parameters Contains the band combination parameters for a given (NG)EN-DC/NE-DC band combination.	ВС	No	N/A	N/A
ne-DC-BC Indicates whether the UE supports NE-DC for the band combination.	ВС	No	N/A	N/A
powerClass Indicates power class the UE supports when operating according to this band combination. If the field is absent, the UE supports the default power class. If this power class is higher than the power class that the UE supports on the individual bands of this band combination (ue-PowerClass in BandNR), the latter determines maximum TX power available in each band. The UE sets the power class parameter only in band combinations that are applicable as specified in TS 38.101-1 [2] and TS 38.101-3 [4].	ВС	No	N/A	FR1 only

SRS-SwitchingTimeNR Indicates the interruption time on DL/UL reception within a NR band pair during the RF retuning for switching between a carrier on one band and another (PUSCH-less) carrier on the other band to transmit SRS. switchingTimeDL/ switchingTimeUL: n0us represents 0 us, n30us represents 30us, and so on. switchingTimeDL/ switchingTimeUL is mandatory present if switching between the NR band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	N/A	N/A
SRS-SwitchingTimeEUTRA Indicates the interruption time on DL/UL reception within a EUTRA band pair during the RF retuning for switching between a carrier on one band and another (PUSCH-less) carrier on the other band to transmit SRS. switchingTimeDL/switchingTimeUL: n0 represents 0 OFDM symbols, n0dot5 represents 0.5 OFDM symbols, n1 represents 1 OFDM symbol and so on. switchingTimeDL/switchingTimeUL is mandatory present if switching between the EUTRA band pair is supported, otherwise the field is absent. It is signalled per pair of bands per band combination.	FD	No	N/A	N/A
 srs-TxSwitch Defines whether UE supports SRS for DL CSI acquisition as defined in clause 6.2.1.2 of TS 38.214 [12]. The capability signalling comprises of the following parameters: supportedSRS-TxPortSwitch indicates SRS Tx port switching pattern supported by the UE. The indicated UE antenna switching capability of 'xTyR' corresponds to a UE, capable of SRS transmission on 'x' antenna ports over total of 'y' antennas, where 'y' corresponds to all or subset of UE receive antennas, where 2T4R is two pairs of antennas; txSwitchImpactToRx indicates the entry number of the first-listed band with UL (see NOTE) in the band combination that affects this DL; txSwitchWithAnotherBand indicates the entry number of the first-listed band with UL (see NOTE) in the band combination that switches together with this UL. For txSwitchImpactToRx and txSwitchWithAnotherBand, value 1 means first entry, value 2 means second entry and so on. All DL and UL that switch together indicate the same entry number. The entry number is the band entry number in a band combination. The UE is restricted not to include fallback band combinations for the purpose of indicating different SRS antenna switching capabilities. NOTE: The first-listed band with UL includes a band associated with FeatureSetUplinkId set to 0 corresponding to the support of SRS-SwitchingTimeNR. 	BC	Yes	N/A	N/A
supportedBandwidthCombinationSet Defines the supported bandwidth combination for the band combination set as defined in the TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. For NR SA CA, NR-DC, inter-band (NG)EN-DC without intra-band (NG)EN-DC component and intra-band (NG)EN-DC with additional inter-band NR CA component, the field defines the bandwidth combinations for the NR part of the band combination. For intra-band (NG)EN-DC without additional inter-band NR and LTE CA component, the field indicates the supported bandwidth combination set applicable to the NR and LTE band combinations. Field encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination as defined in the TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4]. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. It is mandatory if the band combination has more than one NR carrier (at least one SCell in an NR cell group) or is an intra-band (NG)EN-DC combination or both.	ВС	CY	N/A	N/A
supportedBandwidthCombinationSetIntraENDC Defines the supported bandwidth combination for the band combination set as defined in the TS 38.101-3 [4]. For intra-band (NG)EN-DC with additional inter-band CA component(s) of LTE and/or NR, the field defines the bandwidth combinations for the intra-band (NG)EN-DC component. Field encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination as defined in the TS 38.101-3 [4]. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. It is mandatory if the band combination is an intraband (NG)EN-DC combination with additional inter-band NR/LTE CA component.	ВС	CY	N/A	N/A

4.2.7.2 BandNR parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
additionalActiveTCI-StatePDCCH Indicates whether the UE supports one additional active TCI-State for control in addition to the supported number of active TCI-States for PDSCH. The UE can include this field only if maxNumberActiveTCI-PerBWP in tci-StatePDSCH is set to n1. Otherwise, the UE does not include this field.	Band	CY	N/A	N/A
aperiodicBeamReport Indicates whether the UE supports aperiodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH. The UE provides the capability for the band number for which the report is provided (where the measurement is performed).	Band	Yes	N/A	N/A
aperiodicTRS Indicates whether the UE supports DCI triggering aperiodic TRS associated with periodic TRS.	Band	No	N/A	N/A
asymmetricBandwidthCombinationSet Defines the supported asymmetric channel bandwidth combination for the band as defined in the TS 38.101-1 [2]. Field encoded as a bit map, where bit N is set to "1" if UE support asymmetric channel bandwidth combination set N for this band as defined in the TS 38.101-1 [2]. The leading / leftmost bit (bit 0) corresponds to the asymmetric channel bandwidth combination set 1, the next bit corresponds to the asymmetric channel bandwidth combination set 2 and so on. UE shall support asymmetric channel bandwidth combination set 0. If the field is absent, the UE supports asymmetric channel bandwidth combination set 0.	Band	No	No	No
bandNR Defines supported NR frequency band by NR frequency band number, as specified in TS 38.101-1 [2] and TS 38.101-2 [3].	Band	Yes	N/A	N/A
beamCorrespondenceWithoutUL-BeamSweeping Indicates how UE supports FR2 beam correspondence as specified in TS 38.101-2 [3], clause 6.6. The UE that fulfils the beam correspondence requirement without the uplink beam sweeping (as specified in TS 38.101-2 [3], clause 6.6) shall set the field to supported. The UE that fulfils the beam correspondence requirement with the uplink beam sweeping (as specified in TS 38.101-2 [3], clause 6.6) shall not report this field.	Band	Yes	N/A	FR2 only

beamManagementSSB-CSI-RS Defines support of SS/PBCH and CSI-RS based RSRP measurements. The capability comprises signalling of - maxNumberSSB-CSI-RS-ResourceOneTx indicates maximum total number of configured one port NZP CSI-RS resources and SS/PBCH blocks that are supported by the UE to measure L1-RSRP as specified in TS 38.215 [13] within a slot and across all serving cells (see NOTE). On FR2, it is mandatory to report >=8; On FR1, it is mandatory with capability signalling to report >=8.	Band	Yes	N/A	FD
 maxNumberCSI-RS-Resource indicates maximum total number of configured NZP-CSI-RS resources that are supported by the UE to measure L1-RSRP as specified in TS 38.215 [13] across all serving cells (see NOTE). It is mandated to report at least n8 for FR1. 				
 maxNumberCSI-RS-ResourceTwoTx indicates maximum total number of two ports NZP CSI-RS resources that are supported by the UE to measure L1- RSRP as specified in TS 38.215 [13] within a slot and across all serving cells (see NOTE). 				
 supportedCSI-RS-Density indicates density of one RE per PRB for one port NZP CSI-RS resource for RSRP reporting, if supported. On FR2, it is mandatory to report either "three" or "oneAndThree"; On FR1, it is mandatory with capability signalling to report either "three" or "oneAndThree". 				
 maxNumberAperiodicCSI-RS-Resource indicates maximum number of configured aperiodic CSI-RS resources across all serving cells (see NOTE). For FR1 and FR2, the UE is mandated to report at least n4. 				
NOTE: If the UE sets a value other than $n0$ in an FR1 band, it shall set that same value in all FR1 bands. If the UE sets a value other than $n0$ in an FR2 band, it shall set that same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells.				
beamReportTiming Indicates the number of OFDM symbols between the last symbol of SSB/CSI-RS and the first symbol of the transmission channel containing beam report. The UE provides the capability for the band number for which the report is provided (where the measurement is performed). The UE includes this field for each supported subcarrier spacing.	Band	Yes	N/A	N/A
beamSwitchTiming Indicates the minimum number of OFDM symbols between the DCI triggering of	Band	No	N/A	FR2 only
aperiodic CSI-RS and aperiodic CSI-RS transmission. The number of OFDM symbols is measured from the last symbol containing the indication to the first symbol of CSI-RS. The UE includes this field for each supported sub-carrier spacing. If this field is not included, the beam switch timing is up to 48 OFDM symbols for each supported sub-carrier spacing.				
bwp-DiffNumerology Indicates whether the UE supports BWP adaptation up to 4 BWPs with the different numerologies, via DCI and timer. For the UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP includes the bandwidth of the CORESET#0 (if CORESET#0 is present) and SSB for PCell and PSCell (if configured). For SCell(s), the bandwidth of the UE-specific RRC configured DL BWP includes SSB, if there is SSB on SCell(s).	Band	No	N/A	N/A
bwp-SameNumerology Defines type A/B BWP adaptation (up to 2/4 BWPs) with the same numerology, via DCI and timer. For the UE capable of this feature, the bandwidth of a UE-specific RRC configured DL BWP includes the bandwidth of the CORESET#0 (if CORESET#0 is present) and SSB for PCell and PSCell (if configured). For SCell(s), the bandwidth of the UE-specific RRC configured DL BWP includes SSB, if there is	Band	No	N/A	N/A
SSB on SCell(s). bwp-WithoutRestriction Indicates support of BWP operation without bandwidth restriction. The Bandwidth restriction in terms of DL BWP for PCell and PSCell means that the bandwidth of a UE-specific RRC configured DL BWP may not include the bandwidth of CORESET #0 (if configured) and SSB. For SCell(s), it means that the bandwidth of DL BWP may not include SSB.	Band	No	N/A	N/A

channelBWs-DL	Band	Yes	N/A	N/A
Indicates for each subcarrier spacing the UE supported channel bandwidths.				
Absence of the <i>channelBWs-DL</i> (without suffix) for a band or absence of specific				
scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the				
channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100,				
200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS				
38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry.				
For FR1, the bits in <i>channelBWs-DL</i> (without suffix) starting from the leading /				
leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in				
channelBWs-DL (without suffix) starting from the leading / leftmost bit indicate 50,				
100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1.				
For FR1, the leading/leftmost bit in <i>channelBWs-DL-v1590</i> indicates 70MHz, and all				
the remaining bits in <i>channelBWs-DL-v1590</i> shall be set to 0.				
NOTE: To determine whether the UE supports a specific SCS for a given band,				
the network validates the supportedSubCarrierSpacingDL and the scs-				
60kHz.				
To determine whether the UE supports a channel bandwidth of 90 MHz,				
the network may ignore this capability for and validate instead the				
channelBW-90mhz and the supportedBandwidthCombinationSet. For				
serving cells with other channel bandwidths the network validates the				
channelBWs-DL, the supportedBandwidthCombinationSet, the				
asymmetricBandwidthCombinationSet (for a band supporting asymmetric channel bandwidth as defined in clause 5.3.6 of TS 38.101-1 [2]) and				
supportedBandwidthDL.				
	Band	Yes	N/A	N/A
channelBWs-UL	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths.	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry.	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading /	Band	Yes	N/A	N/A
ChannelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50,	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1.	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and	Band	Yes	N/A	N/A
<i>channelBWs-UL</i> Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the <i>channelBWs-UL</i> (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in <i>channelBWs-UL</i> (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in <i>channelBWs-UL</i> (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1.	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the <i>channelBWs-UL</i> (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in <i>channelBWs-UL</i> (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in <i>channelBWs-UL</i> (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in <i>channelBWs-UL-v1590</i> indicates 70 MHz, and all the remaining bits in <i>channelBWs-UL-v1590</i> shall be set to 0.	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz.	Band	Yes	N/A	N/A
 channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz. To determine whether the UE supports a channel bandwidth of 90 MHz 	Band	Yes	N/A	N/A
 channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz. To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the 	Band	Yes	N/A	N/A
 channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz. To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For 	Band	Yes	N/A	N/A
 ChannelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz. To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the 	Band	Yes	N/A	N/A
ChannelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz. To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-UL, the supportedBandwidthCombinationSet, the	Band	Yes	N/A	N/A
ChannelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz. To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-UL, the supportedBandwidthCombinationSet, the asymmetricBandwidthCombinationSet (for a band supporting asymmetric	Band	Yes	N/A	N/A
channelBWs-UL Indicates for each subcarrier spacing the UE supported channel bandwidths. Absence of the channelBWs-UL (without suffix) for a band or absence of specific scs-XXkHz entry for a supported subcarrier spacing means that the UE supports the channel bandwidths among [5, 10, 15, 20, 25, 30, 40, 50, 60, 80, 100] and [50, 100, 200] that were defined in clause 5.3.5 of TS 38.101-1 version 15.7.0 [2] and TS 38.101-2 version 15.7.0 [3] for the given band or the specific SCS entry. For FR1, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 5, 10, 15, 20, 25, 30, 40, 50, 60 and 80MHz. For FR2, the bits in channelBWs-UL (without suffix) starting from the leading / leftmost bit indicate 50, 100 and 200MHz. The third / rightmost bit (for 200MHz) shall be set to 1. For FR1, the leading/leftmost bit in channelBWs-UL-v1590 indicates 70 MHz, and all the remaining bits in channelBWs-UL-v1590 shall be set to 0. NOTE: To determine whether the UE supports a specific SCS for a given band, the network validates the supportedSubCarrierSpacingUL and the scs-60kHz. To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-UL, the supportedBandwidthCombinationSet, the	Band	Yes	N/A	N/A

codebookParameters	Band	FD	N/A	N/A
Indicates the codebooks and the corresponding parameters supported by the UE.	Danu	ן ו	11/7	11//
The state of the s				
Parameters for type I single panel codebook (type1 singlePanel) supported by the				
UE, which are mandatory to report:				
- supportedCSI-RS-ResourceList;				
- a UE shall support a maxNumberTxPortsPerResource minimum value of				
4 for codebook type I single panel in FR1 in the case of a single active				
CSI-resource across all bands in a band combination, regardless of what				
it reports in supportedCSI-RS-ResourceList with maxNumberTxPortsPerResource;				
- a UE shall support a <i>maxNumberTxPortsPerResource</i> minimum value of				
8 when configured with wideband CSI report for codebook type I single				
panel in FR1 in the case of a single active CSI-resource across all bands				
in a band combination, regardless of what it reports in <i>supportedCSI-RS</i> -				
ResourceList with maxNumberTxPortsPerResource;				
- a UE shall support a maxNumberTxPortsPerResource minimum value of				
2 for codebook type I single panel in FR2 in the case of a single active				
CSI-resource across all bands in a band combination, regardless of what				
it reports in supportedCSI-RS-ResourceList with				
maxNumberTxPortsPerResource.				
- modes indicates supported codebook modes (mode 1, both mode 1 and				
mode 2);				
 maxNumberCSI-RS-PerResourceSet indicates the maximum number of CSI- RS resource in a resource set. 				
KS resource in a resource set.				
Parameters for type I multi-panel codebook (type1 multiPanel) supported by the UE,				
which are optional:				
- supportedCSI-RS-ResourceList;				
 modes indicates supported codebook modes (mode 1, mode 2, or both 				
mode 1 and mode 2);				
- maxNumberCSI-RS-PerResourceSet indicates the maximum number of CSI-				
RS resource in a resource set;				
- nrofPanels indicates supported number of panels.				
Parameters for type II codebook (type2) supported by the UE, which are optional:				
- supportedCSI-RS-ResourceList,				
- parameterLx indicates the parameter "Lx" in codebook generation where x is				
an index of Tx ports indicated by <i>maxNumberTxPortsPerResource</i> ;				
 amplitudeScalingType indicates the amplitude scaling type supported by the 				
UE (wideband or both wideband and sub-band);				
- amplitudeSubsetRestriction indicates whether amplitude subset restriction is				
supported for the UE.				
Parameters for type II codebook with port selection (type2-PortSelection) supported				
by the UE, which are optional:				
- supportedCSI-RS-ResourceList;				
- parameterLx indicates the parameter "Lx" in codebook generation where x is				
an index of Tx ports indicated by maxNumberTxPortsPerResource;				
- amplitudeScalingType indicates the amplitude scaling type supported by the				
UE (wideband or both wideband and sub-band).				
supportedCSI-RS-ResourceList includes list of the following parameters:				
- maxNumberTxPortsPerResource indicates the maximum number of Tx ports				
in a resource;				
- maxNumberResourcesPerBand indicates the maximum number of resources				
across all CCs within a band simultaneously;				
- totalNumberTxPortsPerBand indicates the total number of Tx ports across all				
CCs within a band simultaneously.				
crossCarrierScheduling-SameSCS	Band	No	N/A	N/A
Indicates whether the UE supports cross carrier scheduling for the same				".
numerology with carrier indicator field (CIF) in carrier aggregation where				
numerologies for the scheduling cell and scheduled cell are same.				

csi-ReportFramework	Band	Yes	N/A	N/A
Indicates whether the UE supports CSI report framework. This capability signalling comprises the following parameters:	Danu	162	IN/A	IN/A
 maxNumberPeriodicCSI-PerBWP-ForCSI-Report indicates the maximum number of periodic CSI report setting per BWP for CSI report; 				
 maxNumberPeriodicCSI-PerBWP-ForBeamReport indicates the maximum number of periodic CSI report setting per BWP for beam report. 				
 maxNumberAperiodicCSI-PerBWP-ForCSI-Report indicates the maximum number of aperiodic CSI report setting per BWP for CSI report; 				
 maxNumberAperiodicCSI-PerBWP-ForBeamReport indicates the maximum number of aperiodic CSI report setting per BWP for beam report; 				
 maxNumberAperiodicCSI-triggeringStatePerCC indicates the maximum number of aperiodic CSI triggering states in CSI-AperiodicTriggerStateList per CC; 				
 maxNumberSemiPersistentCSI-PerBWP-ForCSI-Report indicates the maximum number of semi-persistent CSI report setting per BWP for CSI report; 				
 maxNumberSemiPersistentCSI-PerBWP-ForBeamReport indicates the maximum number of semi-persistent CSI report setting per BWP for beam report; 				
 simultaneousCSI-ReportsPerCC indicates the number of CSI report(s) for which the UE can measure and process reference signals simultaneously in a CC of the band for which this capability is provided. The CSI report comprises periodic, semi-persistent and aperiodic CSI and any latency classes and codebook types. The CSI report in simultaneousCSI- ReportsPerCC includes the beam report and CSI report. 				
The UE is mandated to report csi-ReportFramework.				
csi-RS-ForTracking	Band	Yes	N/A	N/A
Indicates support of CSI-RS for tracking (i.e. TRS). This capability signalling comprises the following parameters:				
- maxBurstLength indicates the TRS burst length. Value 1 indicates 1 slot and				
value 2 indicates both of 1 slot and 2 slots. In this release UE is mandated to report value 2;				
 maxSimultaneousResourceSetsPerCC indicates the maximum number of TRS resource sets per CC which the UE can track simultaneously; 				
 maxConfiguredResourceSetsPerCC indicates the maximum number of TRS resource sets configured to UE per CC. It is mandated to report at least 8 for FR1 and 16 for FR2; 				
- maxConfiguredResourceSetsAllCC indicates the maximum number of TRS resource sets configured to UE across CCs. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. The UE is mandated to report at least 16 for FR1 and 32 for FR2.				
The UE is mandated to report csi-RS-ForTracking.				

 csi-RS-IM-ReceptionForFeedback Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability signalling comprises the following parameters: maxConfigNumberNZP-CSI-RS-PerCC indicates the maximum number of configured NZP-CSI-RS resources per CC; 	Band	Yes	N/A	N/A
 maxConfigNumberPortsAcrossNZP-CSI-RS-PerCC indicates the maximum number of ports across all configured NZP-CSI-RS resources per CC; 				
 maxConfigNumberCSI-IM-PerCC indicates the maximum number of configured CSI-IM resources per CC; 				
 maxNumberSimultaneousNZP-CSI-RS-PerCC indicates the maximum number of simultaneous CSI-RS-resources per CC; 				
 totalNumberPortsSimultaneousNZP-CSI-RS-PerCC indicates the total number of CSI-RS ports in simultaneous CSI-RS resources per CC. 				
The UE is mandated to report csi-RS-IM-ReceptionForFeedback.				
csi-RS-ProcFrameworkForSRS Indicates support of CSI-RS processing framework for SRS. This capability signalling comprises the following parameters: - maxNumberPeriodicSRS-AssocCSI-RS-PerBWP indicates the maximum number of periodic SRS resources associated with CSI-RS per BWP;	Band	No	N/A	N/A
 maxNumberAperiodicSRS-AssocCSI-RS-PerBWP indicates the maximum number of aperiodic SRS resources associated with CSI-RS per BWP; 				
 maxNumberSP-SRS-AssocCSI-RS-PerBWP indicates the maximum number of semi-persistent SRS resources associated with CSI-RS per BWP; 				
 simultaneousSRS-AssocCSI-RS-PerCC indicates the number of SRS resources that the UE can process simultaneously in a CC, including periodic, aperiodic and semi-persistent SRS. 				
extendedCP Indicates whether the UE supports 60 kHz subcarrier spacing with extended CP length for reception of PDCCH, and PDSCH, and transmission of PUCCH, PUSCH, and SRS.	Band	No	N/A	N/A
groupBeamReporting Indicates whether UE supports RSRP reporting for the group of two reference signals.	Band	No	N/A	N/A
maxNumberCSI-RS-BFD Indicates maximal number of CSI-RS resources across all CCs, and across MCG and SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the maximum value that can be signalled is 16. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1.	Band	CY	N/A	N/A
maxNumberCSI-RS-SSB-CBD Defines maximal number of different CSI-RS [and/or SSB] resources across all CCs, and across MCG and SCG in case of NR-DC, for new beam identifications. In this release, the maximum value that can be signalled is 128. If the UE includes the field in an FR1 band, it shall set the same value in all FR1 bands. If the UE includes the field in an FR2 band, it shall set the same value in all FR2 bands. The UE supports a total number of resources equal to the maximum of the FR1 and FR2 value, but no more than the FR1 value across all FR1 serving cells and no more than the FR2 value across all FR2 serving cells. It is mandatory with capability signalling for FR2 and optional for FR1. The UE is mandated to report at least 32 for FR2.	Band	CY	N/A	N/A
maxNumberNonGroupBeamReporting Defines support of non-group based RSRP reporting using N_max RSRP values reported.	Band	Yes	N/A	N/A

maxNumberRxBeam	Band	CY	N/A	N/A
Defines whether UE supports receive beamforming switching using NZP CSI-RS				
resource. UE shall indicate a single value for the preferred number of NZP CSI-RS				
resource repetitions per CSI-RS resource set. Support of Rx beam switching is				
mandatory for FR2.				
maxNumberRxTxBeamSwitchDL	Band	No	N/A	FR2
Defines the number of Tx and Rx beam changes UE can perform on this band				only
within a slot. UE shall report one value per each subcarrier spacing supported by				
the UE. In this release, the number of Tx and Rx beam changes for scs-15kHz and				
scs-30kHz are not included.	ļ	0)/		
maxNumberSSB-BFD	Band	CY	N/A	N/A
Defines maximal number of different SSBs across all CCs, and across MCG and				
SCG in case of NR-DC, for UE to monitor PDCCH quality. In this release, the				
maximum value that can be signalled is 16. If the UE includes the field in an FR1				
band, it shall set the same value in all FR1 bands. If the UE includes the field in an				
FR2 band, it shall set the same value in all FR2 bands. The UE supports a total				
number of resources equal to the maximum of the FR1 and FR2 value, but no more				
than the FR1 value across all FR1 serving cells and no more than the FR2 value				
across all FR2 serving cells. It is mandatory with capability signalling for FR2 and				
optional for FR1.	D		N1/A	
maxUplinkDutyCycle-PC2-FR1	Band	No	N/A	FR1
Indicates the maximum percentage of symbols during a certain evaluation period				only
that can be scheduled for uplink transmission so as to ensure compliance with				
applicable electromagnetic energy absorption requirements provided by regulatory				
bodies. This field is only applicable for FR1 power class 2 UE as specified in clause				
6.2.1 of TS 38.101-1 [2]. If the field is absent, 50% shall be applied. Value n60				
corresponds to 60%, value n70 corresponds to 70% and so on.	ļ			
maxUplinkDutyCycle-FR2	Band	No	N/A	FR2
Indicates the maximum percentage of symbols during 1s that can be scheduled for				only
uplink transmission at the UE maximum transmission power, so as to ensure				
compliance with applicable electromagnetic power density exposure requirements				
provided by regulatory bodies. This field is applicable for all power classes UE in				
FR2 as specified in TS 38.101-2 [3]. Value n15 corresponds to 15%, value n20				
corresponds to 20% and so on. If the field is absent or the percentage of uplink				
symbols transmitted within any 1s evaluation period is larger than				
maxUplinkDutyCycle-FR2, the UE behaviour is specified in TS 38.101-2 [3].	D	N.	N1/A	N1/A
modifiedMPR-Behaviour	Band	No	N/A	N/A
Indicates whether UE supports modified MPR behaviour defined in TS 38.101-1 [2]				
and TS 38.101-2 [3].	D		N1/A	N1/A
multipleTCI	Band	Yes	N/A	N/A
Indicates whether UE supports more than one TCI state configurations per				
CORESET. UE is only required to track one active TCl state per CORESET. UE is				
required to support minimum between 64 and number of configured TCI states				
indicated by tci-StatePDSCH. This field shall be set to supported.	Donal	NIa	NI/A	FDA
pdsch-256QAM-FR2	Band	No	N/A	FR2
Indicates whether the UE supports 256QAM modulation scheme for PDSCH for				only
FR2 as defined in 7.3.1.2 of TS 38.211 [6].	Daniel	V	NI/A	N1/A
periodicBeamReport	Band	Yes	N/A	N/A
Indicates whether UE supports periodic 'CRI/RSRP' or 'SSBRI/RSRP' reporting				
using PUCCH formats 2, 3 and 4 in one slot.	D .		TDD	
powerBoosting-pi2BPSK	Band	No	TDD	FR1
Indicates whether UE supports power boosting for pi/2 BPSK, when applicable as			only	only
defined in 6.2 of TS 38.101-1 [2].	D	0)(N1/A	N1/A
ptrs-DensityRecommendationSetDL	Band	CY	N/A	N/A
For each supported sub-carrier spacing, indicates preferred threshold sets for				
determining DL PTRS density. It is mandated for FR2. For each supported sub-				
carrier spacing, this field comprises:				
- two values of frequencyDensity;				
three values of time Doneits				
- three values of timeDensity.				

<pre>ptrs-DensityRecommendationSetUL For each supported sub-carrier spacing, indicates preferred threshold sets for determining UL PTRS density. For each supported sub-carrier spacing, this field comprises:</pre>	Band	No	N/A	N/A
Indicates whether the UE supports indication of <i>PUCCH-spatialrelationinfo</i> by a MAC CE per PUCCH resource. It is mandatory for FR2 and optional for FR1.				
pusch-256QAM Indicates whether the UE supports 256QAM modulation scheme for PUSCH as defined in 6.3.1.2 of TS 38.211 [6].	Band	No	N/A	N/A
pusch-TransCoherence Defines support of the uplink codebook subset by the UE for UL precoding for PUSCH transmission as described in clause 6.1.1.1 of TS 38.214 [12]. UE indicated support of partial coherent codebook subset shall also support non-coherent codebook subset. UE indicated support of full coherent codebook subset shall also support partial and non-coherent codebook subset.	Band	No	N/A	N/A
rateMatchingLTE-CRS Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs determined by the higher layer configuration LTE-carrier configuring common RS, as specified in TS 38.214 [12].	Band	Yes	N/A	N/A
 spatialRelations Indicates whether the UE supports spatial relations. The capability signalling comprises the following parameters. maxNumberConfiguredSpatialRelations indicates the maximum number of configured spatial relations per CC for PUCCH and SRS. It is not applicable to FR1 and applicable to FR2 only. The UE is mandated to report 16 or higher values; maxNumberActiveSpatialRelations indicates the maximum number of active spatial relations with regarding to PUCCH and SRS for PUSCH, per BWP per CC. It is not applicable to FR1 and applicable and mandatory to report one or higher value for FR2 only; additionalActiveSpatialRelationPUCCH indicates support of one additional active spatial relation for PUCCH. It is mandatory with capability signalling if maxNumberActiveSpatialRelations is set to n1; maxNumberDL-RS-QCL-TypeD indicates the maximum number of downlink RS resources used for QCL type D in the active TCl states and active spatial relation information, which is optional. The UE is mandated to report spatialRelations for FR2. 	Band	FD	N/A	FD
sp-BeamReportPUCCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting using PUCCH formats 2, 3 and 4 in one slot.	Band	No	N/A	N/A
sp-BeamReportPUSCH Indicates support of semi-persistent 'CRI/RSRP' or 'SSBRI/RSRP' reporting on PUSCH.	Band	No	N/A	N/A
 srs-AssocCSI-RS Parameters for the calculation of the precoder for SRS transmission based on channel measurements using associated NZP CSI-RS resource (srs-AssocCSI-RS) as described in clause 6.1.1.2 of TS 38.214 [12]. UE supporting this feature shall also indicate support of non-codebook based PUSCH transmission. This capability signalling includes list of the following parameters: maxNumberTxPortsPerResource indicates the maximum number of Tx ports in a resource; maxNumberResourcesPerBand indicates the maximum number of resources across all CCs within a band simultaneously; totalNumberTxPortsPerBand indicates the total number of Tx ports across all CCs within a band simultaneously. 	Band	No	N/A	N/A

following parameters: - maxNumberConfiguredTClstate configured TCI-states per CC for	CH. The capability signalling comprises the esPerCC indicates the maximum number of or PDSCH. For FR2, the UE is mandated to e UE is mandated to set these values to the SBs in the supported band:	Band	Yes	N/A	N/A
- maxNumberActiveTCI-PerBWF TCI-states per BWP per CC, inc active TCI state(s), it is not exp assumption(s) for any PDSCH a	Pindicates the maximum number of activated cluding control and data. If a UE reports X ected that more than X active QCL type D and any CORESETs for a given BWP of a he UE. The UE shall include this field.				
Note the UE is required to track only the	ne active TCI states.				
The UE is mandated to report tci-State	PDSCH.				
twoPortsPTRS-UL Defines whether UE supports PT-RS v	vith 2 antenna ports for UL transmission.	Band	No	N/A	N/A
ue-PowerClass		Band	Yes	N/A	N/A
class as defined in clause 6.2 of TS 38	nt UE power class than the default UE power 3.101-1 [2], the UE shall report the supported UE shall report the supported UE power class 101-2 [3] in this field.				
uplinkBeamManagement		Band	No	N/A	FR2
Defines support of beam management	for UL. This capability signalling comprises				only
the following parameters:					
	Set-BM indicates the maximum number of				
SRS resources per SRS resour supported by the UE.	ce set configurable for beam management,				
	indicates the maximum number of SRS peam management, supported by the UE.				
	ndenceWithoutUL-BeamSweeping to pability. This feature is optional for the UE that ut uplink beam sweeping as defined in clause				
maximum number of SRS re	berSRS-ResourceSet to determine the esource sets that can be configured to the UE aperiodic configurations as below:				
Maximum number of SRS resource sets across all time domain behaviour (periodic/semi- persistent/aperiodic) reported in maxNumberSRS-ResourceSet	Additional constraint on the maximum number of SRS resource sets configured to the UE for each supported time domain behaviour (periodic/semi-persistent/aperiodic)				
1	1				
2	1				
3	1				
4	2				
5	2				
6	2				
7	4				
8	4	1			

4.2.7.3 CA-ParametersEUTRA

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
additionalRx-Tx-PerformanceReq	BC	No	N/A	N/A
additionalRx-Tx-PerformanceReq defined in 4.3.5.22, TS 36.306 [15].				
dl-1024QAM-TotalWeightedLayers Indicates total number of weighted layers for the LTE part of the concerned (NG)EN-DC/NE-DC band combination the UE can process for 1024QAM, as described in TS 36.306 [15] equation 4.3.5.31-1. Actual value = (10 + indicated value x 2), i.e. value 0 indicates 10 layers, value 1 indicates 12 layers and so on. For an (NG)EN-DC/NE-DC band combination for which this field is not included, dl- 1024QAM-TotalWeightedLayers-r15 as described in TS 36.331 [17] applies, if included.	BC	No	N/A	N/A
multipleTimingAdvance multipleTimingAdvance defined in 4.3.5.3, TS 36.306 [15].	ВС	No	N/A	N/A
simultaneousRx-Tx simultaneousRx-Tx defined in 4.3.5.4, TS 36.306 [15].	ВС	No	N/A	N/A
supportedBandwidthCombinationSetEUTRA Indicates the set of supported bandwidth combinations for the LTE part for interband (NG)EN-DC without intra-band (NG)EN-DC component and intra-band (NG)EN-DC with additional inter-band LTE CA component. The field is encoded as a bit map, where bit N is set to "1" if UE support Bandwidth Combination Set N for this band combination. The leading / leftmost bit (bit 0) corresponds to the Bandwidth Combination Set 0, the next bit corresponds to the Bandwidth Combination Set 1 and so on. The UE shall neither include the field for a (NG)EN-DC combination which has only one LTE carrier, nor for a (NG)EN-DC combination which has more than one LTE carrier for which the UE only supports Bandwidth Combination Set 0 for the LTE part. If the inter-band (NG)EN-DC has more than one LTE carrier, the UE shall support at least one bandwidth combination for the supported LTE part.	ВС	CY	N/A	N/A
supportedNAICS-2CRS-AP supportedNAICS-2CRS-AP defined in 4.3.5.8, TS 36.306 [15].	BC	No	N/A	N/A
fd-MIMO-TotalWeightedLayers Indicates total number of weighted layers for the LTE part of the concerned (NG)EN-DC/NE-DC band combination the UE can process for FD-MIMO, as described in TS 36.306 [15] equation 4.3.28.13-1 and TS 36.331 [17] clause 6.3.6, NOTE 8 in UE-EUTRA-Capability field descriptions. For an (NG)EN-DC/NE-DC band combination for which this field is not included, totalWeightedLayers-r13 as described in TS 36.331 [17] applies, if included.	BC	No	N/A	N/A
ue-CA-PowerClass-N ue-CA-PowerClass-N defined in 4.3.5.1.3, TS 36.306 [15].	ВС	No	N/A	N/A

4.2.7.4 *CA-ParametersNR*

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
Csi-RS-IM-ReceptionForFeedbackPerBandComb Indicates support of CSI-RS and CSI-IM reception for CSI feedback. This capability signalling comprises the following parameters: - maxNumberSimultaneousNZP-CSI-RS-ActBWP-AllCC indicates the maximum number of simultaneous CSI-RS resources in active BWPs across all CCs, and across MCG and SCG in case of NR-DC. This parameter limits the total number of NZP-CSI-RS resources that the NW may configure across all CCs, and across MCG and SCG in case of NR-DC (irrespective of the associated codebook type). The network applies this limit in addition to the limits signalled in MIMO-ParametersPerBand-> maxNumberSimultaneousNZP-CSI-RS-PerCC and in Phy-ParametersFRX-Diff-> maxNumberSimultaneousNZP-CSI-RS-PerCC; - totalNumberPortsSimultaneousNZP-CSI-RS-ActBWP-AllCC indicates the total number of CSI-RS ports in simultaneous CSI-RS resources in active BWPs across all CCs, and across MCG and SCG in case of NR-DC. This parameter limits the total number of ports that the NW may configure across all NZP-CSI-RS resources across all CCs, and across MCG and SCG in case of NR-DC (irrespective of the associated codebook type). The network applies this limit in addition to the limits signalled in MIMO-ParametersPerBand-> totalNumberPortsSimultaneousNZP-CSI-RS-PerCC and in Phy-ParametersFRX-Diff-> totalNumberPortsSimultaneousNZP-CSI-RS-PerCC.	BC	Yes	N/A	N/A
The UE is mandated to report csi-RS-IM-ReceptionForFeedbackPerBandComb. diffNumerologyAcrossPUCCH-Group Indicates whether different numerology across two NR PUCCH groups for data and control channel at a given time in NR CA and (NG)EN-DC/NE-DC is supported by the UE.	ВС	No	N/A	N/A
diffNumerologyWithinPUCCH-GroupLargerSCS Indicates whether UE supports different numerology across carriers within a PUCCH group and a same numerology between DL and UL per carrier for data/control channel at a given time in NR CA, (NG)EN-DC/NE-DC and NR-DC. In case of NR CA and (NG)EN-DC/NE-DC with one NR PUCCH group and in case of NR CA with two NR PUCCH groups, it also indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group up to two different numerologies within the same NR PUCCH group, wherein NR PUCCH is sent on the carrier with larger SCS for data and control channel at a given time. In case of (NG)EN-DC/NE-DC with two NR PUCCH groups, it indicates whether the UE supports different numerologies across NR carriers up to two different numerologies within an NR PUCCH group in FR1, wherein NR PUCCH is sent on the carrier with larger SCS, and same numerology across NR carriers within another NR PUCCH group in FR2 for data and control channel at a given time. In case of NR-DC, it indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group in MCG (in FR1) up to two different numerologies within the same NR PUCCH group wherein NR PUCCH is sent on the carrier with larger SCS for data/control channel at a given time; and same numerology across NR carriers in SCG (in FR2).	BC	No	N/A	N/A

Indicates whether UE supports different numerology across carriers within a PUCCH group and a same numerology between DL and UL per carrier for data/control channel at a given time in NR CA, (NG)EN-DC/NE-DC and NR-DC. In case of NR CA and (NG)EN-DC/NE-DC with one NR PUCCH group and in case of NR CA with two NR PUCCH groups, it also indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group up to two different numerologies within the same NR PUCCH group, wherein NR PUCCH is sent on the carrier with smaller SCS for data and control channel at a given time. In case of (NG)EN-DC/NE-DC with two NR PUCCH groups, it indicates whether the UE supports different numerologies across NR carriers up to two different numerologies within an NR PUCCH group in FR1, wherein NR PUCCH is sent on the carrier with smaller SCS, and same numerology across NR carriers within another NR PUCCH group in FR2 for data and control channel at a given time. In case of NR-DC, it indicates whether the UE supports different numerologies across NR carriers within the same NR PUCCH group in MCG (in FR1) up to two different numerologies within the same NR PUCCH group wherein NR PUCCH is sent on the carrier with smaller SCS for data/control channel at a given time; and same numerology across NR carriers in SCG (in FR2).	ВС	No	N/A	N/A
dualPA-Architecture For band combinations with single-band with UL CA, this field indicates the support of dual PA. If absent in such band combinations, the UE supports single PA for all the ULs. For other band combinations, this field is not applicable.	BC	No	N/A	N/A
parallelTxSRS-PUCCH-PUSCH Indicates whether the UE supports parallel transmission of SRS and PUCCH/ PUSCH across CCs in an inter-band CA band combination.	BC	No	N/A	N/A
paralleITxPRACH-SRS-PUCCH-PUSCH Indicates whether the UE supports parallel transmission of PRACH and SRS/PUCCH/PUSCH across CCs in an inter-band CA band combination.	ВС	No	N/A	N/A
simultaneous CSI-Reports AIICC Indicates whether the UE supports CSI report framework and the number of CSI report(s) which the UE can simultaneously process across all CCs, and across MCG and SCG in case of NR-DC. The CSI report comprises periodic, semi-persistent and aperiodic CSI and any latency classes and codebook types. The CSI report in simultaneous CSI-Reports AIICC includes the beam report and CSI report. This parameter may further limit simultaneous CSI-Reports PerCC in MIMO-Parameters PerBand and Phy-Parameters FRX-Diff for each band in a given band combination.	BC	Yes	N/A	N/A
simultaneousRxTxInterBandCA Indicates whether the UE supports simultaneous transmission and reception in TDD-TDD and TDD-FDD inter-band NR CA. It is mandatory for certain TDD-FDD and TDD-TDD band combinations defined in TS 38.101-1 [2], TS 38.101-2 [3] and TS 38.101-3 [4].	ВС	CY	N/A	N/A
simultaneousRxTxSUL Indicates whether the UE supports simultaneous reception and transmission for a NR band combination including SUL. Mandatory/Optional support depends on band combination and captured in TS 38.101-1 [2].	ВС	CY	N/A	N/A
simultaneousSRS-AssocCSI-RS-AIICC Indicates support of CSI-RS processing framework for SRS and the number of SRS resources that the UE can process simultaneously across all CCs, and across MCG and SCG in case of NR-DC, including periodic, aperiodic and semi-persistent SRS. This parameter may further limit simultaneousSRS-AssocCSI-RS-PerCC in MIMO-ParametersPerBand and Phy-ParametersFRX-Diff for each band in a given band combination.	BC	No	N/A	N/A
SupportedNumberTAG Defines the number of timing advance groups supported by the UE. It is applied to NR CA, NR-DC and (NG)EN-DC/NE-DC. For (NG)EN-DC/NE-DC, it indicates number of TAGs only for NR CG. The number of TAGs for the LTE MCG is signalled by existing LTE TAG capability signalling. For NR CA/NR-DC band combination, if the band combination comprised of more than one band entry (i.e., inter-band or intra-band non-contiguous band combination), it indicates that different timing advances on different band entries are supported. If absent, the UE supports only one TAG for the NR part. It is mandatory for the UE to support more than one TAG for NR-DC.	ВС	CY	N/A	N/A

4.2.7.5 FeatureSetDownlink parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
additionalDMRS-DL-Alt	FS	No	N/A	FR1
Indicates whether the UE supports the alternative additional DMRS position for co- existence with LTE CRS. It is applied to 15kHz SCS and one additional DMRS case only.				only
crossCarrierScheduling-OtherSCS	FS	No	N/A	N/A
Indicates whether the UE supports cross carrier scheduling for the different numerologies with carrier indicator field (CIF) in DL carrier aggregation where numerologies for the scheduling cell and scheduled cell are different. NOTE: Cross-carrier scheduling with different numerologies is not supported in this release of specification.				
csi-RS-MeasSCellWithoutSSB	FS	No	N/A	N/A
Defines whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that does not transmit SS/PBCH block. A UE that supports this feature shall also support scellWithoutSSB.				
dl-MCS-TableAlt-DynamicIndication	FS	No	N/A	N/A
Indicates whether the UE supports dynamic indication of MCS table for PDSCH.				
featureSetListPerDownlinkCC Indicates which features the UE supports on the individual DL carriers of the feature set (and hence of a band entry that refer to the feature set) by FeatureSetDownlinkPerCC-Id. The UE shall hence include as many FeatureSetDownlinkPerCC-Id in this list as the number of carriers it supports according to the ca-bandwidthClassDL. The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the FeatureSetDownlinkPerCC-Id in this list. A fallback per CC feature set resulting from the reported feature set per DL CC is not signalled but the UE shall support it.	FS	N/A	N/A	N/A
intraBandFreqSeparationDL	FS	CY	N/A	FR2
Indicates DL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the FeatureSetDownlink of each band entry within a band. The values c1, c2 and c3 correspond to the values defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports DL intra-band non-contiguous CA in FR2.				only
oneFL-DMRS-ThreeAdditionalDMRS-DL Defines whether the UE supports DM-RS pattern for DL transmission with 1 symbol front-loaded DM-RS with three additional DM-RS symbols.	FS	No	N/A	N/A
oneFL-DMRS-TwoAdditionalDMRS-DL Defines support of DM-RS pattern for DL transmission with 1 symbol front-loaded DM-RS with 2 additional DM-RS symbols and more than 1 antenna ports.	FS	Yes	N/A	N/A
pdcch-MonitoringAnyOccasions Defines the supported PDCCH search space monitoring occasions. withoutDCI-gap indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot for Type 1-PDCCH common search space configured by dedicated RRC signaling, for a Type 3-PDCCH common search space, or for a UE-specific search space with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively. withDCI-gap indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation of two OFDM symbols for 15 kHz, four OFDM symbols for 30 kHz, seven OFDM symbols for 60 kHz with NCP, and 140FDM symbols for 120kHz between two consecutive transmissions of PDCCH scrambled with C-RNTI, MCS-C-RNTI, or CS-RNTI for Type 1-PDCCH common search space configured by dedicated RRC signaling, for a Type 3-PDCCH common search space, or for a UE-specific search space, with the capability of supporting at least 44, 36, 22, and 20 blind decodes in a slot for 15 kHz, 30 kHz, 60kHz, and 120 kHz subcarrier spacing values respectively.	FS	No	N/A	N/A

pdcch-MonitoringAnyOccasionsWithSpanGap Indicates whether the UE supports PDCCH search space monitoring occasions in any symbol of the slot with minimum time separation between two consecutive transmissions of PDCCH with span up to two OFDM symbols for two OFDM symbols or span up to three OFDM symbols for four and seven OFDM symbols. Value set1 indicates the supported value set (X,Y) is (7,3), value set2 indicates the supported value set (X,Y) is (4,3) and (7,3) and value set 3 indicates the supported value set (X,Y) is (2,2), (4,3) and (7,3).	FS	No	N/A	N/A
pdsch-ProcessingType1-DifferentTB-PerSlot Defines whether the UE capable of processing time capability 1 supports reception of up to two, four or seven unicast PDSCHs for several transport blocks with PDSCH scrambled using C-RNTI, TC-RNTI, or CS-RNTI in one serving cell within the same slot per CC that are multiplexed in time domain only.	FS	No	N/A	N/A
 Note PDSCH(s) for Msg.4 is included. pdsch-ProcessingType2 Indicates whether the UE supports PDSCH processing capability 2. The UE supports it only if all serving cells are self-scheduled and if all serving cells in one band on which the network configured processingType2 use the same subcarrier spacing. This capability signalling comprises the following parameters for each subcarrier spacing supported by the UE. fallback indicates whether the UE supports PDSCH processing capability 2 when the number of configured carriers is larger than numberOfCarriers for a reported value of differentTB-PerSlot. If fallback = 'sc', UE supports capability 2 processing time on lowest cell index among the configured carriers in the band where the value is reported, if fallback = 'cap1-only', UE supports only capability 1, in the band where the value is reported; differentTB-PerSlot indicates whether the UE supports processing type 2 for 1, 2, 4 and/or 7 unicast PDSCHs for different transport blocks per slot per CC; and if so, it indicates up to which number of CA serving cells the UE supports that number of unicast PDSCHs for different TBs. The UE shall include at least one of numberOfCarriers for 1, 2, 4 or 7 transport blocks per slot in this field if pdsch-ProcessingType2 is indicated. 	FS	No	N/A	FR1 only
 pdsch-ProcessingType2-Limited Indicates whether the UE supports PDSCH processing capability 2 with scheduling limitation for SCS 30kHz. This capability signalling comprises the following parameter. differentTB-PerSlot-SCS-30kHz indicates the number of different TBs per slot. The UE supports this limited processing capability 2 only if: One carrier is configured in the band, independent of the number of carriers configured in the other bands; The maximum bandwidth of PDSCH is 136 PRBs; N1 based on Table 5.3-2 of TS 38.214 [12] for SCS 30 kHz. 	FS	No	N/A	FR1 only
pdsch-SeparationWithGap Indicates whether the UE supports separation of two unicast PDSCHs with a gap, applicable to Sub-carrier spacings of 30 kHz and 60 kHz only. For any two consecutive slots n and n+1, if there are more than 1 unicast PDSCH in either slot, the minimum time separation between starting time of any two unicast PDSCHs within the duration of these slots is 4 OFDM symbols for 30kHz and 7 OFDM symbols for 60kHz.	FS	No	N/A	N/A
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	N/A	N/A
scellWithoutSSB Defines whether the UE supports configuration of SCell that does not transmit SS/PBCH block. This is conditionally mandatory with capability signalling for intraband CA but not supported for inter-band CA.	FS	CY	N/A	N/A
searchSpaceSharingCA-DL Defines whether the UE supports DL PDCCH search space sharing for carrier aggregation operation.	FS	No	N/A	N/A

SupportedSRS-Resources	FS	FD	N/A	N/A
- maxNumberPeriodicSRS-PerBWP-PerSlot indicates supported maximum number of periodic SRS resources per slot in the BWP				
 maxNumberSemiPersistentSRS-PerBWP indicate supported maximum number of semi-persistent SRS resources that can be configured for the UE per each BWP 				
 maxNumberSemiPersistentSRS-PerBWP-PerSlot indicates supported maximum number of semi-persistent SRS resources per slot in the BWP 				
 maxNumberSRS-Ports-PerResource indicates supported maximum number of SRS antenna port per each SRS resource 				
If the UE indicates the support of srs-CarrierSwitch for this band and this field is absent, the UE suports one periodic, one aperiodic, no semi-persistent SRS resources per BWP per slot and one SRS antenna port per SRS resource.				
timeDurationForQCL Defines minimum number of OFDM symbols required by the UE to perform PDCCH reception and applying spatial QCL information received in DCI for PDSCH processing as described in TS 38.214 [12] clause 5.1.5. UE shall indicate one value of the minimum number of OFDM symbols per each subcarrier spacing of 60kHz and 120kHz.	FS	Yes	N/A	FR2 only
twoFL-DMRS-TwoAdditionalDMRS-DL Defines whether the UE supports DM-RS pattern for DL transmission with 2 symbols front-loaded DM-RS with one additional 2 symbols DM-RS.	FS	No	N/A	N/A
type1-3-CSS Defines whether the UE is able to receive PDCCH in FR2 in a Type1-PDCCH common search space configured by dedicated RRC signaling, in a Type3-PDCCH common search space or a UE-specific search space if those are associated with a CORESET with a duration of 3 symbols.	FS	Yes	N/A	FR2 only
ue-SpecificUL-DL-Assignment Indicates whether the UE supports dynamic determination of UL and DL link direction and slot format based on Layer 1 scheduling DCI and higher layer configured parameter UL-DL-configuration-dedicated as specified in TS 38.213 [11].	FS	No	N/A	N/A

4.2.7.6 FeatureSetDownlinkPerCC parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
channelBW-90mhz	FSPC	No	N/A	FR1
Indicates whether the UE supports the channel bandwidth of 90 MHz. maxNumberMIMO-LayersPDSCH Defines the maximum number of spatial multiplexing layer(s) supported by the UE for DL reception. For single CC standalone NR, it is mandatory with capability signaling to support at least 4 MIMO layers in the bands where 4Rx is specified as mandatory for the given UE and at least 2 MIMO layers in FR2. If absent, the UE does not support MIMO on this carrier.	FSPC	CY	N/A	only N/A
supportedBandwidthDL Indicates maximum DL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS 38.101-1 [2] for FR1 and Table 5.3.5-1 in TS 38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 Table 5.3.5-1 for each band shall be mandatory with a single CC unless indicated optional. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3]. NOTE: To determine whether the UE supports a channel bandwidth of 90 MHz, the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-DL, the supportedBandwidthCombinationSet and supportedBandwidthDL.	FSPC	CY	N/A	N/A
 supportedModulationOrderDL Indicates the maximum supported modulation order to be applied for downlink in the carrier in the max data rate calculation as defined in 4.1.2. If included, the network may use a modulation order on this serving cell which is higher than the value indicated in this field as long as UE supports the modulation of higher value for downlink. If not included: for FR1, the network uses the modulation order signalled in pdsch-256QAM-FR1. for FR2, the network uses the modulation order signalled per band i.e. pdsch-256QAM-FR2 if signalled. If not signalled in a given band, the network shall use the modulation order 64QAM. In all the cases, it shall be ensured that the data rate does not exceed the max data rate (DataRate) and max data rate per CC (DataRateCC) according to TS 38.214 [12]. 	FSPC	No	N/A	N/A
supportedSubCarrierSpacingDL Defines the supported sub-carrier spacing for DL by the UE, as defined in clause 4.2-1 of TS 38.211 [6], indicating the UE supports simultaneous reception with same or different numerologies in CA. Support of simultaneous reception with same numerology for intra-band NR CA including both contiguous and non-contiguous is mandatory with capability in both FR1 and FR2. Support of simultaneous reception with two different numerologies between FR1 band(s) and FR2 band(s) in DL is mandatory with capability if UE supports inter-band NR CA including both FR1 band(s) and FR2 band(s). Optional for other cases. Support of simultaneous reception of with different numerologies in CA for other cases is optional.	FSPC	CY	N/A	N/A

4.2.7.7 *FeatureSetUplink* parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
scalingFactor Indicates the scaling factor to be applied to the band in the max data rate calculation as defined in 4.1.2. Value f0p4 indicates the scaling factor 0.4, f0p75 indicates 0.75, and so on. If absent, the scaling factor 1 is applied to the band in the max data rate calculation.	FS	No	N/A	N/A
crossCarrierScheduling-OtherSCS Indicates whether the UE supports cross carrier scheduling for the different numerologies with carrier indicator field (CIF) in UL carrier aggregation where numerologies for the scheduling cell and scheduled cell are different. The UE shall set this field to the same value as crossCarrierScheduling-OtherSCS in the associated FeatureSetDownlink (if present). NOTE: Cross-carrier scheduling with different numerologies is not supported in this release of specification.	FS	No	N/A	N/A
dynamicSwitchSUL Indicates whether the UE supports supplemental uplink with dynamic switch (DCI based selection of PUSCH carrier).	FS	No	N/A	N/A
featureSetListPerUplinkCC Indicates which features the UE supports on the individual UL carriers of the feature set (and hence of a band entry that refer to the feature set) by FeatureSetUplinkPerCC-Id. The UE shall hence include as many FeatureSetUplinkPerCC-Id in this list as the number of carriers it supports according to the ca-bandwidthClassUL. The order of the elements in this list is not relevant, i.e., the network may configure any of the carriers in accordance with any of the FeatureSetUplinkPerCC-Id in this list. A fallback per CC feature set resulting from the reported feature set per UL CC is not signalled but the UE shall support it.	FS	N/A	N/A	N/A
intraBandFreqSeparationUL Indicates UL frequency separation class the UE supports, which indicates a maximum frequency separation between lower edge of lowest CC and upper edge of highest CC in a frequency band, for intra-band non-contiguous CA. The UE sets the same value in the FeatureSetUplink of each band entry within a band. The values c1, c2 and c3 corresponds to the values defined in TS 38.101-2 [3]. It is mandatory to report for UE which supports UL non-contiguous CA in FR2.	FS	CY	N/A	FR2 only
pa-PhaseDiscontinuityImpacts Indicates incapability motivated by impacts of PA phase discontinuity with overlapping transmissions with non-aligned starting or ending times or hop boundaries across carriers for intra-band (NG)EN-DC/NE-DC, intra-band CA and FDM based ULSUP.	FS	No	N/A	N/A
pusch-ProcessingType1-DifferentTB-PerSlot Indicates whether the UE capable of processing time capability 1 supports transmission of up to two, four or seven unicast PUSCHs for several transport blocks in one serving cell within the same slot per CC that are multiplexed in time domain only.	FS	No	N/A	N/A
 pusch-ProcessingType2 Indicates whether the UE supports PUSCH processing capability 2. The UE supports it only if all serving cells are self-scheduled and if all serving cells in one band on which the network configured processingType2 use the same subcarrier spacing. This capability signalling comprises the following parameters for each subcarrier spacing supported by the UE. fallback indicates whether the UE supports PUSCH processing capability 2 when the number of configured carriers is larger than numberOfCarriers for a reported value of differentTB-PerSlot. If fallback = 'sc', UE supports capability 2 processing time on lowest cell index among the configured carriers in the band where the value is reported, if fallback = 'cap1-only', UE supports only capability 1, in the band where the value is reported; differentTB-PerSlot indicates whether the UE supports processing type 2 for 1, 2, 4 and/or 7 unicast PUSCHs for different transport blocks per slot per CC; and if so, it indicates up to which number of CA serving cells the UE supports that number of unicast PUSCHs for different TBs. The UE shall include at least one of numberOfCarriers for 1, 2, 4 or 7 transport blocks per slot in this field if pusch-ProcessingType2 is indicated. 	FS	No	N/A	FR1 only

pusch-SeparationWithGap	FS	No	N/A	N/A
Indicates whether the UE supports separation of two unicast PUSCHs with a gap,				
applicable to Sub-carrier spacings of 15 kHz, 30 kHz and 60 kHz only. For any two				
consecutive slots n and n+1, if there are more than 1 unicast PUSCH in either slot,				
the minimum time separation between starting time of any two unicast PUSCHs				
within the duration of these slots is 2 OFDM symbols for 15kHz, 4 OFDM symbols				
for 30kHz and 7 OFDM symbols for 60kHz.				
searchSpaceSharingCA-UL	FS	No	N/A	N/A
Defines whether the UE supports UL PDCCH search space sharing for carrier				
aggregation operation.				
simultaneousTxSUL-NonSUL	FS	No	N/A	N//
Indicates whether the UE supports simultaneous transmission of SRS on an				
SUL/non-SUL carrier and PUSCH/PUCCH/SRS on the other UL carrier in the same				
cell.				
supportedSRS-Resources	FS	FD	N/A	N/A
Defines support of SRS resources. The capability signalling comprising indication of:				
- maxNumberAperiodicSRS-PerBWP indicates supported maximum number				
of aperiodic SRS resources that can be configured for the UE per each BWP				
- maxNumberAperiodicSRS-PerBWP-PerSlot indicates supported maximum				
number of aperiodic SRS resources per slot in the BWP				
- maxNumberPeriodicSRS-PerBWP indicates supported maximum number of				
periodic SRS resources per BWP				
- maxNumberPeriodicSRS-PerBWP-PerSlot indicates supported maximum				
number of periodic SRS resources per slot in the BWP				
- maxNumberSemiPersistentSRS-PerBWP indicate supported maximum				
number of semi-persistent SRS resources that can be configured for the UE per each BWP				
many Alicenta and Committee and COC Devictory. Devictory in directory accounts of				
 maxNumberSemiPersistentSRS-PerBWP-PerSlot indicates supported maximum number of semi-persistent SRS resources per slot in the BWP 				
- maxNumberSRS-Ports-PerResource indicates supported maximum number				
of SRS antenna port per each SRS resource				
f this field is not included, the UE suports one periodic, one aperiodic, no semi-				
persistent SRS resources per BWP and one periodic, one aperiodic, no semi-				
persistent SRS resources per BWP per slot and one SRS antenna port per SRS				
esource.				
woPUCCH-Group	FS	No	N/A	N/
ndicates whether two PUCCH group in CA with a same numerology across CCs for				
lata and control channel [at a given time] is supported by the UE. For NR CA, two				
PUCCH group is supported with the same numerology across NR carriers for data				
and control channel at a given time. For (NG)EN-DC/NE-DC, two PUCCH group is				
supported with the same numerology across NR carriers for data and control				
channel at a given time, wherein an NR PUCCH group is configured in FR1 and another NR PUCCH group is configured in FR2.				
Il-MCS-TableAlt-DynamicIndication	FS	No	N/A	N/
ndicates whether the UE supports dynamic indication of MCS table using MCS-C-	'3	'10	1 11/77	1 1/
RNII for PUSCH				
	FS	Nο	N/A	N/
RNTI for PUSCH. zeroSlotOffsetAperiodicSRS Indicates whether the UE supports 0 slot offset between aperiodic SRS triggering	FS	No	N/A	N/

4.2.7.8 FeatureSetUplinkPerCC parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
channelBW-90mhz	FSPC	No	N/A	FR1
Indicates whether the UE supports the channel bandwidth of 90 MHz. maxNumberMIMO-LayersCB-PUSCH Defines supported maximum number of MIMO layers at the UE for PUSCH transmission with codebook precoding. UE indicating support of this feature shall also indicate support of PUSCH codebook coherency subset. This feature is not supported for SUL.	FSPC	No	N/A	only N/A
maxNumberMIMO-LayersNonCB-PUSCH Defines supported maximum number of MIMO layers at the UE for PUSCH transmission using non-codebook precoding. This feature is not supported for SUL. UE supporting non-codebook based PUSCH transmission shall indicate support of maxNumberMIMO-LayersNonCB-PUSCH, maxNumberSRS-ResourcePerSet and maxNumberSimultaneousSRS-ResourceTx together.	FSPC	No	N/A	N/A
maxNumberSimultaneousSRS-ResourceTx Defines the maximum number of simultaneous transmitted SRS resources at one symbol for non-codebook based transmission to the UE. This feature is not supported for SUL.	FSPC	No	N/A	N/A
maxNumberSRS-ResourcePerSet Defines the maximum number of SRS resources per SRS resource set configured for codebook or non-codebook based transmission to the UE. This feature is not supported for SUL.	FSPC	No	N/A	N/A
supportedBandwidthUL Indicates maximum UL channel bandwidth supported for a given SCS that UE supports within a single CC, which is defined in Table 5.3.5-1 in TS38.101-1 [2] for FR1 and Table 5.3.5-1 in TS 38.101-2 [3] for FR2. For FR1, all the bandwidths listed in TS38.101-1 Table 5.3.5-1 for each band shall be mandatory with a single CC unless indicated optional. For FR2, the set of mandatory CBW is 50, 100, 200 MHz. When this field is included in a band combination with a single band entry and a single CC entry (i.e. non-CA band combination), the UE shall indicate the maximum channel bandwidth for the band according to TS 38.101-1 [2] and TS 38.101-2 [3]. NOTE: To determine whether the UE supports a channel bandwidth of 90 MHz the network may ignore this capability for and validate instead the channelBW-90mhz and the supportedBandwidthCombinationSet. For serving cells with other channel bandwidths the network validates the channelBWs-UL, the supportedBandwidthCombinationSet and supportedBandwidthUL. supportedModulationOrderUL Indicates the maximum supported modulation order to be applied for uplink in the	FSPC	CY	N/A	N/A
carrier in the max data rate calculation as defined in 4.1.2. If included, the network may use a modulation order on this serving cell which is higher than the value indicated in this field as long as UE supports the modulation of higher value for uplink. If not included, - for FR1 and FR2, the network uses the modulation order signalled per band i.e. pusch-256QAM if signalled. If not signalled in a given band, the network shall use the modulation order 64QAM. In all the cases, it shall be ensured that the data rate does not exceed the max data rate (DataRate) and max data rate per CC (DataRateCC) according to TS 38.214 [12].				
supportedSubCarrierSpacingUL Defines the supported sub-carrier spacing for UL by the UE, as defined in 4.2-1 of TS 38.211 [6], indicating the UE supports simultaneous transmission with same or different numerologies in CA, or indicating the UE supports different numerologies on NR UL and SUL within one cell. Support of simultaneous transmissions with same numerology for intra-band NR CA including both contiguous and noncontiguous is mandatory with capability in both FR1 and FR2. Support of simultaneous transmission with two different numerologies between FR1 band(s) and FR2 band(s) in UL is mandatory with capability if UE supports inter-band NR CA including both FR1 band(s) and FR2 band(s). Support of simultaneous transmission with different numerologies in CA for other cases is optional.	FSPC	CY	N/A	N/A

4.2.7.9 *MRDC-Parameters*

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
asyncIntraBandENDC Indicates whether the UE supports asynchronous FDD-FDD intra-band (NG)EN-DC with MRTD and MTTD as specified in clause 7.5 and 7.6 of TS 38.133 [5]. If asynchronous FDD-FDD intra-band (NG)EN-DC is not supported, the UE supports only synchronous FDD-FDD intra-band (NG)EN-DC.	ВС	No	FDD only	FR1 only
dualPA-Architecture For an intra-band band combination, this field indicates the support of dual PAs. If absent in an intra-band band combination, the UE supports single PA for all the ULs in the intra-band band combination. For other band combinations, this field is not applicable.	BC	No	N/A	N/A
dynamicPowerSharingENDC Indicates whether the UE supports dynamic (NG)EN-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability the UE supports the dynamic power sharing behaviour as specified in clause 7 of TS 38.213 [11].	ВС	Yes	N/A	FR1 only
dynamicPowerSharingNEDC Indicates whether the UE supports dynamic NE-DC power sharing between NR FR1 carriers and the LTE carriers. If the UE supports this capability, the UE supports the dynamic power sharing behavior as specified in clause 7 of TS 38.213 [11].	ВС	Yes	N/A	FR1 only
intraBandENDC-Support Indicates whether the UE supports intra-band (NG)EN-DC with only non-contiguous spectrum, or with both contiguous and non-contiguous spectrum for the (NG)EN-DC combination as specified in TS 38.101-3 [4]. If the UE does not include this field for an intra-band (NG)EN-DC combination the UE only supports the contiguous spectrum for the intra-band (NG)EN-DC combination.	ВС	No	N/A	N/A
interBandContiguousMRDC Indicates for an inter-band (NG)EN-DC/NE-DC combination, where the frequency range of the E-UTRA band is a subset of the frequency range of the NR band (as specified in Table 5.5B.4.1-1 of TS 38.101-3 [4]), that the UE supports intra-band contiguous (NG)EN-DC/NE-DC requirements (see TS 38.101-3 [4]). If the field is absent for such an inter-band (NG)EN-DC/NE-DC combination, the UE supports intra-band non-contiguous (NG)EN-DC/NE-DC requirements.	BC	CY	N/A	N/A
simultaneousRxTxInterBandENDC Indicates whether the UE supports simultaneous transmission and reception in TDD-TDD and TDD-FDD inter-band (NG)EN-DC/NE-DC. It is mandatory for certain TDD-FDD and TDD-TDD band combinations defined in TS 38.101-3 [4].	ВС	CY	N/A	N/A
singleUL-Transmission Indicates that the UE does not support simultaneous UL transmissions as defined in TS 38.101-3 [4]. The UE may only include this field for certain band combinations defined in TS 38.101-3 [4]. If included for a particular band combination, the field applies to all fallback band combinations of this band combination that are defined in TS 38.101-3 [4] as being allowed to include this field and does not apply to any other fallback band combinations defined in TS 38.101-3 [4].	ВС	No	N/A	N/A
spCellPlacement Indicates whether the UE supports a SpCell on FR1-FDD, FR1-TDD and/or FR2-TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to SCG of (NG)EN-DC and MCG of NE-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations.	UE	No	N/A	N/A
tdm-Pattern Indicates whether the UE supports the tdm-PatternConfig for single UL-transmission associated functionality, as specified in TS 36.331 [17]. Support is conditionally mandatory in (NG)EN-DC for UEs that do not support dynamicPowerSharingENDC and for UEs that indicate single UL transmission for any (NG)EN-DC BC. Support is conditionally mandatory in NE-DC for UEs that do not support dynamicPowerSharingNEDC and for UEs that indicate single UL transmission for any NE-DC BC. The feature is optional otherwise.	ВС	CY	N/A	FR1 only
ul-SharingEUTRA-NR Indicates whether the UE supports (NG)EN-DC/NE-DC with EUTRA-NR coexistence in UL sharing via TDM only, FDM only, or both TDM and FDM from UE perspective as specified in TS 38.101-3 [4].	ВС	No	N/A	FR1 only

ul-SwitchingTimeEUTRA-NR	BC	CY	N/A	FR1
Indicates support of switching type between LTE UL and NR UL for (NG)EN-				only
DC/NE-DC with LTE-NR coexistence in UL sharing from UE perspective as defined				
in clause 6.3B of TS 38.101-3 [4]. It is mandatory to report switching time type 1 or				
type 2 if UE reports <i>ul-SharingEUTRA-NR</i> is <i>tdm</i> or <i>both</i> .				
ul-TimingAlignmentEUTRA-NR	BC	No	N/A	N/A
Indicates whether to apply the same UL timing between NR and LTE for dynamic				
power sharing capable UE operating in a synchronous intra-band contiguous				
(NG)EN-DC. If this field is absent, UE shall be capable of handling a timing				
difference up to applicable MTTD requirements when operating in a synchronous				
intra-band contiguous (NG)EN-DC network, as specified in TS 38.133 [5]. If this				
capability is included in an inter-band (NG)EN-DC BC with an intra-band (NG)EN-				
DC BC part, this capability is used to indicate the restriction to the intra-band				
(NG)EN-DC BC part.				

4.2.7.10 Phy-Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
absoluteTPC-Command Indicates whether the UE supports absolute TPC command mode.	UE	No	No	Yes
almostContiguousCP-OFDM-UL Indicates whether the UE supports almost contiguous UL CP-OFDM transmissions as defined in clause 6.2 of TS 38.101-1 [2].	UE	No	No	Yes
bwp-SwitchingDelay Defines whether the UE supports DCI and timer based active BWP switching delay type1 or type2 specified in clause 8.6.2 of TS 38.133 [5]. It is mandatory to report type 1 or type 2.	UE	Yes	No	No
cbg-FlushIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG flushing out information (CBGFI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-DL Indicates whether the UE supports CBG-based (re)transmission for DL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
cbg-TransIndication-UL Indicates whether the UE supports CBG-based (re)transmission for UL using CBG transmission information (CBGTI) as specified in TS 38.214 [12].	UE	No	No	No
configuredUL-GrantType1 Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
configuredUL-GrantType2 Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	UE	No	No	No
cqi-TableAlt Indicates whether UE supports the CQI table with target BLER of 10^-5.	UE	No	No	Yes
csi-ReportFramework See csi-ReportFramework in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in MIMO-ParametersPerBand.	UE	Yes	No	N/A
csi-ReportWithoutCQI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/i1' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
csi-ReportWithoutPMI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/CQI' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
csi-RS-CFRA-ForHO Indicates whether the UE can perform reconfiguration with sync using a contention free random access on PRACH resources that are associated with CSI-RS resources of the target cell.	UE	No	No	No
csi-RS-IM-ReceptionForFeedback See csi-RS-IM-ReceptionForFeedback in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in MIMO-ParametersPerBand.	UE	Yes	No	N/A
csi-RS-ProcFrameworkForSRS See csi-RS-ProcFrameworkForSRS in 4.2.7.2. For a band combination comprised of FR1 and FR2 bands, this parameter, if present, limits the corresponding parameter in MIMO-ParametersPerBand.	UE	No	No	N/A
dl-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64QAM MCS table for PDSCH.	UE	No	No	Yes
dl-SchedulingOffset-PDSCH-TypeA Indicates whether the UE supports DL scheduling slot offset (K0) greater than 0 for PDSCH mapping type A.	UE	Yes	Yes	Yes
dl-SchedulingOffset-PDSCH-TypeB Indicates whether the UE supports DL scheduling slot offset (K0) greater than 0 for PDSCH mapping type B.	UE	Yes	Yes	Yes
downlinkSPS Indicates whether the UE supports PDSCH reception based on semi-persistent scheduling.	UE	No	No	No
dynamicBetaOffsetInd-HARQ-ACK-CSI Indicates whether the UE supports indicating beta-offset (UCI repetition factor onto PUSCH) for HARQ-ACK and/or CSI via DCI among the RRC configured beta-offsets.	UE	No	No	No

dynamicHARQ-ACK-Codebook Indicates whether the UE supports HARQ-ACK codebook dynamically constructed	UE	Yes	No	No
by DCI(s). This field shall be set to supported. dynamicHARQ-ACK-CodeB-CBG-Retx-DL	UE	No	Na	No
	UE	INO	No	INO
Indicates whether the UE supports HARQ-ACK codebook size for CBG-based				
(re)transmission based on the DAI-based solution as specified in TS 38.213 [11].		N	N.L.	
dynamicPRB-BundlingDL	UE	No	No	No
Indicates whether UE supports DCI-based indication of the PRG size for PDSCH				
reception.		N 1		
dynamicSFI	UE	No	Yes	Yes
Indicates whether the UE supports monitoring for DCI format 2_0 and determination				
of slot formats via DCI format 2_0.				
dynamicSwitchRA-Type0-1-PDSCH	UE	No	No	No
Indicates whether the UE supports dynamic switching between resource allocation				
Types 0 and 1 for PDSCH as specified in TS 38.212 [10].				
dynamicSwitchRA-Type0-1-PUSCH	UE	No	No	No
Indicates whether the UE supports dynamic switching between resource allocation				
Types 0 and 1 for PUSCH as specified in TS 38.212 [10].				
pucch-F0-2WithoutFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 0 or 2 without				
frequency hopping. When included, the UE does not support PUCCH formats 0 and				
2 without frequency hopping. When not included, the UE supports the PUCCH				
formats 0 and 2 without frequency hopping.				
pucch-F1-3-4WithoutFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 1, 3 or 4		163	140	100
without frequency hopping. When included, the UE does not support PUCCH				
formats 1, 3 and 4 without frequency hopping. When not included, the UE supports				
the PUCCH formats 1, 3 and 4 without frequency hopping.		\\	NI-	NI-
interleavingVRB-ToPRB-PDSCH	UE	Yes	No	No
Indicates whether the UE supports receiving PDSCH with interleaved VRB-to-PRB				
mapping as specified in TS 38.211 [6].				
interSlotFreqHopping-PUSCH	UE	No	No	No
Indicates whether the UE supports inter-slot frequency hopping for PUSCH				
transmissions.				
intraSlotFreqHopping-PUSCH	UE	Yes	No	Yes
Indicates whether the UE supports intra-slot frequency hopping for PUSCH				
transmission, except for PUSCH scheduled by PDCCH in the Type1-PDCCH				
common search space before RRC connection establishment.				
maxLayersMIMO-Indication	UE	Yes	No	No
Indicates whether the UE supports the network configuration of maxMIMO-Layers				
as specified in TS 38.331 [9].				
maxNumberSearchSpaces	UE	No	No	No
Indicates whether the UE supports up to 10 search spaces in an SCell per BWP.				
multipleCORESET	UE	CY	No	Yes
Indicates whether the UE supports configuration of more than one PDCCH	0L	01	140	100
CORESET per BWP in addition to the CORESET with CORESET-ID 0 in the BWP.				
It is mandatory with capability signaling for FR2 and optional for FR1.		\\	NI-	V
mux-HARQ-ACK-PUSCH-DiffSymbol	UE	Yes	No	Yes
Indicates whether the UE supports HARQ-ACK piggyback on a PUSCH with/without				
aperiodic CSI once per slot when the starting OFDM symbol of the PUSCH is				
different from the starting OFDM symbols of the PUCCH resource that HARQ-ACK				
would have been transmitted on.				
mux-MultipleGroupCtrlCH-Overlap	UE	No	No	Yes
Indicates whether the UE supports more than one group of overlapping PUCCHs				
and PUSCHs per slot per PUCCH cell group for control multiplexing.				
mux-SR-HARQ-ACK-CSI-PUCCH-MultiPerSlot	UE	No	No	Yes
Indicates whether the UE supports multiplexing SR, HARQ-ACK and CSI on a			-	
PUCCH or piggybacking on a PUSCH more than once per slot when SR, HARQ-				
	1			
ACK and CSI are supposed to be sent with the same or different starting symbol in	I			

mux-SR-HARQ-ACK-CSI-PUCCH-OncePerSlot sameSymbol indicates the UE supports multiplexing SR, HARQ-ACK and CSI on a	UE	FD	No	Yes
PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-ACK and CSI				
are supposed to be sent with the same starting symbols on the PUCCH resources				
in a slot. <i>diffSymbol</i> indicates the UE supports multiplexing SR, HARQ-ACK and				
CSI on a PUCCH or piggybacking on a PUSCH once per slot, when SR, HARQ-				
ACK and CSI are supposed to be sent with the different starting symbols in a slot.				
The UE is mandated to support the multiplexing and piggybacking features				
indicated by sameSymbol while the UE is optional to support the multiplexing and				
piggybacking features indicated by <i>diffSymbol</i> .				
If the UE indicates sameSymbol in this field and does not support mux-HARQ-ACK-				
PUSCH-DiffSymbol, the UE supports HARQ-ACK/CSI piggyback on PUSCH once				
per slot, when the starting OFDM symbol of the PUSCH is the same as the starting				
OFDM symbols of the PUCCH resource(s) that would have been transmitted on.				
If the UE indicates sameSymbol in this field and supports mux-HARQ-ACK-PUSCH-				
DiffSymbol, the UE supports HARQ-ACK/CSI piggyback on PUSCH once per slot				
for which case the starting OFDM symbol of the PUSCH is the different from the				
starting OFDM symbols of the PUCCH resource(s) that would have been				
transmitted on.				
mux-SR-HARQ-ACK-PUCCH	UE	No	No	Yes
Indicates whether the UE supports multiplexing SR and HARQ-ACK on a PUCCH	J_	'10	. 10	103
or piggybacking on a PUSCH once per slot, when SR and HARQ-ACK are				
supposed to be sent with the different starting symbols in a slot.				
nzp-CSI-RS-IntefMgmt	UE	No	No	No
Indicates whether the UE supports interference measurements using NZP CSI-RS.	OL.	140	INO	110
oneFL-DMRS-ThreeAdditionalDMRS-UL	UE	No	No	Yes
Defines whether the UE supports DM-RS pattern for UL transmission with 1 symbol	OL	INO	NO	163
front-loaded DM-RS with three additional DM-RS symbols.				
oneFL-DMRS-TwoAdditionalDMRS-UL	UE	Yes	No	Yes
Defines support of DM-RS pattern for UL transmission with 1 symbol front-loaded	UE	165	INO	165
DM-RS with 2 additional DM-RS symbols and more than 1 antenna ports.				
onePortsPTRS	UE	CY	No	Yes
Defines whether UE supports PT-RS with 1 antenna port in DL reception and/or UL	UE	01	INO	165
transmission. It is mandatory with UE capability signalling for FR2 and optional for				
FR1. The left most in the bitmap corresponds to DL reception and the right most bit				
in the bitmap corresponds to UL transmission.				
onePUCCH-LongAndShortFormat	UE	No	No	Yes
Indicates whether the UE supports transmission of one long PUCCH format and	OL	INO	INO	165
one short PUCCH format in TDM in the same slot.				
pCell-FR2	UE	Yes	No	FR2
	UE	165	INO	
Indicates whether the UE supports PCell operation on FR2.	115	No	No	only
pdcch-MonitoringSingleOccasion	UE	No	No	FR1
Indicates whether the UE supports receiving PDCCH scrambled with C-RNTI or CS-				only
RNTI in a search space configured to be monitored within a single span of any three				
contiguous OFDM symbols in a slot with the capability of supporting at least 44				
blind decodes in a slot for 15 kHz subcarrier spacing.	HE	No	No	Nic
pdcch-BlindDetectionCA	UE	No	No	No
Indicates PDCCH blind decoding capabilities supported by the UE for CA with more				
than 4 CCs as specified in TS 38.213 [11]. The field value is from 4 to 16.				
NOTE: ED1 ED2 differentiation is not allowed in this release, although the				
NOTE: FR1-FR2 differentiation is not allowed in this release, although the				
capability signalling is supported for FR1-FR2 differentiation.	1.15	N-	NI~	Vaa
pdcch-BlindDetectionMCG-UE	UE	No	No	Yes
Indicates PDCCH blind decoding capabilities supported for MCG when in NR DC.				
The field value is from 1 to 15. The UE sets the value in accordance with the				
constraints specified in TS 38.213 [11].				
Additionally, if the UE does not report <i>pdcch-BlindDetectionCA</i> , and if X is the				
maximum number of CCs supported by the UE across all NR-DC band				
combinations then there is at least one parameter pair (X1, X2) such that X1 + X2 =				
X and the UE supports at least one NR-DC band combination with X1 CCs in MCG				
and X2 CCs in SCG and for which X1 <= pdcch-BlindDetectionMCG-UE and X2 <=				
pdcch-BlindDetectionSCG-UE.				

		1		
pdcch-BlindDetectionSCG-UE Indicates PDCCH blind decoding capabilities supported for SCG when in NR DC. The field value is from 1 to 15. The UE sets the value in accordance with the constraints specified in TS 38.213 [11].	UE	No	No	Yes
Additionally, if the UE does not report <i>pdcch-BlindDetectionCA</i> , and if X is the maximum number of CCs supported by the UE across all NR-DC band				
combinations then there is at least one parameter pair (X1, X2) such that X1 + X2 = X and the UE supports at least one NR-DC band combination with X1 CCs in MCG and X2 CCs in SCG and for which X1 <= pdcch-BlindDetectionMCG-UE and X2 <=				
pdcch-BlindDetectionSCG-UE.		.,		
pdsch-256QAM-FR1	UE	Yes	No	FR1
Indicates whether the UE supports 256QAM modulation scheme for PDSCH for FR1 as defined in 7.3.1.2 of TS 38.211 [6].				only
<pre>pdsch-MappingTypeA Indicates whether the UE supports receiving PDSCH using PDSCH mapping type A</pre>	UE	Yes	No	No
with less than seven symbols. This field shall be set to supported.				
pdsch-MappingTypeB Indicates whether the UE supports receiving PDSCH using PDSCH mapping type	UE	Yes	No	No
B.	UE	No	No	No
pdsch-RepetitionMultiSlots Indicates whether the UE supports receiving PDSCH scheduled by DCI format 1_1	UE	No	INO	No
when configured with higher layer parameter <i>pdsch-AggregationFactor</i> > 1, as defined in 5.1.2.1 of TS 38.214 [12].				
pdsch-RE-MappingFR1-PerSymbol/pdsch-RE-MappingFR1-PerSlot	UE	Yes	No	FR1
Indicates the maximum number of supported PDSCH Resource Element (RE)	OL	165	NO	only
mapping patterns for FR1, each described as a resource (including NZP/ZP CSI-				Offiny
RS, CRS, CORESET and SSB) or bitmap. The number of patterns coinciding in a				
symbol in a CC and in a slot in a CC are limited by the respective capability				
parameters. Value n10 means 10 RE mapping patterns and n16 means 16 RE				
mapping patterns, and so on. The UE shall set the fields pdsch-RE-MappingFR1-				
PerSymbol and pdsch-RE-MappingFR1-PerSlot to at least n10 and n16,				
respectively. In the exceptional case that the UE does not include the fields, the				
network may anyway assume that the UE supports the required minimum values.				
pdsch-RE-MappingFR2-PerSymbol/pdsch-RE-MappingFR2-PerSlot	UE	Yes	No	FR2
Indicates the maximum number of supported PDSCH Resource Element (RE)		163	140	only
mapping patterns for FR2, each described as a resource (including NZP/ZP CSI-				0,
RS, CORESET and SSB) or bitmap. The number of patterns coinciding in a symbol				
in a CC and in a slot in a CC are limited by the respective capability parameters.				
Value n6 means 6 RE mapping patterns and n16 means 16 RE mapping patterns,				
and so on. The UE shall set the fields pdsch-RE-MappingFR2-PerSymbol and				
pdsch-RE-MappingFR2-PerSlot to at least n6 and n16, respectively. In the				
exceptional case that the UE does not include the fields, the network may anyway				
assume that the UE supports the required minimum values.				
precoderGranularityCORESET	UE	No	No	No
Indicates whether the UE supports receiving PDCCH in CORESETs configured with				
CORESET-precoder-granularity equal to the size of the CORESET in the frequency				
domain as specified in TS 38.211 [6].				
pre-EmptIndication-DL	UE	No	No	No
Indicates whether the UE supports interrupted transmission indication for PDSCH reception based on reception of DCI format 2_1 as defined in TS 38.213 [11].				
pucch-F2-WithFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 2 (2 OFDM				
symbols in total) with frequency hopping in a slot. This field shall be set to				
supported.				
pucch-F3-WithFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 3 (4~14 OFDM				
symbols in total) with frequency hopping in a slot. This field shall be set to				
supported.				
pucch-F3-4-HalfPi-BPSK	UE	CY	No	Yes
Indicates whether the UE supports pi/2-BPSK for PUCCH format 3/4 as defined in				
6.3.2.6 of TS 38.211 [6]. It is optional for FR1 and mandatory with capability				
signalling for FR2.				<u></u>
pucch-F4-WithFH	UE	Yes	No	Yes
Indicates whether the UE supports transmission of a PUCCH format 4 (4~14 OFDM				
symbols in total) with frequency hopping in a slot.				

<pre>pusch-RepetitionMultiSlots Indicates whether the UE supports transmitting PUSCH scheduled by DCI format 0_1 when configured with higher layer parameter pusch-AggregationFactor > 1, as defined in clause 6.1.2.1 of TS 38.214 [12].</pre>	UE	Yes	No	No
pucch-Repetition-F1-3-4 Indicates whether the UE supports transmission of a PUCCH format 1 or 3 or 4 over multiple slots with the repetition factor 2, 4 or 8.	UE	Yes	No	No
pusch-HalfPi-BPSK Indicates whether the UE supports pi/2-BPSK modulation scheme for PUSCH as defined in 6.3.1.2 of TS 38.211 [6]. It is optional for FR1 and mandatory with capability signalling for FR2.	UE	CY	No	Yes
pusch-LBRM Indicates whether the UE supports limited buffer rate matching in UL as specified in TS 38.212 [10].	UE	No	No	Yes
ra-Type0-PUSCH Indicates whether the UE supports resource allocation Type 0 for PUSCH as specified in TS 38.214 [12].	UE	No	No	No
rateMatchingCtrlResrcSetDynamic Indicates whether the UE supports dynamic rate matching for DL control resource set.	UE	Yes	No	No
rateMatchingResrcSetDynamic Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs corresponding to resource sets configured with RB-symbol level granularity based on dynamic indication in the scheduling DCI as specified in TS 38.214 [12].	UE	No	No	No
rateMatchingResrcSetSemi-Static Indicates whether the UE supports receiving PDSCH with resource mapping that excludes the REs corresponding to resource sets configured with RB-symbol level granularity following the semi-static configuration as specified in TS 38.214 [12].	UE	Yes	No	No
scs-60kHz Indicates whether the UE supports 60kHz subcarrier spacing for data channel in FR1 as defined in clause 4.2-1 of TS 38.211 [6].	UE	No	No	FR1 only
semiOpenLoopCSI Indicates whether UE supports CSI reporting with report quantity set to 'CRI/RI/i1/CQI' as defined in clause 5.2.1.4 of TS 38.214 [12].	UE	No	No	Yes
semiStaticHARQ-ACK-Codebook Indicates whether the UE supports HARQ-ACK codebook constructed by semistatic configuration.	UE	Yes	No	No
spatialBundlingHARQ-ACK Indicates whether the UE supports spatial bundling of HARQ-ACK bits carried on PUCCH or PUSCH per PUCCH group. With spatial bundling, two HARQ-ACK bits for a DL MIMO data is bundled into a single bit by logical "AND" operation.	UE	Yes	No	No
spCellPlacement Indicates whether the UE supports a SpCell on FR1-FDD, FR1-TDD and/or FR2-TDD depending on which additional SCells of other frequency range(s) / duplex mode(s) are configured. It is applicable to NR SA and MCG of NR-DC, where UL is configured on more than one of FR1-FDD, FR1-TDD and FR2-TDD in a cell group. If not included, the UE supports SpCell on any serving cell with UL in supported band combinations.	UE	No	No	No
sp-CSI-IM	UE	No	No	Yes
Indicates whether the UE supports semi-persistent CSI-IM. sp-CSI-ReportPUCCH Indicates whether UE supports semi-persistent CSI reporting using PUCCH formats 2, 3 and 4.	UE	No	No	No
sp-CSI-ReportPUSCH Indicates whether UE supports semi-persistent CSI reporting using PUSCH.	UE	No	No	No
sp-CSI-RS Indicates whether the UE supports semi-persistent CSI-RS.	UE	Yes	No	Yes
supportedDMRS-TypeDL Defines supported DM-RS configuration types at the UE for DL reception. Type 1 is mandatory with capability signaling. Type 2 is optional. If this field is not included, Type 1 is supported.	UE	FD	No	Yes
supportedDMRS-TypeUL Defines supported DM-RS configuration types at the UE for UL transmission. Support of both type 1 and type 2 is mandatory with capability signalling. If this field	UE	FD	No	Yes

tdd-MultiDL-UL-SwitchPerSlot Indicates whether the UE supports more than one switch points in a slot for actual	UE	No	TDD only	Yes
DL/UL transmission(s).			Orny	
tpc-PUCCH-RNTI	UE	No	No	Yes
Indicates whether the UE supports group DCI message based on TPC-PUCCH-RNTI for TPC commands for PUCCH.			140	100
tpc-PUSCH-RNTI	UE	No	No	Yes
Indicates whether the UE supports group DCI message based on TPC-PUSCH-RNTI for TPC commands for PUSCH.				
tpc-SRS-RNTI	UE	No	No	Yes
Indicates whether the UE supports group DCI message based on TPC-SRS-RNTI for TPC commands for SRS.				
twoDifferentTPC-Loop-PUCCH	UE	Yes	Yes	Yes
Indicates whether the UE supports two different TPC loops for PUCCH closed loop power control.				
twoDifferentTPC-Loop-PUSCH	UE	Yes	Yes	Yes
Indicates whether the UE supports two different TPC loops for PUSCH closed loop power control.				
twoFL-DMRS	UE	Yes	No	Yes
Defines whether the UE supports DM-RS pattern for DL reception and/or UL transmission with 2 symbols front-loaded DM-RS without additional DM-RS symbols.				
The left most in the bitmap corresponds to DL reception and the right most bit in the				
bitmap corresponds to UL transmission.				
twoFL-DMRS-TwoAdditionalDMRS-UL	UE	Yes	No	Yes
Defines whether the UE supports DM-RS pattern for UL transmission with 2				
symbols front-loaded DM-RS with one additional 2 symbols DM-RS.				
twoPUCCH-AnyOthersInSlot	UE	No	No	Yes
Indicates whether the UE supports transmission of two PUCCH formats in TDM in the same slot, which are not covered by twoPUCCH-F0-2-ConsecSymbols and onePUCCH-LongAndShortFormat.				
twoPUCCH-F0-2-ConsecSymbols	UE	No	Yes	Yes
Indicates whether the UE supports transmission of two PUCCHs of format 0 or 2 in	0_	''	100	100
consecutive symbols in a slot.				
type1-PUSCH-RepetitionMultiSlots	UE	No	No	No
Indicates whether the UE supports Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 1 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.	<u> </u>			
type2-PUSCH-RepetitionMultiSlots	UE	No	No	No
Indicates whether the UE supports Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value equal to 2, 4, or 8 with a single repetition of the transport block within each slot, and redundancy version pattern as indicated by UL-TWG-RV-rep. A UE supporting this feature shall also support Type 2 PUSCH transmissions with configured grant as specified in TS 38.214 [12] with UL-TWG-repK value of one.				
type2-SP-CSI-Feedback-LongPUCCH Indicates whether UE supports Type II CSI semi-persistent CSI reporting over PUCCH Formats 3 and 4 as defined in clause 5.2.4 of TS 38.214 [12].	UE	No	No	No
uci-CodeBlockSegmentation Indicates whether the UE supports segmenting UCI into multiple code blocks	UE	Yes	No	Yes
depending on the payload size.				
1 0 1 0 1 1 1 1 1 0 0 T 1 1 1 1 1 1 1 1	UE	No	No	Yes
ul-64QAM-MCS-TableAlt Indicates whether the UE supports the alternative 64QAM MCS table for PUSCH with and without transform precoding respectively. ul-SchedulingOffset	UE	Yes	Yes	Yes

4.2.7.11 Other PHY parameters

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
appliedFreqBandListFilter Mirrors the FreqBandList that the NW provided in the capability enquiry, if any. The UE filtered the band combinations in the supportedBandCombinationList in accordance with this appliedFreqBandListFilter.	UE	No	No	No
downlinkSetEUTRA Indicates the features that the UE supports on the DL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-DownlinkId. The FeatureSetEUTRA-DownlinkId = 0 means that the UE does not support a EUTRA DL carrier in this band of a band combination.	Band	N/A	N/A	N/A
downlinkSetNR Indicates the features that the UE supports on the DL carriers corresponding to one NR band entry in a band combination by FeatureSetDownlinkId. The FeatureSetDownlinkId = 0 means that the UE does not support a DL carrier in this band of a band combination. A fallback per band feature set resulting from the reported DL feature set that has fallback per CC feature set is not signalled but the UE shall support it.	Band	N/A	N/A	N/A
featureSetCombinations Pools of feature sets that the UE supports on the NR or MR-DC band combinations.	UE	N/A	No	No
featureSets Pools of downlink and uplink features sets as well as a pool of FeatureSetCombination elements. A FeatureSetCombination refers to the IDs of the feature set(s) that the UE supports in that FeatureSetCombination. The BandCombination entries in the BandCombinationList then indicate the ID of the FeatureSetCombination that the UE supports for that band combination.	UE	N/A	No	No
naics-Capability-List Indicates that UE in MR-DC supports NAICS as defined in TS 36.331 [17].	UE	No	No	No
receivedFilters Contains all filters requested with UE-CapabilityRequestFilterNR from version 15.6.0 onwards.	UE	No	No	No
supportedBandCombinationList Defines the supported NR and/or MR-DC band combinations by the UE. For each band combination the UE identifies the associated feature set combination by featureSetCombinations index referring to featureSetCombination. A fallback band combination resulting from the reported CA and MR-DC band combination is not signalled but the UE shall support it. For intra-band non-contiguous CA band combinations, the UE only includes one band combination, and exclude the others for which the presence of uplink CA bandwidth class in the band combination entry is different. One band combination entry can also indicate support of any other possible permutations in the presence of uplink CA bandwidth class where a paired downlink CA bandwidth class is the same or where the number of UL CCs is smaller than the one of paired DL CCs expressed by the CA bandwidth class, as specified in TS 36.306 [15]. For these band combinations not included in the capability, the supported feature set is the same as the ones for the band combination included in the UE capability.	UE	Yes	No	No
supportedBandCombinationListNEDC-Only Defines the supported NE-DC only type of band combinations by the UE.	UE	No	No	No
supportedBandListNR Includes the supported NR bands as defined in TS 38.101-1 [2] and TS 38.101-2 [3].	UE	Yes	No	No
uplinkSetEUTRA Indicates the features that the UE supports on the UL carriers corresponding to one EUTRA band entry in a band combination by FeatureSetEUTRA-UplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination.	Band	N/A	N/A	N/A
uplinkSetNR Indicates the features that the UE supports on the UL carriers corresponding to one NR band entry in a band combination by FeatureSetUplinkId. The FeatureSetUplinkId = 0 means that the UE does not support a UL carrier in this band of a band combination. A fallback per band feature set resulting from the reported UL feature set that has fallback per CC feature set is not signalled but the UE shall support it.	Band	N/A	N/A	N/A

4.2.7.12 NRDC-Parameters

Definitions for parameters	Per	M	FDD- TDD DIFF	FR1- FR2 DIFF
sfn-SyncNRDC Indicates the UE supports NR-DC only with SFN and frame synchronization between PCell and PSCell. If not included by the UE supporting NR-DC, the UE supports NR-DC with slot-level synchronization without condition on SFN and frame synchronization.	UE	No	No	No

4.2.7.13 *CarrierAggregationVariant*

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
fr1fdd-FR1TDD-CA-SpCellOnFR1FDD Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when configured with an FR1 TDD SCell.	UE	No	No	No
fr1fdd-FR1TDD-CA-SpCellOnFR1TDD Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell.	UE	No	No	No
fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR1FDD Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when configured with an FR1 TDD SCell and an FR2 TDD SCell.	UE	No	No	No
fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR1TDD Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell and an FR2 TDD SCell.	UE	No	No	No
fr1fdd-FR1TDD-FR2TDD-CA-SpCellOnFR2TDD Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell and an FR1 TDD SCell.	UE	No	No	No
fr1fdd-FR2TDD-CA-SpCellOnFR1FDD Indicates whether the UE supports an FR1 FDD SpCell (and possibly SCells) when configured with an FR2 TDD SCell.	UE	No	No	No
fr1fdd-FR2TDD-CA-SpCellOnFR2TDD Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when configured with an FR1 FDD SCell.	UE	No	No	No
fr1tdd-FR2TDD-CA-SpCellOnFR1TDD Indicates whether the UE supports an FR1 TDD SpCell (and possibly SCells) when configured with an FR2 TDD SCell.	UE	No	No	No
fr1tdd-FR2TDD-CA-SpCellOnFR2TDD Indicates whether the UE supports an FR2 TDD SpCell (and possibly SCells) when configured with an FR1 TDD SCell.	UE	No	No	No

4.2.8 Void

4.2.9 MeasAndMobParameters

Definitions for parameters	Per M		FDD- TDD DIFF	FR1- FR2 DIFF	
csi-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. This parameter needs FR1 and FR2 differentiation. If the UE supports this feature, the UE needs to report maxNumberResource-CSI-RS-RLM.	UE	Yes	No	Yes	
csi-RSRP-AndRSRQ-MeasWithSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured with an associated SS/PBCH. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report maxNumberCSI-RS-RRM-RS-SINR.	UE	No	No	Yes	
csi-RSRP-AndRSRQ-MeasWithoutSSB Indicates whether the UE can perform CSI-RSRP and CSI-RSRQ measurement as specified in TS 38.215 [13], where CSI-RS resource is configured for a cell that transmits SS/PBCH block and without an associated SS/PBCH block. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report maxNumberCSI-RS-RRM-RS-SINR.	UE	No	No	Yes	
csi-SINR-Meas Indicates whether the UE can perform CSI-SINR measurements based on configured CSI-RS resources as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponding to the frequency range of measured target cell. If the UE supports this feature, the UE needs to report maxNumberCSI-RS-RRM-RS-SINR.	UE	No	No	Yes	
eutra-CGI-Reporting Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC. The consistent DRX configuration implies that MN and SN have the same DRX cycle and on-duration configured by MN completely contains onduration configured by SN. It is mandated if the UE supports EUTRA.	UE	CY	No	No	
eutra-CGI-Reporting-NEDC Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NEDC is configured.	UE	No	No	No	
eutra-CGI-Reporting-NRDC Defines whether the UE supports acquisition of relevant information from a neighbouring E-UTRA cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NR-DC is configured wherein MN and SN have different DRX cycles, or on-duration configured by MN does not contain on-duration configured by SN if the DRX cycles are the same.	UE	No	No	No	
eventA-MeasAndReport Indicates whether the UE supports NR measurements and events A triggered reporting as specified in TS 38.331 [9]. This field only applies to SN configured measurement when (NG)EN-DC is configured. For NR MCG, this feature is mandatory supported.	UE	Yes	Yes	No	
eventB-MeasAndReport Indicates whether the UE supports EUTRA measurement and event B triggered reporting as specified in TS 38.331 [9]. It is mandated if the UE supports EUTRA.	UE	CY	No	No	
handoverLTE-5GC Indicates whether the UE supports HO to EUTRA connected to 5GC. It is mandated if the UE supports EUTRA connected to 5GC.	UE	CY	Yes	Yes	
handoverFDD-TDD Indicates whether the UE supports HO between FDD and TDD. It is mandated if the UE supports both FDD and TDD. This field only applies to NR SA/NR-DC/ NE-DC (e.g. PCell handover). For PSCell change when (NG)EN-DC/NR-DC is configured, this feature is mandatory supported.	UE	Yes	No	No	

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF	
handoverFR1-FR2 Indicates whether the UE supports HO between FR1 and FR2. Support is mandatory for the UE supporting both FR1 and FR2. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover). For PSCell change when (NG)EN-DC/NR-DC is configured, this feature is mandatory supported.	UE	Yes	No	No	
handoverInterF Indicates whether the UE supports inter-frequency HO. It indicates the support for inter-frequency HO from the corresponding duplex mode if this capability is included in fdd-Add-UE-NR-Capabilities or tdd-Add-UE-NR-Capabilities. It indicates the support for inter-frequency HO from the corresponding frequency range if this capability is included in fr1-Add-UE-NR-Capabilities or fr2-Add-UE-NR-Capabilities. This field only applies to NR SA/NR-DC/NE-DC (e.g. PCell handover). For PSCell change when (NG)EN-DC/NR-DC is configured, this feature is mandatory supported.	UE	Yes	Yes	Yes	
handoverLTE-EPC Indicates whether the UE supports HO to EUTRA connected to EPC. It is mandated if the UE supports EUTRA connected to EPC.	UE	CY	Yes	Yes	
independentGapConfig This field indicates whether the UE supports two independent measurement gap configurations for FR1 and FR2 specified in clause 9.1.2 of TS 38.133 [5]. The field also indicates whether the UE supports the FR2 inter-RAT measurement without gaps when (NG)EN-DC is not configured.	UE	No	No	No	
intraAndInterF-MeasAndReport Indicates whether the UE supports NR intra-frequency and inter-frequency measurements and at least periodical reporting. This field only applies to NE-DC and SN configured measurement when (NG)EN-DC is configured. For NR MCG, this feature is mandatory supported.	UE	Yes	Yes	No	
periodicEUTRA-MeasAndReport Indicates whether the UE supports periodic EUTRA measurement and reporting. It is mandated if the UE supports EUTRA.	UE	CY	No	No	
maxNumberCSI-RS-RRM-RS-SINR Defines the maximum number of CSI-RS resources for RRM and RS-SINR measurement across all measurement frequencies per slot. If UE supports any of csi-RSRP-AndRSRQ-MeasWithSSB, csi-RSRP-AndRSRQ-MeasWithoutSSB, and csi-SINR-Meas, UE shall report this capability.	UE	CY	No	No	
maxNumberResource-CSI-RS-RLM Defines the maximum number of CSI-RS resources within a slot per spCell for CSI-RS based RLM. If UE supports any of csi-RS-RLM and ssb-AndCSI-RS-RLM, UE shall report this capability.	UE	CY	No	Yes	
nr-CGI-Reporting Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when (NG)EN-DC and NE-DC are not configured or, when consistent DRX is configured in NR-DC. The consistent DRX configuration implies that MN and SN have the same DRX cycle and on-duration configured by MN completely contains on-duration configured by SN.	UE	Yes	No	No	
nr-CGI-Reporting-ENDC Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the (NG)EN-DC is configured.	UE	Yes	No	No	
nr-CGI-Reporting-NEDC Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NE-DC is configured.	UE	Yes	No	No	
nr-CGI-Reporting-NRDC Defines whether the UE supports acquisition of relevant information from a neighbouring intra-frequency or inter-frequency NR cell by reading the SI of the neighbouring cell and reporting the acquired information to the network as specified in TS 38.331 [9] when the NR-DC is configured wherein MN and SN have different DRX cycles, or on-duration configured by MN does not contain onduration configured by SN if the DRX cycles are the same.	UE	Yes	No	No	

Definitions for parameters	Per	М	FDD- TDD DIFF	FR1- FR2 DIFF
simultaneousRxDataSSB-DiffNumerology Indicates whether the UE supports concurrent intra-frequency measurement on serving cell or neighbouring cell and PDCCH or PDSCH reception from the serving cell with a different numerology as defined in clause 8 and 9 of TS 38.133 [5].	UE	No	No	Yes
Indicates whether the UE supports SFTD measurements between the PCell and a configured PSCell. If this capability is included in UE-MRDC-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in (NG)ENDC. If this capability is included in UE-NR-Capability, it indicates that the UE supports SFTD measurement between PCell and PSCell in NR-DC.	UE	No	Yes	No
sftd-MeasPSCell-NEDC Indicates whether the UE supports SFTD measurement between the NR PCell and a configured E-UTRA PSCell in NE-DC.	UE	No	Yes	No
Indicates whether the SFTD measurement with and without measurement gaps between the EUTRA PCell and the NR cells is supported by the UE which is capable of EN-DC/NGEN-DC when EN-DC/NGEN-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one EN-DC band combination consisting of the set of the current E-UTRA serving frequencies and the NR frequency where SFTD measurement is configured. In UE-NR-Capability, this field is not used, and UE does not include the field.	UE	No	Yes	No
Indicates whether the inter-frequency SFTD measurement with and without measurement gaps between the NR PCell and inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured. The SFTD measurement without gaps can be used when the UE supports at least one DC or CA band combination consisting of the set of the current NR serving frequencies and the NR frequency where SFTD measurement is configured.	UE	No	Yes	No
sftd-MeasNR-Neigh-DRX Indicates whether the inter-frequency SFTD measurement using DRX off period between the NR PCell and the inter-frequency NR neighbour cells is supported by the UE when MR-DC is not configured.	UE	No	Yes	No
ssb-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block as specified in TS 38.213 [11] and TS 38.133 [5]. This field shall be set to supported.	UE	Yes	No	No
ssb-AndCSI-RS-RLM Indicates whether the UE can perform radio link monitoring procedure based on measurement of SS/PBCH block and CSI-RS as specified in TS 38.213 [11] and TS 38.133 [5]. If the UE supports this feature, the UE needs to report maxNumberResource-CSI-RS-RLM.	UE	No	No	No
ss-SINR-Meas Indicates whether the UE can perform SS-SINR measurement as specified in TS 38.215 [13]. If this parameter is indicated for FR1 and FR2 differently, each indication corresponds to the frequency range of measured target cell.	UE	No	No	Yes
supportedGapPattern Indicates measurement gap pattern(s) optionally supported by the UE for NR SA, for NR-DC, for NE-DC and for independent measurement gap configuration on FR2 in (NG)EN-DC. The leading / leftmost bit (bit 0) corresponds to the gap pattern 2, the next bit corresponds to the gap pattern 3, as specified in TS 38.133 [5] and so on. The UE shall set the bits corresponding to the measurement gap pattern 13 and 14 to 1 if the UE is an NR standalone capable UE that supports a band in FR2 or if the UE is an (NG)EN-DC capable UE that supports independentGapConfig and supports a band in FR2.	UE	СҮ	No	No

4.2.10 Inter-RAT parameters

Definitions for parameters		М	FDD- TDD DIFF
mfbi-EUTRA	UE	Yes	No
Indicates whether the UE supports the mechanisms defined for cells broadcasting multi			
band information i.e. comprehending <i>multiBandInfoList</i> defined in TS 36.331 [17].	LIF	Nia	Nia
modifiedMPR-BehaviorEUTRA modifiedMPR-Behavior in 4.3.5.10, TS 36.306 [15].	UE	No	No
multiNS-Pmax-EUTRA	UE	No	No
multiNS-Pmax defined in 4.3.5.16, TS 36.306 [15].			
ne-DC	UE	No	No
Indicates whether the UE supports NE-DC as specified in TS 37.340 [7].			
rs-SINR-MeasEUTRA	UE	No	No
rs-SINR-Meas in 4.3.6.13, TS 36.306 [15].			
rsrqMeasWidebandEUTRA	UE	No	Yes
rsrqMeasWideband in 4.3.6.2, TS 36.306 [15]			
supportedBandListEUTRA	UE	No	No
supportedBandListEUTRA defined in 4.3.5.1, TS 36.306 [15].			

4.2.10.1 Void

4.2.10.2 Void

4.2.11 Void

4.2.12 Void

4.2.13 IMS Parameters

Definitions for parameters		M	FDD- TDD DIFF	FR1- FR2 DIFF
voiceOverEUTRA-5GC Indicates whether the UE supports IMS voice over E-UTRA via 5GC. It is mandated to the UE if the UE is capable of IMS voice over E-UTRA via 5GC. Otherwise, the UE does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.	UE	No	No	No
voiceOverNR Indicates whether the UE supports IMS voice over NR. It is mandated to the UE if the UE is capable of IMS voice over NR. Otherwise, the UE does not include this field. If this field is included and the UE is capable of E-UTRA with EPC, the UE shall support IMS voice over E-UTRA via EPC.	UE	No	No	Yes
voiceOverSCG-BearerEUTRA-5GC Indicates whether the UE supports IMS voice over SCG bearer of NE-DC.	UE	No	No	N/A

NOTE: In this release of specification, IMS voice over split bearer is not supported for NR-DC and NE-DC.

4.2.14 RRC buffer size

The RRC buffer size is defined as the maximum overall RRC configuration size that the UE is required to store. The RRC buffer size is 45Kbytes.

Optional features without UE radio access capability parameters

5.1 PWS features

Definitions for feature

CMAS

It is optional for UE to support CMAS reception as specified in TS 38.331 [9]. It is optional for a CMAS-capable UE to support Geofencing information (*warningAreaCoordinates*) as specified in TS 38.331 [9].

FTWS

It is optional for UE to support ETWS reception as specified in TS 38.331 [9].

KPAS

It is optional for UE to support Korean Public Alert System (KPAS) reception as specified in TS 38.331 [9]. KPAS uses the same AS mechanisms as defined for CMAS. Therefore a KPAS-capable UE shall support all behaviour that is included in TS 38.331 [9] and TS 38.304 [20] for a CMAS-capable UE.

EU-Alert

It is optional for UE to support EU-Alert reception as specified in TS 38.331 [9]. EU-Alert uses the same AS mechanisms as defined for CMAS. Therefore a EU-Alert-capable UE shall support all behaviour that is included in TS 38.331 [9] and TS 38.304 [20] for a CMAS-capable UE.

5.2 UE receiver features

Definitions for feature

SU-MIMO Interference Mitigation advanced receiver

- R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2 with 2 RX antennas
- R-ML (reduced complexity ML) receivers with enhanced inter-stream interference suppression for SU-MIMO transmissions with rank 2, 3, and 4 with 4 RX antennas

UE supporting the feature is required to meet the Enhanced Receiver Type requirements in TS 38.101-4 [18].

5.3 RRC connection

Definitions for feature

RRC connection release with deprioritisation

It is optional for UE to support RRCRelease with deprioritisationReg as specified in TS 38.331 [9].

RRC connection establishment failure with temporary offset

It is optional for UE to support RRC connection establishment failure with temporary offset (*Qoffsettemp*) as specified in TS 38.331 [9].

6 Conditionally mandatory features without UE radio access capability parameters

Features	Condition
Skipping UL configured grant if no data to transmit.	Either configuredUL-GrantType1 or configuredUL-GrantType2 is supported.
Downlink SDAP header	Either NAS reflective QoS or as-Reflective QoS is supported.
IMS emergency call	It is mandatory to support IMS emergency call for UEs which are IMS voice capable in NR.

7 Void

UE Capability Constraints 8

The following table lists constraints indicating the UE capabilities that the UE shall support.

Parameter	Description	Value				
#DRBs	The number of DRBs that a UE shall support.	16 per UE. NOTE1 NOTE3				
#minCellperMeasObj ectNR	The minimum number of neighbour cells (excluding black list cells) that a UE shall be able to store associated with a MeasObjectNR.	32 NOTE 2				
#minBlackCellRange sperMeasObjectNR	The minimum number of blacklist cell PCI ranges that a UE shall be able to store associated with a MeasObjectNR.	8				
#minCellperMeasObj ectEUTRA	The minimum number of neighbour cells that a UE shall be able to store associated with a MeasObjectEUTRA.	NOTE 2				
#minCellTotal	The minimum number of neighbour cells (excluding black list cells) that UE shall be able to store in total from all measurement objects configured.	256 with counting CSI-RS and SSB as 2.				
#maxDeprioritisation Freq	The UE shall be able to store a depriotisation request for up to 8 frequencies (applicable when receiving another frequency specific deprioritisation request via <i>RRCRelease</i> before T325 expiry).	8				
NOTE 1: For one MAC entity, the maximum number of DRBs configured with PDCP duplication and with RLC entity(ies) associated with this MAC entity is 8. NOTE 2: In case of CGI reporting, the limit regarding the cells configured includes the cell for which the						

UE is requested to report CGI i.e. the amount of neighbour cells that can be included is at most (# minCellperMeasObjectRAT - 1), where RAT represents NR and EUTRA.

This requirement is applicable in NR SA, NR-DC and NE-DC.

Annex A (normative): Differentiation of capabilities

Annex A.1: TDD/FDD differentiation of capabilities in TDD-FDD CA

Annex A.1 specifies for which TDD and FDD serving cells a UE supporting TDD/FDD CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for TDD/FDD CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FDD and TDD, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.1-1 in accordance to the following rules:
 - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell duplex mode;
 - PSCell: the UE shall support the feature for the PSCell, if the UE indicates support of the feature for the PSCell duplex mode;
 - Per serving cell: the UE shall support the feature for a serving cell if the UE indicates support of the feature for the serving cell's duplex mode;
 - All serving cells: UE shall support the feature for all serving cells in a CG if the UE indicates support of the feature for both TDD and FDD duplex modes;
 - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for all associated serving cells's duplex modes;
- For the fields where the UE is not allowed to indicate different support for FDD and TDD, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

Table A.1-1: Rel-15 UE capabilities for which FDD/TDD differentiation is allowed

UE-NR-Capability or	Classification			
UE-MRDC-Capability				
eventA-MeasAndReport	PSCell			
dl-SchedulingOffset-PDSCH-TypeA (Note3)	Associated serving cells			
dl-SchedulingOffset-PDSCH-TypeB (Note3)	Associated serving cells			
dynamicSFI (Note3)	Associated serving cells			
handoverInterF	PCell			
handoverLTE-EPC	PCell			
handoverLTE-5GC	PCell			
intraAndInterF-MeasAndReport	PSCell			
logicalChannelSR-DelayTimer(Note2)	Associated serving cells			
longDRX-Cycle	All serving cells			
multipleConfiguredGrants(Note1)	Associated serving cells			
multipleSR-Configurations	Per serving cell			
sftd-MeasNR-Cell	PCell			
sftd-MeasNR-Neigh	PCell			
sftd-MeasNR-Neigh-DRX	PCell			
sftd-MeasPSCell	PCell			
sftd-MeasPSCell-NEDC	PCell			
shortDRX-Cycle	All serving cells			
skipUplinkTxDynamic	Per serving cell			
twoDifferentTPC-Loop-PUCCH (Note3)	Associated serving cells			
twoDifferentTPC-Loop-PUSCH (Note3)	Associated serving cells			
ul-SchedulingOffset (Note3)	Associated serving cells			
NOTE 1: The associated serving cells including	g the serving cell(s) configured			
with configured grant.				
NOTE 2: For a given logical channel, the asso	ciated serving cells including the			
PUCCH cell(s) associated with this lo	ogical channel (via			
schedulingRequestID).	or brookly also a sell a sounding or also			
NOTE 3: The associated serving cells including				
command and the cell applying the command.				

Annex A.2: FR1/FR2 differentiation of capabilities in FR1-FR2 CA

Annex A.2 specifies for which FR1 and FR2 serving cells a UE supporting FR1/FR2 CA shall support a feature/capability for which it indicates support within the capability signalling.

A UE that indicates support for FR1/FR2 CA (e.g. MCG or SCG):

- For the fields for which the UE is allowed to indicate different support for FR1 and FR2, the UE shall support the feature on the PCell and/or SCell(s), as specified in tables A.2-1 in accordance to the following rules:
 - PCell: the UE shall support the feature for the PCell, if the UE indicates support of the feature for the PCell FR mode;
 - Associated serving cells: UE shall support the feature if the UE indicates support of the feature for associated serving cells's FR modes;
- For the fields where the UE is not allowed to indicate different support for FR1 and FR2, the UE shall support the feature for PCell and SCell(s) if the UE indicates support of the feature via the common capability bit.

Table A.2-1: Rel-15 UE capabilities for which FR1/FR2 differentiation is allowed

UE-NR-Capability	Classification
absoluteTPC-Command (Note2)	Associated serving cells
dl-SchedulingOffset-PDSCH-TypeA (Note2)	Associated serving cells
dl-SchedulingOffset-PDSCH-TypeB (Note2)	Associated serving cells
dynamicSFI (Note2)	Associated serving cells
handoverInterF	PCell
handoverLTE-EPC	PCell
handoverLTE-5GC	PCell
tpc-PUCCH-RNTI (Note2)	Associated serving cells
tpc-PUSCH-RNTI (Note2)	Associated serving cells
tpc-SRS-RNTI (Note2)	Associated serving cells
twoDifferentTPC-Loop-PUCCH (Note2)	Associated serving cells
twoDifferentTPC-Loop-PUSCH (Note2)	Associated serving cells
ul-SchedulingOffset (Note2)	Associated serving cells
voiceOverNR (Note1)	Associated serving cells.

NOTE 1: For a UE that does not support *lch-ToSCellRestriction* capability, the associated serving cells includes all serving cells in the CG; for a UE that supports *lch-ToSCellRestriction* capability, the associated serving cells includes the serving cells indicated by *allowedServingCells* for the LCH.

NOTE 2: The associated serving cells including both the cell sending the command and the cell applying the command.

Annex B:

UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations

Annex B clarifies the UE capability indication for the case where the UE is allowed to support different functionality between FDD and TDD, and between FR1 and FR2. Table B-1 clarifies the setting of UE capability fields for cases where the UE supports the corresponding feature in different combinations of duplex mode and frequency range. There are two possible ways of UE capability indication in Case 3 and Case 8.

Table B-1: UE capability indication for UE capabilities with both FDD/TDD and FR1/FR2 differentiations

	Joil for the reature	feature Setting of UE capability fields					
		Common UE capability (with suffix '-XDD-Diff')	Common UE capability (with suffix '-FRX-diff')	fdd-Add-UE- NR/MRDC- Capabilities	tdd-Add- UE- NR/MRDC- Capabilities	fr1-Add-UE- NR/MRDC- Capabilities	fr2-Add-UE- NR/MRDC- Capabilities
Case 1	FR1 FDD: 'supported' FR1 TDD: 'supported' FR2 TDD: 'supported'	Included	Included	Not included	Not included	Not included	Not included
Case 2	FR1 FDD: 'not supported' FR1 TDD: 'not supported' FR2 TDD: 'not supported'	Not included	Not included	Not included	Not included	Not included	Not included
Case 3	FR1 FDD: 'not supported'	Not included	Included	Not included	Included	Not included	Not included
	FR1 TDD: 'supported' FR2 TDD: 'supported'	Not included	Not included	Not included	Included	Not included	Not included
Case 4	FR1 FDD: 'not supported' FR1 TDD: 'not supported' FR2 TDD: 'supported'	Not included	Not included	Not included	Included	Not included	Included
Case 5	FR1 FDD: 'not supported' FR1 TDD: 'supported' FR2 TDD: 'not supported'	Not included	Not included	Not included	Included	Included	Not included
Case 6	FR1 FDD: 'supported' FR1 TDD: 'not supported' FR2 TDD: 'supported'	The current UE case.	JE capability signalling does not support the UE capability indication for this				
Case 7	FR1 FDD: 'supported' FR1 TDD: 'not supported' FR2 TDD: 'not supported'	Not included	Not included	Included	Not included	Included	Not included
Case 8	FR1 FDD: 'supported' FR1 TDD: 'supported' FR2 TDD: 'not supported'	Included Not included	Not included Not included	Not included Not included	Not included Not included	Included Included	Not included Not included

Annex C (informative): Change history

						Change history	
Date	Meetin g	TDoc	CR	Rev	Cat	Subject/Comment	New version
06/2017	RAN2# 98	R2-1704810				First version	0.0.1
06/2017	RAN2# NR2	R2-1707386					0.0.2
08/2017	RAN2# 99	R2-1708750					0.0.3
12/2017		R2-1712587					0.0.4
12/2017		R2-1714141					0.0.5
12/2017		R2-1714271					0.1.0
12/2017	RP-78	RP-172521				Submitted to RAN#78 for approval	1.0.0
12/2017	RP-78	202.				Upgraded to Rel-15	15.0.0
03/2018	RP-79	RP-180440	0003	3	F	Updates on UE capabilities	15.1.0
06/2018	RP-80	RP-181216	0009	2	В	Introduce ANR in NR	15.2.0
	RP-80	RP-181216	0012	1	F	Miscellaneous corrections	15.2.0
	RP-80	RP-181216	0013	-	В	Delay budget report and MAC CE adaptation for NR for TS 38.306	15.2.0
09/2018	RP-81	RP-181940	8000	4	F	Correction on total layer2 buffer size	15.3.0
	RP-81	RP-181942	0024	1	F	Introduction of UE capability constraints	15.3.0
	RP-81	RP-181942	0030	-	F	38.306 corrections and cleanup	15.3.0
12/2018	RP-82	RP-182651	0016	4	F	Clarification for Interruption-based and gap-based SFTD measurement	
	RP-82	RP-182653	0033	1	F	Timer based BWP switching	15.4.0
	RP-82	RP-182652	0035	2	F	Additional UE capabilities for NR standalone	15.4.0
	RP-82	RP-182651	0037	1	F	Clarification to UE capability of independentGapConfig for inter-RAT	15.4.0
						NR measurement not yet configured with EN-DC	
	RP-82	RP-182661	0038	2	F	Update of L2 capability parameters	15.4.0
	RP-82	RP-182660	0047	2	F	Clarification on physical layer parameters of UE capability	15.4.0
	RP-82	RP-182666	0050	3	F	Introduce RRC buffer size in NR	15.4.0
	RP-82	RP-182664	0051	2	F	Clarification of multipleConfiguredGrants	15.4.0
	RP-82	RP-182664	0052	2	F	CR to 38.306 for PDCP CA duplication for SRB	15.4.0
	RP-82	RP-182661	0054	1	F	UE capability handling for FDD/TDD and FR1/FR2	15.4.0
	RP-82	RP-182663	0057	1	F	Clarify for per CC UL/DL modulation order capabilities	15.4.0
	RP-82	RP-182664	0058	1	F	Inter-frequency handover capability	15.4.0
	RP-82	RP-182665	0060	3	F	UE capability on PA architecture	15.4.0
	RP-82	RP-182661	0062	1	F	CR on signaling contiguous and non-contiguous EN-DC capability	15.4.0
	RP-82	RP-182813	0063	6	F	Update of UE capabilities	15.4.0
	RP-82	RP-182662	0065	2	F	Introduction of SRS switching capability	15.4.0
	RP-82	RP-182667	0068	2	В	CR on introduction of UE overheating support in NR SA scenario	15.4.0
	RP-82	RP-182664	0071	-	F	Introduction of SRS switching capability	15.4.0
03/2019	RP-83	RP-190634	0073	1	F	Capability for aperiodic CSI-RS triggering with different numerology between PDCCH and CSI-RS	15.5.0
	RP-83	RP-190542	0074	1	F	Layer-1 capability update	15.5.0
	RP-83	RP-190545	0075	2	F	CR to 38.306 on introducing nr-CGI-Reporting-ENDC	15.5.0
	RP-83	RP-190545	0086	2	F	CR to clarify intra-NR handover capabilities	15.5.0
	RP-83	RP-190546	8800	3	F	Clarification for PDSCHs and PUSCHs per slot for different TBs for UE	15.5.0
						capable of processing time capability 1	
	RP-83	RP-190542	0092	2	F	Correction to mandatory supported capability signaling	15.5.0
	RP-83	RP-190542	0097	2	F	Miscellaneous corrections	15.5.0
	RP-83	RP-190545	0098	2	F	Correction on supportedBandwidthCombinationSetEUTRA-v1530 usage	15.5.0
	RP-83	RP-190543	0099	-	F	Clarification on signaling the bandwidth class	15.5.0
	RP-83	RP-190545	0100	1	F	Clarification on Frequency Separation Class	15.5.0
	RP-83	RP-190544	0101	=	F	CR on Processing delay requirements for RRC Resume procedures in TS 38.306	15.5.0
06/2019	RP-84	RP-191375	0094	1	F	CR to clarify ul-TimingAlignmentEUTRA-NR	15.6.0
	RP-84	RP-191373	0108	-	F	Layer-1, RF and RRM capability updates	15.6.0
	RP-84	RP-191373	0109	-	F	Clarification on UE capability of Ich-ToSCellRestriction	15.6.0
	RP-84	RP-191379	0110	2	F	Correction on description of additionalActiveSpatialRelationPUCCH	15.6.0
	RP-84	RP-191378	0111	1	F	Clarification on csi-RS-CFRA-ForHO	15.6.0
	RP-84	RP-191379	0114	2	F	CR on capability of maxUplinkDutyCycle for FR2	15.6.0
	RP-84	RP-191380	0115	2	F	38.306 miscellaneous corrections	15.6.0
	RP-84	RP-191378	0116	1	В	38.306 CR for late drop	15.6.0
	RP-84	RP-191381	0118	4	F	Clarification on supported modulation order capability	15.6.0
	RP-84	RP-191374	0119	-	F	Correction to PDCP parameters	15.6.0
	RP-84	RP-191381	0121	3	F	Corrections to UE Capability definitions	15.6.0
	RP-84	RP-191378	0122	1	F	38.306 Clarification on multiple TA capabilities	15.6.0
	RP-84	RP-191379	0123	2	F	CR to clarify non-codebook based PUSCH transmission	15.6.0
	RP-84	RP-191380	0124	3	F	Clarification on pdsch-ProcessingType2	

		0125	1	F	Clarification on present of tci-StatePDSCH	15.6.0
RP-84	RP-191378	0126	1		Clarification on SA fallback BC support	15.6.0
						15.6.0
						15.6.0
			1			15.6.0
			-		DC	15.6.0
RP-84	RP-191376	0134	-	F	Modified UE capability on different numerologies within the same PUCCH group	15.6.0
RP-84	RP-191554	0135	-	F	Removal of "Capability for aperiodic CSI-RS triggering with different numerology between PDCCH and CSI-RS"	15.6.0
RP-85	RP-192196	0136	1	С		15.7.0
RP-85	RP-192191	0142	1	В	Introduction of SFTD measurement to neighbour cells for NR SA	15.7.0
RP-85	RP-192193	0146	1	F	MR-DC measurement gap pattern capability	15.7.0
RP-85	RP-192194	0151	3	F	Clarifying UE capability freqHoppingPUCCH-F0-2 and freqHoppingPUCCH-F1-3-4	15.7.0
RP-85	RP-192190	0152	-	F		15.7.0
RP-85	RP-192192	0153	2	F	Miscellaneous corrections	15.7.0
RP-85	RP-192190	0154	-	F	Capability of measurement gap patterns	15.7.0
RP-85	RP-192193	0155	2	F	Correction to IMS capability	15.7.0
RP-85	RP-192194	0156	3	F	UE Capabilities covering across all serving cells	15.7.0
RP-85	RP-192190	0167	-	F	Clarification on UE capability on different numerologies within the same PUCCH group	15.7.0
RP-85	RP-192193	0168	1	F	Correction on CA parameters in NR-DC	15.7.0
RP-85	RP-192346	0169	-	С	Introduction of UE capability for NR-DC with SFN synchronization	15.7.0
RP-86	RP-192934	0185	1	F	Clarification on the restriction of maximum SRS resource sets	15.8.0
RP-86	RP-192936	0186	3	F		15.8.0
RP-86		0191	1	F		15.8.0
RP-86	RP-192937	0200	1	F	Clarification on ne-DC capability	15.8.0
RP-86	RP-192935	0202	1	F	Correction to channelBWs	15.8.0
RP-86	RP-192936	0204	1	F	Use of splitSRB-WithOneUL-Path capability (38.306)	15.8.0
RP-86	RP-192935	0205	-	F	Correction to pdsch-RepetitionMultiSlots and pusch-RepetitionMultiSlots	15.8.0
RP-86	RP-192937	0215	1	F		15.8.0
RP-86	RP-192937	0216	1	F	NE-DC dynamic power sharing capability	15.8.0
RP-86		0219	-	F		15.8.0
			-			15.8.0
RP-87	RP-200334	0194	2	F	Correction on parameter description of beamManagementSSB-CSI-RS	15.9.0
RP-87	RP-200335	0208	3	F	CR on BWCS for inter-ENDC BC with intra-ENDC BC (38.306)	15.9.0
RP-87			5	-		15.9.0
			-			15.9.0
		_	_	+		15.9.0
						15.9.0
		_		+		15.9.0
						15.9.0 15.10.0
						15.10.0
						15.10.0
RP-88		0287		F		15.10.0
RP-88	RP-201160	0294	1	F	SRS Capability report for SRS only Scell	15.10.0
RP-88	RP-201159	0298	-	F	Clarification on L1 feature of NGEN-DC and NE-DC	15.10.0
RP-88	RP-201162	0300	1	F	Clarification on L2 and RAN4 feature of NGEN-DC and NE-DC	15.10.0
RP-88	RP-201163	0303	1	F	Correction on UE capabilities with xDD and FRx differentiations	15.10.0
RP-88	RP-201163	0311	1	F	Invalidating bandwidth class F for FR1	15.10.0
RP-88	RP-201162	0317	1	F	parameters"	15.10.0
						1
RP-88	RP-201163	0319	1	F	Missing UE capability requirements	15.10.0
RP-88	RP-201164	0325	2	F	Correction on UE capability constraints	15.10.0
RP-88 RP-88	RP-201164 RP-201160	0325 0332	2	F F	Correction on UE capability constraints on the capability of Basic CSI feedback (2-32)	15.10.0 15.10.0
RP-88	RP-201164	0325		F	Correction on UE capability constraints on the capability of Basic CSI feedback (2-32) Clarification on the support of IMS voice over split bearer for NR-DC and NE-DC	15.10.0
RP-88 RP-88	RP-201164 RP-201160	0325 0332	2	F F	Correction on UE capability constraints on the capability of Basic CSI feedback (2-32) Clarification on the support of IMS voice over split bearer for NR-DC	15.10.0 15.10.0
RP-88 RP-88 RP-88	RP-201164 RP-201160 RP-201162	0325 0332 0338	2 - 1	F F	Correction on UE capability constraints on the capability of Basic CSI feedback (2-32) Clarification on the support of IMS voice over split bearer for NR-DC and NE-DC Clarification on maximum number of supported PDSCH Resource Element mapping patterns Introduction of CGI reporting capabilities	15.10.0 15.10.0 15.10.0
RP-88 RP-88 RP-88 RP-88 RP-88	RP-201164 RP-201160 RP-201162 RP-201161 RP-201164 RP-201161	0325 0332 0338 0342 0345 0347	2 - 1 1 2 1	F F F F	Correction on UE capability constraints on the capability of Basic CSI feedback (2-32) Clarification on the support of IMS voice over split bearer for NR-DC and NE-DC Clarification on maximum number of supported PDSCH Resource Element mapping patterns Introduction of CGI reporting capabilities UE Capability Enhancement for FR1(TDD/FDD) / FR2 CA and DC	15.10.0 15.10.0 15.10.0 15.10.0 15.10.0
RP-88 RP-88 RP-88 RP-88 RP-88 RP-88	RP-201164 RP-201160 RP-201162 RP-201161 RP-201164 RP-201161 RP-201161	0325 0332 0338 0342 0345 0347 0352	2 - 1 1	F F F F F	Correction on UE capability constraints on the capability of Basic CSI feedback (2-32) Clarification on the support of IMS voice over split bearer for NR-DC and NE-DC Clarification on maximum number of supported PDSCH Resource Element mapping patterns Introduction of CGI reporting capabilities UE Capability Enhancement for FR1(TDD/FDD) / FR2 CA and DC CR on unnecessary XDD FRX differentiation	15.10.0 15.10.0 15.10.0 15.10.0 15.10.0 15.10.0 15.10.0
RP-88 RP-88 RP-88 RP-88 RP-88	RP-201164 RP-201160 RP-201162 RP-201161 RP-201164 RP-201161	0325 0332 0338 0342 0345 0347	2 - 1 1 2 1	F F F F	Correction on UE capability constraints on the capability of Basic CSI feedback (2-32) Clarification on the support of IMS voice over split bearer for NR-DC and NE-DC Clarification on maximum number of supported PDSCH Resource Element mapping patterns Introduction of CGI reporting capabilities UE Capability Enhancement for FR1(TDD/FDD) / FR2 CA and DC	15.10.0 15.10.0 15.10.0 15.10.0 15.10.0
	RP-84 RP-84 RP-84 RP-84 RP-84 RP-84 RP-84 RP-84 RP-85 RP-85 RP-85 RP-85 RP-85 RP-85 RP-85 RP-86 RP-87 RP-87 RP-87 RP-87 RP-87 RP-87 RP-87 RP-87 RP-87 RP-88 RP-88 RP-88 RP-88 RP-88 RP-88	RP-84 RP-191378 RP-84 RP-191375 RP-84 RP-191379 RP-84 RP-191376 RP-84 RP-191376 RP-84 RP-191376 RP-84 RP-191376 RP-85 RP-191554 RP-85 RP-192196 RP-85 RP-192193 RP-85 RP-192193 RP-85 RP-192193 RP-85 RP-192190 RP-85 RP-192190 RP-85 RP-192193 RP-85 RP-192193 RP-85 RP-192193 RP-85 RP-192193 RP-85 RP-192193 RP-85 RP-192193 RP-86 RP-192193 RP-87 RP-192934 RP-86 RP-192934 RP-86 RP-192935 RP-86 RP-192935 RP-86 RP-192935 RP-86 RP-192937 RP-86 RP-192937 RP-86 RP-192937 RP-86 <th< td=""><td>RP-84 RP-191378 0126 RP-84 RP-191375 0128 RP-84 RP-191379 0130 RP-84 RP-191379 0132 RP-84 RP-191376 0133 RP-84 RP-191376 0134 RP-84 RP-191376 0134 RP-84 RP-191376 0134 RP-85 RP-192196 0136 RP-85 RP-192196 0136 RP-85 RP-192191 0142 RP-85 RP-192193 0146 RP-85 RP-192193 0146 RP-85 RP-192193 0151 RP-85 RP-192190 0152 RP-85 RP-192190 0154 RP-85 RP-192190 0154 RP-85 RP-192193 0156 RP-85 RP-192193 0167 RP-85 RP-192193 0168 RP-85 RP-192193 0168 RP-86 RP-192934 0185 RP-86 <t< td=""><td>RP-84 RP-191378 0126 1 RP-84 RP-191375 0128 - RP-84 RP-191379 0130 2 RP-84 RP-191376 0133 - RP-84 RP-191376 0133 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-85 RP-192196 0136 1 RP-85 RP-192199 0142 1 RP-85 RP-192193 0146 1 RP-85 RP-192190 0152 - RP-85 RP-192190 0153 2 RP-85 RP-192190 0154 - RP-85 RP-192190 0167 - RP-85 RP-192193 0168 1 RP-86 RP-192934 0169 - RP-86 RP-192935</td><td>RP-84 RP-191378 0126 1 F RP-84 RP-191375 0128 - F RP-84 RP-191379 0130 2 F RP-84 RP-191376 0132 1 F RP-84 RP-191376 0133 - F RP-84 RP-191376 0134 - F RP-85 RP-192196 0136 1 C RP-85 RP-192190 0142 1 B RP-85 RP-192193 0146 1 F RP-85 RP-192190 0152 - F RP-85 RP-192190 0154 - F RP-85 RP-192193 0167 - <</td><td>RP-84 RP-191375 0126 1 F Clarification on SA failback BC support RP-84 RP-191379 0130 2 F Correction to Beam Correspondence for CA RP-84 RP-191379 0130 2 F Correction on the number of DRB in UE Capability Constraints RP-84 RP-191376 0131 F CR Correction on the number of DRB in UE Capability Constraints RP-84 RP-191376 0133 F UE capability signaling for FDMIMO processing capabilities for EN-DC. RP-84 RP-191376 0134 - F Modified UE capability on different numerologies within the same PUCCH group RP-84 RP-191379 0135 - F Removal of 'Capability for aperiodic CSI-RS' triggering with different numerology between PDCCH and CSI-RS' RP-85 RP-192190 0136 1 C. Additional capability signaling for 1024QAM support RP-85 RP-192191 0142 1 B Introduction of SFTD measurement to neighbour cells for NR SA RP-85 RP-192191 0151 3 F Clarifying UE capability for aperiodic CSI-RS triggering with different numero</td></t<></td></th<>	RP-84 RP-191378 0126 RP-84 RP-191375 0128 RP-84 RP-191379 0130 RP-84 RP-191379 0132 RP-84 RP-191376 0133 RP-84 RP-191376 0134 RP-84 RP-191376 0134 RP-84 RP-191376 0134 RP-85 RP-192196 0136 RP-85 RP-192196 0136 RP-85 RP-192191 0142 RP-85 RP-192193 0146 RP-85 RP-192193 0146 RP-85 RP-192193 0151 RP-85 RP-192190 0152 RP-85 RP-192190 0154 RP-85 RP-192190 0154 RP-85 RP-192193 0156 RP-85 RP-192193 0167 RP-85 RP-192193 0168 RP-85 RP-192193 0168 RP-86 RP-192934 0185 RP-86 <t< td=""><td>RP-84 RP-191378 0126 1 RP-84 RP-191375 0128 - RP-84 RP-191379 0130 2 RP-84 RP-191376 0133 - RP-84 RP-191376 0133 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-85 RP-192196 0136 1 RP-85 RP-192199 0142 1 RP-85 RP-192193 0146 1 RP-85 RP-192190 0152 - RP-85 RP-192190 0153 2 RP-85 RP-192190 0154 - RP-85 RP-192190 0167 - RP-85 RP-192193 0168 1 RP-86 RP-192934 0169 - RP-86 RP-192935</td><td>RP-84 RP-191378 0126 1 F RP-84 RP-191375 0128 - F RP-84 RP-191379 0130 2 F RP-84 RP-191376 0132 1 F RP-84 RP-191376 0133 - F RP-84 RP-191376 0134 - F RP-85 RP-192196 0136 1 C RP-85 RP-192190 0142 1 B RP-85 RP-192193 0146 1 F RP-85 RP-192190 0152 - F RP-85 RP-192190 0154 - F RP-85 RP-192193 0167 - <</td><td>RP-84 RP-191375 0126 1 F Clarification on SA failback BC support RP-84 RP-191379 0130 2 F Correction to Beam Correspondence for CA RP-84 RP-191379 0130 2 F Correction on the number of DRB in UE Capability Constraints RP-84 RP-191376 0131 F CR Correction on the number of DRB in UE Capability Constraints RP-84 RP-191376 0133 F UE capability signaling for FDMIMO processing capabilities for EN-DC. RP-84 RP-191376 0134 - F Modified UE capability on different numerologies within the same PUCCH group RP-84 RP-191379 0135 - F Removal of 'Capability for aperiodic CSI-RS' triggering with different numerology between PDCCH and CSI-RS' RP-85 RP-192190 0136 1 C. Additional capability signaling for 1024QAM support RP-85 RP-192191 0142 1 B Introduction of SFTD measurement to neighbour cells for NR SA RP-85 RP-192191 0151 3 F Clarifying UE capability for aperiodic CSI-RS triggering with different numero</td></t<>	RP-84 RP-191378 0126 1 RP-84 RP-191375 0128 - RP-84 RP-191379 0130 2 RP-84 RP-191376 0133 - RP-84 RP-191376 0133 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-84 RP-191376 0134 - RP-85 RP-192196 0136 1 RP-85 RP-192199 0142 1 RP-85 RP-192193 0146 1 RP-85 RP-192190 0152 - RP-85 RP-192190 0153 2 RP-85 RP-192190 0154 - RP-85 RP-192190 0167 - RP-85 RP-192193 0168 1 RP-86 RP-192934 0169 - RP-86 RP-192935	RP-84 RP-191378 0126 1 F RP-84 RP-191375 0128 - F RP-84 RP-191379 0130 2 F RP-84 RP-191376 0132 1 F RP-84 RP-191376 0133 - F RP-84 RP-191376 0134 - F RP-85 RP-192196 0136 1 C RP-85 RP-192190 0142 1 B RP-85 RP-192193 0146 1 F RP-85 RP-192190 0152 - F RP-85 RP-192190 0154 - F RP-85 RP-192193 0167 - <	RP-84 RP-191375 0126 1 F Clarification on SA failback BC support RP-84 RP-191379 0130 2 F Correction to Beam Correspondence for CA RP-84 RP-191379 0130 2 F Correction on the number of DRB in UE Capability Constraints RP-84 RP-191376 0131 F CR Correction on the number of DRB in UE Capability Constraints RP-84 RP-191376 0133 F UE capability signaling for FDMIMO processing capabilities for EN-DC. RP-84 RP-191376 0134 - F Modified UE capability on different numerologies within the same PUCCH group RP-84 RP-191379 0135 - F Removal of 'Capability for aperiodic CSI-RS' triggering with different numerology between PDCCH and CSI-RS' RP-85 RP-192190 0136 1 C. Additional capability signaling for 1024QAM support RP-85 RP-192191 0142 1 B Introduction of SFTD measurement to neighbour cells for NR SA RP-85 RP-192191 0151 3 F Clarifying UE capability for aperiodic CSI-RS triggering with different numero

	RP-88 F	RP-201187	0361	-	В	CR on introduction of BCS to asymmetric channel bandwidths (38.306)	15.10.0
--	---------	-----------	------	---	---	---	---------