Dhaka University of Engineering & Technology (DUET), Gazipur 08-12-20

Department of Computer Science and Engineering (CSE)

Course Title: Microprocessor & Interfacing Sessional (CSE-3812)

Lab: 02

Familiarizing with MDA 8086 trainer Kit Commands in Serial Monitor Mode.

Objectives:

- 1. To familiarize with the operation of MDA-8086 in "Serial Monitor" mode.
- 2. To learn the procedure of loading a program in RAM of MDA-8086 in "Serial Monitor" mode.

Basic Theory:


Serial monitor is the basic monitor program to perform data communication between MDA-8086 and a computer. So as to use serial monitor, we have to move jumper P1 which located on the PCB like this.

observe the contents of different registers in the LCD. On the other hand, users can load instructions/programs from the computer via serial port in Serial Monitor Mode.

On a power-up, the following message will be displayed on a LCD.

MDA-8086 Kit!! Midas 2109-5964 Midas 2109-5964

To use "Serial Monitor" mode, move jumper P1 which is located on the PCB like this.



Connect the serial interface of the MDA-8086 with the computer (PC) interface and run the WinComm program in PC and press the RES key to change the mode of MDA-8086 trainer Kit.

Operation of serial monitor command

Users can only use commands which are stored at the serial monitor. Serial monitor can execute to command when the user types command and then CR (carriage return) key. If there is no command at the serial monitor, an error message will be displayed with a bell sound and the serial monitor prompt will be displayed again.

8086>?

HELP Command

E segment: offset..... Enter Data to Memory D segment: offset length..... Dump Memory Contents R [register name]...... Register Display & Change M address1, length, address2......: Move Memory From 1 to 2 F address, length, data..... Fill Memory with any Data L Return Key...... Program Download G Segment : offset Execute Program T...... Program 1 step execute

Basic Command Syntax:

1. Memory Modify Command Syntax: E segment: offset

Purpose: This command is used to enter data to memory.

Example:

8086> E 0000:1000 € 0000:1000 FF? 11 0000:1001 FF? 22 0000:1002 FF? 33 0000:1003 FF? 44~ 0000:1004 FF? 55 0000, 100517.

1 Enter > Back

```
0000:1005 FF? / (Offset decrement)
          0000:1004 55?
2. Memory Display Command
   Syntax: D segment: offset
   Purpose: This command is used to display the data stored in memory.
   Example:
 √8086> D 0000:1000
```

D 0000:1000 3

3. Display Register Command

Syntax: R

Purpose: The R command is used to display the 8086 processor registers

0000:1000 11 22 33 44 55 FF FF

Example: 8086> R

DX=0000 AX=0000 BX=0000 CX=0000 SP=0540 BP=0000 SI=0000 DI=0000 DS=0000 XS=0000 ES=0000 SS=0000 IP=1000 FL=0000=

To Change individual register:

```
8086 > R AX
AX = 0000 1234
8086 > R BX 🗸
BX= 0000 4567
8086 > R CX
CX= 0000 7788
8086 > R DX
DX = 0000 1111
```

4. Program download and execute command:

The L command moves object data in hex format from an external device to memory.

8086> L ⋅

Download start!! (Note: See section 5. Serial monitor experiment) : 14100000B800008ED88EC0BB00208B078A6F028A4F038BB6:101014003E8B5604268B76068B7E088B1E0A20CCCC :0E20000012345678ABCDF0146853B1C41020E2 :0000001FF OK completed!!

➤ Set IP 8086>R IP IP=1000 8086>T **⁴** DX=1111 CX=7788 BX=4567 AX = 1234DI=0000 SI = 0000BP=0000 SP=0540 CS = 0000SS=0000 ES=0000 DS=0000 FL=0100 = . . . t 1P = 1003Next address

Execute Program Command

8086> G 0000:1000 4 Execute Address = 0000:1000

Write Assembly Language Program using notepad to transfer the following hexa-decimal values to the specified registers:



AX=3789 h, BX= AB9F h, CX=C25A h, DX= B21C h

Then, ADD the value of AX with BX and SUBTRACT the value of DX from CX. MOV the content from AX to BX and CX to DX. Then, make an AND operation using the updated contents of AX and CX.

Experiment Procedure:

- 1. Write the above program in notepad and save the file as "filename.asm". Place this file in the folder where "masm.exe" exists.
- 2. Go to the command prompt and execute "masm.exe". You will see the following message Microsoft (R) Macro Assembler Version 5.10 Copyright (C) Microsoft Corp 1981, 1988. All right reserved. Source filename [.ASM]:
- 3. Follow the procedure given below to prepare machine code for your program: Source filename [.ASM]: filename Press ENTER

Object filename [C: file name.OBJ]: Press ENTER

Source listing [NUL.LST]: filename Press ENTER Cross reference [NUL.CRF]: Press ENTER

File povenload

4. Execute "LOD186.exe". You will see the following message Paragon LOD186 Loader-Version 4.0h Copyright (C) 1983 - 1986 Microtec Research Inc. ALL RIGHT RESERVED. Object/Command File [.OBJ]:

Follow the procedure given below to prepare HEX (ABS) file for your program:

[.OBJ]:

Object/Command File

Press ENTER filename

Output Object File

[C:filename.ABS]: Press ENTER

[C:NUL.MAP]

Map Filename

Press ENTER

**LOAD COMPLETE

Turn on the 8086 microprocessor kit.

- 7. Open the "Wincomm" window. Press "L" then "Enter". You will see the following message:
 - ** Serial Monitor 1.0 **
 - ** Midas 335-0964/5 **

8086 > L Press ENTER

Down load start!!

- 8. Strike PgUp or F3 key of your keyboard. A new window will appear. Locate the "filename.ABS" file and open it.
- 9. You will observe that file download has started. A message like the following one will be shown:

:14100000B800008ED88EC0BB00208B078A6F028A4F038BB6

:101014003E8B5604268B76068B7E088B1E0A20CCCC

:0E20000012345678ABCDF0146853B1C41020E2

:0000001FF

OK completed!!

10. After loading the program, run the program in (press T command or G from the keyboard, then press enter) in MDA-8086 kit and ensure the display output and verify the calculated value of different registers. Perform theoretical calculations and verify results and fill-up the given data table.

Seg. Address Offset Address Machine Code	

Instruction	AX	BX	CX	DX	Flag Reg.