Northwind Refrigeration
NWR-2D-48 Two-Door Reach-In Refrigerator
Service Manual
Document NWR-SM-48, Revision C (2025-06)
Applies to model NWR-2D-48, all serial numbers.
For use by qualified refrigeration service technicians only.

Section 2 - Specifications
Refrigerant: R-290
Refrigerant charge: 150 g
Rated voltage: 115 V
Frequency: 60 Hz
Rated current: 6.8 A
Cabinet set point: 3 C (adjustable 1 C to 7 C)

Section 3 - Troubleshooting: cabinet temperature high

3.1 Confirm the controller display reads above set point for more than 30 minutes.

3.2 Check that the evaporator fan runs when the door switch is closed.

3.3 If the fan does not run, measure 115 V at the evaporator fan motor connector.

3.4 Voltage present and fan stopped: replace the evaporator fan motor.

3.5 Inspect the door gasket for tears; a torn gasket causes frost and high temperature.

WARNING: Disconnect power before servicing. R-290 is flammable; no open flames.

Section 4 - Replacement parts
Evaporator fan motor 5A1-0402
Condenser fan motor 5A1-0315
Electronic controller 3C7-1180
Door gasket, left 2G4-0048
Defrost thermostat 4T2-0077
Use only Northwind original parts. Substitutes void the warranty.