

# **Assembly instructions**

## M3 Inserts.


**Buffer tower** 



#### Interface block




#### Case




# **6x3 Magnets**

Interface block




Case




# Assembling the parts.

#### The buffer tower stack.

Use as many tower as you need.




#### Assembling the interface block to the Buffer tower




# **Assembling the buffer Head**


Inserting the bearing to the wheel




#### Assembling the wheel to the head case




#### Assembling the guide to the head




#### Optional spring and ball bearing.




#### Assembling the lever.



### Adjusting the gear.





# Closing the head



# Installing the head on the interface block.


Insert the hook first, then tilt the head so the magnets stick together.





# Usage

Filament loading position



Printing / buffering position

