

ON Switch:

Press: RUN STOP END

Press: LOAD

Insert side One or Two of the Stat exerciser card into the upper slot of the magnetic card reader.

FIX ()

0

The card will be drawn through the card reader and partially ejected from the lower slot.

N. temporary 2 N. Press: END N = 1, 2, 3, ... 8 Cyclic

To stop exerciser:

STOP Press:

*The screen will blank for varying time periods between displays.





M HEWLETT-PACKARD CALCULATOR

9810A STAT EXERCISER CARD

SIDE TWO PROGRAM Model 10 Stat Exerciser

PROGRAM Model 10 Stat Exerciser

SIDE ONE