



Introduction UART


Communication Protocols

- Parallel Vs. Serial
 - Parallel: Faster / More expensive
 - Serial: Cheaper / slower



Communication Protocols

- Timing in serial communication
 - Synchronous Serial
 - Asynchronous Serial
- Rules of Asynch. Protocols
 - Sync bit
 - Parity bit
 - Baud rate
 - Data bit



Parity and Baud Rate

- Parity
 - Even Parity : 10101010101 → 6 one's → EP=0
 - Odd Parity : 01010101010 → 5 one's → OP=0
- Baud Rate
 - Pulse per second
 - In digital world: Bits per second
 - 9600 baud → 9600 bps or 104 μ s per bit.
- Synch bit
 - Required to define the beginning/end of the data
 - the **start bit [LOW]** and the **stop bit [HIGH]**

9600 8N1 – 9600 bps/
8 bits per data / No
parity / One Stop bit
Always has start bit




Questions

- What will be the EVEN parity value if n=1111 1110?
- What will be the ODD parity value if n=1111 1110?
- How long does it take to transmit a 1-Mbit file at 9600 baud rate?
- Let's say P represents Even Parity. Assume P=1. Can we accept this as a correct frame: 1101 1110P?


Serial Communication



- Universal Asynchronous Receiver and Transmitter (UART)
 - UART is programmable.
 - Asynchronous
 - Sender provides no clock signal to receivers
 - FT232R converts the UART port to a standard USB interface



Data Frame



Tolerate **10%** clock shift during transmission

- Sender and receiver uses the same transmission speed
- Data frame
 - One start bit
 - Data (LSB first or MSB, and size of 7, 8, 9 bits)
 - Optional parity bit
 - One or two stop bit

$$\text{Overhead \%} = 1 - (\text{Useful Data} / \text{Total Data})$$

$$9600 / (1 + 8 + 1 + 1) = \sim 872 \text{ frames/second}$$

Problem


- Assume we have a file with size 1 million bits. Assume we use 9600:8-1-1 (includes STOP and SATRT bits). How long does it take to transmit the file? Calculate the Overhead %.
 - 8-1-1 → each frame has 11 bits
 - Baud rate is 9600 bits/sec--> Frame rate = $9600/11=872.72$ Frames/sec or 1.146 msec/frame
 - Number of frames generated: $1,000,000 \text{ bits} \times 1 \text{ frame}/8 \text{ bit} = 125,000 \text{ frames}$
 - Time to transmit 125,000 frames = $125000 \text{ frame} \times 1.146 \text{ msec/frame} = 143.25 \text{ sec!}$
 - Overhead % = $[1 - (\text{Useful Data} / \text{Total Data})] \times 100 = [1 - (8/11)] \times 100 = 27.3$

How long does it take to transmit 100,000 bits at 57,600 baud rate?


What are we transmitting? What is the baud rate?

Start here!

Assume LSB first





Transmitting 0x32 and 0x3C




1 start bit, 1 stop bit, 8 data bits, no parity, baud rate = 9600

Communication Modes


- A serial interface can have different communication modes
 - Full Duplex - means both devices can send and receive simultaneously.
 - Half-Duplex - means serial devices must take turns sending and receiving.




Differential Vs. Single Ended




Noise sources: (1) induction picked up on the wired,
(2) voltage difference between two grounds



Requires more wires
but eliminates noise




Differential Vs. Single Ended




UART

- A universal asynchronous receiver/transmitter (UART) is a block of circuitry responsible for implementing serial communication
- USART – Supports synchronous communication




Multiple Bus Connections



UART Protocols

Different Voltage Levels


Standard	Voltage signal	Max distance	Max speed	Number of devices supported per port
RS-232	Single end (logic 1: +5 to +15V, logic 0: -5 to -15 V)	100 feet	115Kbit/s	1 master, 1 receiver
RS-422	Differential (-6V to +6V)	4000 feet	10Mbit/s	1 master, 10 receivers
RS-485	Differential (-7V to +12V)	4000 feet	10Mbit/s	32 masters, 32 receivers




PN	RS-232	RS-485 HALF	RS-485 FULL	RS-422
1	DCD			
2	RXD	DATA-	TXD-	TXD-
3	TXD	DATA+	TXD+	TXD+
4	DTR			
5	GND		GND	GND
6	DSR			
7	RTS		RXD+	RXD+
8	CTS		RXD-	RXD-
9				

Interfacing

- Note that in general we **SHOULD** use something like Maxim's MAX232 in order to ensure voltage compa)bility between the **PIC and the RS232 or the terminal**
- It is also possible to INVERT polarity of the signals on TX and RX pins of USART, to interface to the terminal




Pin	Signal	Pin	Signal
1	Data Carrier Detect	6	Data Set Ready
2	Received Data	7	Request to Send
3	Transmitted Data	8	Clear to Send
4	Data Terminal Ready	9	Ring Indicator
5	Signal Ground		





Interfacing to a PC

- Download a PC terminal software such as Hyper Terminal or RealTerm (<https://sourceforge.net/projects/realterm/>) If you only have a USB port you may need a USB/ Serial Cable and driver
- Set the Hyper Terminal to 9600, N,1,0




UART Connection

To send and receive data using UART we can use several methods including:
polling, interrupt




Bluetooth




A little about Bluetooth

- Operates at the ISM frequency band
- Bluetooth is divided into 79 channels of different frequencies.
- A Bluetooth device, hops frequency at a rate of 1600 hops per second, randomly selecting a channel of 1 MHz to operate.



A little about Bluetooth

- Operates at the ISM frequency band
- Bluetooth is divided into 79 channels of different frequencies.
- A Bluetooth device, hops frequency at a rate of 1600 hops per second, randomly selecting a channel of 1 MHz to operate.



Bluetooth PICONET

- Each Bluetooth device has a 48-bit address:
0x 0018 E4 0C68 0A

- Temporary Network
- Up to 8 Active Devices
- Master Coordinates the Piconet and Slaves follow the Master
- Each Bluetooth Devices may Operate as Either Master or Slave

