



**ATAK**

**UAS Tool**

Plug-in Version: 12.12.2

ATAK 5.4

15 July 2025

# **Contents**

<b>OVERVIEW .....</b>	
Supported sUAS Platforms .....	
Supported sUAS Platforms (continued) .....	
Supported sUAS Platforms (continued) .....	
<b>HOME SCREEN .....</b>	
<b>PLATFORM SETTINGS .....</b>	
File Manager .....	
Flight Logs .....	
Advanced Options .....	
<b>RADIAL MENU .....</b>	
<b>UAS OPERATOR FEATURES .....</b>	
sUAS Metadata .....	
Quick Flight Toolbar .....	
Quick Flight Toolbar (continued) .....	
Quick Flight Toolbar (continued) .....	
Instrument Panel .....	
Instrument Panel (continued) .....	
Sensor Point of Interest (SPol) Metadata .....	
Lower Toolbar .....	
Lower Toolbar - Gimbal Controls (continued) .....	
Lower Toolbar - Broadcast Video Stream .....	
Lower Toolbar - Platform Settings .....	
Lower Toolbar - Arm/Disarm Platform .....	

# Contents

Lower Toolbar - Trigger .....
Mini Map .....
<b>ADDITIONAL OPTIONS MENU .....</b>
Additional Options (continued) .....
Additional Options (continued) .....
Additional Options - Mission (continued) .....
UAS Stored Tasks (Routes) .....
Editing a Route .....
Route Execution .....
Geofence Manager .....
Geofence Manager (continued) .....
Rally Manager .....
Video Overlays .....
Video Overlays (continued) .....
Widgets .....
Widgets (continued) .....
Adjust UI .....
Logs .....
Logs (continued) .....
ATAK Geofence Manager .....
UAS Map Labels .....
<b>OBSERVER DEVICES .....</b>
Observer Devices (continued) .....
<b>UAS TOOL PREFERENCES .....</b>