PVR CONTROLS

Document No. : PVR / DSG / PRM
Issue No. & Date : 01 & 24-11-2023
Rev No. & Date : 00 & 24-11-2023

PRODUCT REGISTER MAP FOR SZ-7526TX-REA

Communication Settings :

Communication Port	1 TTL Port compatible with RS 485 Slave	
Communication Protocol	Modbus RTU	
Transmission Type	Half Duplex Asynchronous	
Bits Per Byte	1 Start Bit, 8 Data Bits, 1 Stop Bit, Parity : None, even, odd	
Device Id	Settable Disable(0) to 250	
Baud Rate	Settable 1: 9600 2: 19200 3: 38400	
Functions Supported	01 : Read Coil Status 03 : Read Holding Registers 05 : Write Single Coil 06 : Write Single Register 16 : Write Multiple Register	

Note:
1) At a time only 50 registers are accessible.
2) For Read only parameters of Temperature like Control Temperature, Set Point(SP), Control Temp Log High,Control Temp Log Low, multiply Factor is 0.1 if rS is set to 0 and multiply Factor is 1 if rS parameter is set to 1.
3) For Temperature parameters SP, P2,P2d, P3,P3d, HS, LS, P4, P5 multiply Factor is 0.1 if rS is set to 0 and multiply Factor is 1 if rS parameter is set to 1.

TYPE	Address	VARIABLE TYPE	Variable Name	COMMENTS
R	40001	Unsigned Int	PVR Key	7507
R	40002	Unsigned Int	Software Revision	
R	40003	Unsigned Int	Controller Identification Code	115
R	40004	Signed Int	Device (Slave) ID	Eg. dis(0) to 250
R	40005	Signed Int	rS	0 = 0.1 Deg C & 1 = 1 Deg C
R	40006	Signed Int	Control Temperature (Display Temperature)	This is the value of Control Temperature . If value =1001, it is Control Probe Fail Low side condition. If Value is 1002 , it is Control Probe Fail higher side. This is the Temperature which is seen on the Display.
R	40007		NA	
R	40008		Actual Temperature	
R	40009		NA	
R	40010	Unsigned Int	System Status / Delay Status (Bitwise)	
R	40011	Unsigned Char	Relay status (Bitwise)	0 = OFF 1 = ON
R	40012	Unsigned Char	Fault status (Bitwise)	1 = Fault 0 = No Fault
R	40013		NA	
R	40014	Unsigned Int	Compressor Run Hours	
R	40015		NA	
R	40016	Unsigned Int	P8H	Balanced Defrost Time Hours
R	40017	Unsigned Int	P8m	Balanced Defrost Time Mins
R	40018	Signed Int	Set point	Set point for read only purpose.
R	40019	Signed Int	Temp Log High	Last high temperature, Log reset value 1007
R	40020	Signed Int	Temp Log Low	Last low temperature,, Log reset value 1007
These are all programmable parameters .There description ,function ,minimum and maximum limits are as given in the Instruction manual.				
R/W	40031	Signed Int	SP	
R/W	40032	Signed Int	P1	
R/W	40033	Signed Int	P2	
R/W	40034	Signed Int	P2d	
R/W	40035	Signed Int	P3	
R/W	40036	Signed Int	P3d	
R/W	40037	Signed Int	HS	
R/W	40038	Signed Int	LS	
R/W	40039	Signed Int	P4	
R/W	40040	Signed Int	P5	
R/W	40041	Signed Int	P6	
R/W	40042	Signed Int	ot	
R/W	40043	Signed Int	E1	

R/W	40044	Signed Int	Cn	When E1 is not 2 , these parameters can't be modified
R/W	40045	Signed Int	Cy	
R/W	40046	Signed Int	P7	When P1 is 1 ,this parameter can't be modified
R/W	40047	Signed Int	P8	When P1 is 1 ,this parameter can't be modified When P7 is 0 ,this parameter can't be modified
R/W	40048	Signed Int	AF0	
R/W	40049	Signed Int	CF1/ do1	When AF0 is 0, this parameter can't be modified
R/W	40050	Signed Int	CF2/do2	When AF0 is 0, this parameter can't be modified
R/W	40051	Signed Int	CF3	When AF0 is 0, 1, 2 this parameter can't be modified When CF2 is 0,1 this parameter can't be modified
R/W	40052	Signed Int	CF4	When AF0 is 0, 1, 2 this parameter can't be modified When CF2 is 0,1 this parameter can't be modified When CF3 is 0 this parameter can't be modified
R/W	40053	Signed Int	do3	When AF0 is 0, 3, 4 this parameter can't be modified
R/W	40054	Signed Int	did	
R/W	40055	Signed Int	bd	When did is 0,this parameter can't be modified
R/W	40056	Signed Int	Par	When did is 0,this parameter can't be modified
R/W	40057	Signed Int	Ccr	
R/W	40058	Signed Int	ddF	When P1 is 1 ,this parameter can't be modified When P7 is 0 ,this parameter can't be modified
R/W	40059	Signed Int	nd	
R/W	40060	Signed Int	dd	
R/W	40061	Signed Int	AL	
R/W	40062	Signed Int	Adt	
R/W	40063	Signed Int	Add	When AL is 0 ,these parameters can't be modified
R/W	40064	Signed Int	rS	
R/W	40065	Signed Int	PA	
R/W	40066	Signed Int	LP	If LP = 1, All parameters are only readable but can't be modified except LP parameter
R/W	40067	Signed Int	Ver	This is read only parameter
R/W	40068	Signed Int	FS	

Type	**Address**	**Coil Function**	**Variable Name**
R/W	1	Power	Extra
R/W	2	Alarm Relay Mute	When Alarm relay is ON, it will show 1, user need to write 0 to Mute the Alarm Relay
R/W	3	Manual Fault Reset	When Manual Fault Reset is present, it will show 1, user need to write 0 to Reset the Faults.
R/W	4	Temp Log Reset	This value will always be 0, when user want to Reset the Temp Log, user need to write 1.
R/W	5	Defrost	User need to write 1 to Start the Defrost, user need to write 0 to Stop the Defrost.

Type	**40010(Bitwise)**	**System Status**	**COMMENTS**
R	BIT0	POWER OFF	Extra
R	BIT1	KEYPAD LOCK	0 = Keypad is Unlocked 1 = Keypad is Locked
R	BIT2	Resolution_1	0 =1°C 1 = 0.1°C
R	BIT3	Resolution_2	Extra
R	BIT4	Temperature Unit selection	Extra
R	BIT5	DEFROST	0 = Defrost OFF 1 = Defrost ON
R	BIT6	NA	
R	BIT7	NA	
R	BIT8	Compressor Restart time Delay	0 = Delay not in process 1 = Delay in process
R	BIT9	Compressor Minimum ON Time Delay (ot Parameter)	
R	BIT10	Ht/Lt Power On Delay	

Type	**40011 (Bitwise)**	**Relay status**	**COMMENTS**

R	BIT0	COMPRESSOR	0 = Relay OFF 1 = Relay ON
R	BIT1	ALARM	
Type	**40012(Bitwise)**	**Fault status Common**	**COMMENTS**
R	BIT0	Probe Fail Low	0 = Fault absent 1 = Fault Present
R	BIT1	Probe Fail High	
R	BIT2	Ht	
R	BIT3	Lt	
R	BIT4	DOOR	
R	BIT5	COMP FAULT	
R	BIT6	MANUAL COMP FAULT	
NA	Not applicable		

Prepared By :	Checked By :	Approved By :
Name : Sneha Akale	Name : Datta Takale	Name : Bharati Avhad
Designation : Documentation Engg	Designation : QC Engineer	Designation : Design Engineer