

WTP COMPLIANCE AND MONITORING GUIDE

WTP COMPLIANCE AND MONITORING GUIDE

Owner Reference Resource

Purpose

This resource is useful enough to help asset owners identify issues, keep useful records, and decide when to escalate – it is not a repair guide, design guide, or compliance certificate.

Owner guide to understanding monitoring records, alarms and escalation points for water treatment plants.

Important Scope Note

This guide is general information only. It is not a water quality management plan, regulatory compliance certificate, SCADA design guide, commissioning procedure, or operating manual.

Use it to understand what monitoring records are telling you and when to escalate. Do not use it to set operating limits, change alarm settings, tune process control or make compliance determinations without site-specific advice.

What This Guide Helps You Do

- Understand why common monitoring parameters matter.
- Recognise when a trend needs attention.
- Keep better records for review.
- Escalate unclear or repeated alarm conditions.

What This Guide Does Not Cover

- ADWG interpretation for a specific scheme.
- Control philosophy design.
- Alarm setpoint selection.
- SCADA programming.
- Process validation.
- Sampling plan design.
- Regulatory reporting advice.

Why Monitoring Matters

A treatment plant can look normal during a walk-through while the data shows a developing problem.

Monitoring helps confirm:

- The plant is operating as intended.
- Treatment barriers are behaving consistently.
- Trends are not drifting unnoticed.
- Operators have records to support decision-making.
- Faults are escalated before they become service interruptions.

WTP COMPLIANCE AND MONITORING GUIDE

Common Monitoring Areas

Monitoring Area	Why It Matters	Owner-Level Concern
Flow	Shows whether water is moving through the plant as expected.	Sudden drop, surge or unexplained change.
Tank level	Shows storage and process balance.	Level not matching operating condition.
Turbidity	Indicates clarity and solids removal performance.	Persistent rise or unstable trend.
pH	Affects treatment chemistry and water stability.	Drift outside normal site band.
Disinfectant residual	Indicates ongoing disinfection presence.	Missing, falling or unstable residual.
Filter pressure	Shows changing filter condition.	Unusual pressure trend or rapid change.
Chemical usage	Helps identify abnormal dosing demand or supply issue.	Unexpected usage increase or decrease.
Alarm history	Shows whether issues are isolated or repeating.	Repeated, unclear or unresolved alarms.
Telemetry health	Confirms data and remote support are available.	Data gaps, communication loss, unreliable readings.

What Good Looks Like

Area	Good Condition	Escalate When
Readings	Stable and consistent with plant status.	Readings change sharply or contradict site observations.
Trends	Predictable over time.	A parameter drifts for several checks without explanation.
Alarms	Infrequent, understood and closed out.	Alarms repeat, remain active or are cleared without cause.
Records	Complete enough to reconstruct what happened.	Entries are missing, vague or inconsistent.
Operator response	Abnormal conditions are logged and notified.	Issues are carried forward without action.

Alarm Conditions In Plain Language

Alarm Pattern	Practical Meaning
One short alarm	May be a transient event; record and watch.
Repeated alarm	Pattern forming; needs review.
Persistent alarm	Treat as a fault until understood.
Alarm plus abnormal reading	Escalate promptly.
Alarm plus loss of telemetry	Escalate because remote visibility is reduced.

WTP COMPLIANCE AND MONITORING GUIDE

Sample Log Prompts

Use prompts such as:

- What changed since the last normal check?
- Which reading or alarm is affected?
- Is the issue isolated or repeated?
- What action was taken under the site procedure?
- Who was notified?
- What follow-up is required?

Escalation Triggers

Escalate to the responsible technical support person if:

- Multiple parameters drift at the same time.
- A critical alarm repeats.
- The plant cannot maintain stable operation.
- Monitoring data does not match what the operator sees on site.
- The cause of a water quality trend is unclear.
- The records show the same issue returning.

Owner Boundaries

Do not:

- Tune a plant using guesswork.
- Create operating limits from memory.
- Change alarm settings without proper review.
- Treat one acceptable reading as proof the system is healthy.
- Rely only on the SCADA screen without site checks.

Next Step

Monitoring data is only useful when it leads to a clear decision. If the data is unclear, incomplete, or showing repeated alarms, the plant needs review — and chasing the issue inside the operator team alone usually delays the answer.

PC Water Solution reviews WTP monitoring records, operator logs, alarm history and site observations together, so we can identify whether the issue is operational, mechanical, instrumentation-related, or needs further engineering input. The output is a clear next-action list, not a deferred problem.

Request a WTP compliance and monitoring review — call 1300 029 804, email info@pcwater.com.au, or visit pcwater.com.au.