



School: School of Electrical and Electronic Engineering

Week 10 – PN Junction Diodes

Learning Objectives




At the end of this lesson, you will be able to:

- Explain pn junction diode theory and operation mechanisms under different biasing conditions namely thermal equilibrium, forward bias and reverse bias
- Under different bias:
 - Draw the energy band diagram of the pn junction
 - Explain the concepts and determine the key parameters such as built-in voltage, depletion width, space charge, electric field, and junction capacitance
- Explain the concepts of injected minority carriers and current distributions, and calculation of electron and hole diffusion currents under different bias conditions
- Explain how useful capacitance versus voltage characteristics is to determine the built-in voltage and the impurity concentration in the semiconductor

Fundamentals of Semiconductors




- Semiconductors are mainly classified into two categories:
 - Intrinsic Is chemically very pure and possesses poor conductivity, and
 - Extrinsic Is an improved intrinsic semiconductor with a small amount of impurities which
 modifies its electrical properties and improves its conductivity.



Fundamentals of Semiconductors



- **P-type** The addition of trivalent impurities (Group III elements such as Boron) to an intrinsic silicon creates deficiencies of valence electrons, called **holes**.
- N-type The addition of pentavalent impurities (Group V elements such as Phosphorus)
 contributes free electrons.



Fundamentals of Semiconductors (Cont'd.)



- There are two basic transport mechanisms in a semiconductor crystal depending on the driving force:
 - Drift: movement of charge due to electric fields
 - Diffusion: flow of charge due to concentration gradients




Figure 1.4 Drift current


Figure 1.5 Diffusion current

Week 10 - PN Junction Diodes 5

Fundamentals of Semiconductors (Cont'd.)




- Some basic semiconductor devices are BJT, MOSFET, LED, laser, and photo-detectors.
 - Electronic devices: BJT, MOSFET
 - Optoelectronic devices: LED, laser, and photo-detectors




IBM's SiGe Bipolar Transistor



Intel's 65nm MOSFET



Red LED



Photodetector

Figure 1.6 Electronic devices

Figure 1.7 Optoelectronic devices

In this course, we will mainly deal with electronic devices.

Week 10 - PN Junction Diodes 6

PN Junction Diodes



• **PN junction** is a boundary or interface between two types of semiconductor material, p-type and n-type.



Figure 1.8 PN Junction

- PN junction serves an important role in:
 - Modern electronic and optoelectronic applications (used in rectification, switching, light emission and detection, and other operations) and
 - Understanding other semiconductor devices because it is the key building block for most of the devices, such as LEDs, photodetector, MOSFETs and BJTs, etc. as mentioned in previous slide.

Diode I-V Characteristics






Figure 1.9 Diode I-V Characteristics

- Forward bias: p-side positive, I increases exponentially with V
- Reverse bias: p-side negative, current nearly 0 till junction breakdown
- A PN junction allows current to flow easily in only one direction

(Equation 1.1)
$$I = I_s (e^{qV/kT} - 1)$$

where I_s is the reverse saturation current and V is the bias applied

P- and N-type Semiconductors



Assume the p-type semiconductor materials are uniformly doped.

p-type silicon


Doped by acceptors (Boron)

Majority carriers

(Equation 1.2)
$$p = N_A = n_i e^{\frac{E_1 - E_F}{kT}}$$

Minority carriers

(Equation 1.3)
$$n = \frac{n_i^2}{N_A}$$
 where $p \gg n$



$$E_C$$
 ———

$$E_F = ---- E_V = -----$$

P- and N-type Semiconductors



Assume the n-type semiconductor materials are uniformly doped.

n-type silicon


Doped by donors (Phosphorus)

Majority carriers

(Equation 1.4)
$$n = N_D = n_i e^{\frac{E_F - E_i}{kT}}$$

Minority carriers

(Equation 1.5)
$$p = \frac{n_i^2}{N_D}$$
 where $n \gg p$




 $\frac{\mathsf{n}}{----} E_{l}$

PN Junction Formation



• When p- and n-type semiconductors contact together, large carrier concentration gradients at the junction cause carrier diffusion (diffusion currents J_p and J_n).

Holes flow from left to right
$$J_p$$
 to right $J_p = -qD_p \frac{dp}{dx}$ (Equation 1.6)




(Equation 1.7)
$$J_n = -qD_n \frac{dn}{dx} \stackrel{\longleftarrow}{\longrightarrow}$$
 Electrons flow to left But electron current density J_n to right

PN Junction Formation (Cont'd.)



- As holes leave the p-side, some negative acceptor ions (N_A) near the junction are left uncompensated (since the acceptors are fixed in the semiconductor lattice while the holes are mobile).
- Similarly, some positive donor ions (N_D^+) are left as electrons leave n-side.




- Negative and positive space charges form a depletion region.
- They create an electrical field, ξ, directed from positive charges towards negative charges.

Week 10 - PN Junction Diodes 12

PN Junction Formation (Cont'd.)



• The electrical field creates two drift current components, $J_P(\text{drift})$ and $J_n(\text{drift})$, and in the directions opposite to the diffusion current components.



• At thermal equilibrium, (that is, the steady-state condition at a given temperature without any external excitation), the net electron and hole currents flowing across the junction are zero.

Week 10 - PN Junction Diodes 13

PN Junction Formation (Cont'd.)



• That is, each type of drift current must exactly cancel the diffusion current.

$$J_p = q \,\mu_p \,p\xi - qD_p \,\frac{dp}{dx} = 0 \qquad \qquad \text{(Equation 1.10)}$$

$$J_n = q \,\mu_n n \xi + q D_n \,\frac{dn}{dx} = 0 \qquad \qquad \text{(Equation 1.11)}$$

Where,

 $D_n(D_n)$ is the diffusion coefficient of holes (electrons),

 $\mu_p(\mu_n)$ is hole (electron) mobility,

P(n) is the hole (electron) concentration,

k is the Boltzmann constant, and


 ξ is the electrical field.

- $D = (kT/q)\mu$ is the Einstein relation.
- Hence in thermal equilibrium, $J = J_n + J_p = 0$.

Built-in Potential V_{bi}



Figure 1.11



$$\Psi_{p} \equiv -\frac{1}{q} (E_{i} - E_{F}) | x \le -x_{p} = -\frac{kT}{q} \ln \frac{N_{A}}{n_{i}} \text{ (Equation 1.12)} \qquad \Psi_{n} \equiv -\frac{1}{q} (E_{i} - E_{F}) | x \ge x_{n} = \frac{kT}{q} \ln \frac{N_{D}}{n_{i}} \text{ (Equation 1.13)}$$

• The total electrostatic potential difference between the p-side and n-side neutral regions at thermal equilibrium is called the **built-in potential** V_{bi} .

$$V_{bi} = \Psi_n - \Psi_p = \frac{kT}{q} \ln \frac{N_A N_D}{n_i^2}$$
 (Equation 1.14)

• Note that there is an energy band bending at junction due to V_{bi} . this "potential barrier" that prevents any further flow of electrons and holes under thermal equilibrium.

Depletion Width and Maximum Electric Field



Overall space charge neutrality requires:

$$N_A x_p = N_D x_n$$
 (Equation 1.15)

The total depletion layer width is given by:

$$W = x_p + x_n = \sqrt{\frac{2\varepsilon_s}{q} \left[\frac{N_A + N_D}{N_A N_D} \right] V_{bi}} \quad (Equation 1.16)$$

- The electric field can be found by solving the Poisson's equation: $d^2\phi(x)/dx_2 = -\rho(x)/\epsilon_s = -\,d\xi(x)/dx$ (Equation 1.17)
- This is equivalent to integrating the space charge density plot (a) which results in the electric field plot in (b).
- The maximum **electric field** ξ_m occurs at x=0 is given by: $\xi_m = \frac{qN_Dx_n}{\xi_S} = \frac{qN_A^{\ \ x}p}{\xi_S}$ (Equation 1.18)




Figure 1.12

One-sided Abrupt Junction

NANYANG TECHNOLOGICAL UNIVERSITY

- When the impurity concentration on one side of an abrupt junction is much higher than that of the other side, the junction is called a onesided abrupt junction, e.g., a p+-n junction.
- $x_p << x_n$, and the W can be simplified to:

$$W \approx x_n = \sqrt{\frac{2\varepsilon_s V_{bi}}{qN_D}}$$
 (Equation 1.19)

• The maximum electric field is $\xi_m = \frac{qN_BW}{\varepsilon_S}$ (Equation 1.20) where N_B is the lightly doped bulk concentration.





Figure 1.13

P-N Junction under Bias




Forward bias (V_F) :

• Depletion layer width becomes smaller.



• The total electrostatic potential becomes $V_{bi} - V_F$.




$$W_{FB} = \sqrt{\frac{2\varepsilon_s}{q} \left[\frac{N_A + N_D}{N_A N_D} \right] (V_{bi} - VF)} \quad (Equation 1.21)$$

P-N Junction under Bias




Reverse bias (V_R) :

Depletion layer width increased.




• The total electrostatic potential becomes $V_{bi} - V_R$.



$$W_{RB} = \sqrt{\frac{2\varepsilon_{s}}{q} \left[\frac{N_{A} + N_{D}}{N_{A} N_{D}} \right] (V_{bi} + |V_{R}|)}$$
 (Equation 1.22)



(a) Forward bias






Figure 1.14

Minority carriers concentration at depletion edges:

$$p_{n}(x=x_{n}) = P_{no}e^{qV_{F}/kT}$$
 (Equation 1.23a)

$$n_{p}(x=-x_{p}) = n_{po}e^{qV_{F}/kT}$$
 (Equation 1.23b)

Diffusion currents:


$$J_p(x) = -qD_p dp(x)/dx$$
 (Equation 1.24a)
 $J_n(x) = -qD_n dn(x)/dx$ (Equation 1.24b)

Hole and electron diffusion current densities at depletion edges:

$$I_{p}(x) = \left(\frac{qD_{p}p_{no}}{L_{p}}\right) \left[e^{qV_{F}/kT} - 1\right]$$
 (Equation 1.25a)
$$I_{n}(x) = \left(\frac{qD_{n}n_{po}}{L_{n}}\right) \left[e^{qV_{F}/kT} - 1\right]$$
 (Equation 1.25b)



(a) Forward bias



Total current density:

$$J = J_n(-x_p) + J_p(x_n) = \left(\frac{qD_p p_{no}}{L_p} + \frac{qD_p n_{po}}{L_n}\right) \left[e^{qV_F/kT} - 1\right]$$
 (Equation 1.26)

Under Forward bias:

$$J_{\rm F} \sim \left(\frac{qD_p p_{no}}{L_n} + \frac{qD_p n_{po}}{L_n}\right) \left[e^{qV_F/kT}\right] \text{ since } e^{qV_F/kT} >> 1 \quad (Equation 1.27)$$

Figure 1.15



(b) Reverse bias




Figure 1.16

Minority carriers concentration at depletion edges:

$$p_{n}(x=x_{n}) = P_{no}e^{-qV_{|R}|/kT}$$
 << p_{no} (Equation 1.28a)
 $n_{p}(x=-x_{p}) = n_{po}e^{-qV_{|R}|/kT}$ << n_{po} (Equation 1.28b)

Diffusion currents:

$$J_p(x) = -qD_p dp(x)/dx$$
 (Equation 1.29a)
 $J_n(x) = -qD_n dn(x)/dx$ (Equation 1.29b)

Hole and electron diffusion current densities at depletion edges:

$$I_{p}(x) = \left(\frac{qD_{p}p_{no}}{L_{p}}\right) \left[e^{-qV_{|R}|}/_{kT} - 1\right] \sim 0 \quad (Equation 1.30a)$$

$$I_{n}(x) = \left(\frac{qD_{n}n_{po}}{L_{n}}\right) \left[e^{-qV_{|R}|}/_{kT} - 1\right] \sim 0 \quad (Equation 1.30b)$$



(b) Reverse bias




Figure 1.17

Total current density:

$$J = J_n(-x_p) + J_p(x_n) = \left(\frac{qD_p p_{no}}{L_p} + \frac{qD_p n_{po}}{L_n}\right) \left[e^{-qV|R|}/_{kT} - 1\right] \sim 0 \text{ (Equation 1.31)}$$

Under Reverse bias:

$$J_{R} \sim -\left(\frac{qD_{p}p_{no}}{L_{p}} + \frac{qD_{p}n_{po}}{L_{n}}\right) = J_{sat} \sim 0 \text{ since } e^{-qV_{|R}|}/kT << 1$$
 (Equation 1.32)

Depletion Capacitance



 For one-sided abrupt junction, the depletion capacitance per unit area:

$$C_j = \frac{\varepsilon_S}{W} = \sqrt{\frac{q\varepsilon_S N_B}{2(V_{bi} - V)}}$$
 (Equation 1.33)

 ε_s is the dielectric constant of the semiconductor material and W is the total depletion width.


Or

$$\frac{1}{C_i^2} = \frac{2(V_{bi} - V)}{q\varepsilon_s N_B}$$
 (Equation 1.34)

- A plot of $1/Cj^2$ versus V produces a straight line for a one-sided abrupt junction.
- The slope links to the impurity concentration N_B and the intercept at $(1/Cj^2 = 0)$ gives V_{bi} .



 $C=\varepsilon/d$ (capacitance per unit area)



Lesson Summary



- It is important to understand the operation principles of PN junction as it is the basic building block for many other semiconductor devices.
- The key parameters of a PN junction are: built-in voltage (V_{bi}) , depletion width (W), space charge densities $(N_A x_p = N_D x_n)$, electric field(ξ) and depletion capacitance (C_i) .
- Under Forward Bias \Rightarrow V=V_{bi}-V_F W decreases, N_Ax_p and N_px_n decreases, ξ decreases and C_j increases.
- Under Reverse Bias \Rightarrow V=V_{bi}+|V_R|, W increases, N_Ax_p and N_px_n increases, ξ increases and C_j decreases.

Lesson Summary



- Under forward bias, minority carriers injection gives rise to diffusion currents I_p and I_n . The total current $I_T = I_p + I_n$ increases.
- Under reverse bias, minority carriers get depleted and the total current (or reverse saturation current) is very small.
- The capacitance versus voltage characteristics can be used to determine the built-in voltage (V_{bi}) and impurity concentration (N_B) in the semiconductor.

References



No.	Slide No.	Image	Reference
1.	6	SIGE HBT Cross Section (e.25gm SIGE BICKNOS) Enteron Control of Section (e.25gm SIGE BICKNOS) Enteron Enteron Control of Section (e.25gm SIGE BICKNOS) Enteron Enteron Control of Section (e.25gm SIGE BICKNOS) Enteron En	D. (n.d.). Status and Trends of SiGe BiCMOS Technology. Retrieved March 8, 2017, from http://asia.stanford.edu/events/spring01/slides/harame Slides.pdf
2.	6	Cets 50 ms.	90nm_transistor. (n.d.). Retrieved March 08, 2017, from http://www.ixbt.com/
3.	6		Optoelectronic Devices-Types, Applications, Threshold Frequency Define. (2014, July 09). Retrieved March 08, 2017, from http://www.circuitstoday.com/optoelectronic-devices


Week 10 - PN Junction Diodes

References



No.	Slide No.	Image	Reference
-----	-----------	-------	-----------

4. 6



Silicon-Germanium multi-quantum . (n.d.). Retrieved March 08, 2017, from http://imagebank.osa.org/