

Course: EE3013 Semiconductor Devices and Processing

School: School of Electrical and Electronic Engineering

Lithography 3 – Lithography Technology

Disclaimer



The preceding/ following videos contain slides with materials that were originally used for delivery in lecture halls and/ or classrooms in Nanyang Technological University. They might contain adapted materials. While every effort has been made to undertake due diligence to identify the original source, this was not always possible for all materials. The videos are used solely for educational purposes to support the Technology-Enhanced Learning (TEL) aspects of the course. TEL is hosted and deployed in NTULearn and i-NTULearn, a learning management system accessed by students at NTU assigned with a user ID and password. This disclaimer states that no copyright infringement was intended. Should any disagreement or dispute arise, including any claims to rightful ownership, kindly contact CITS, NTU, at +65 6790 5231.

Lithography Technology – Lesson Overview



Lithography technology:


- Lithography equipment
- Resolution and its critical parameters
- Mask and reticle



Lithography Equipment

Lithography Equipment – Aligners





UV Exposure - Printing




UV exposure is sometimes known as "printing" because it "prints" the desired pattern onto the substrate using UV source.


Three Basic UV Exposure Methods

Coptical System Mask Photoresist Si Wafer

Single Exposure




Multiple Exposures



Contact Printing


Lithography Equipment: Single and Multiple Exposure





Single Exposure

- Contact Aligner/ Printer
- Proximity Aligner/ Printer




Multiple Exposure

Step-and-Repeat Aligner (Stepper)

Contact and Proximity Aligners






Proximity Printing mask and wafer in close proximity (a small gap of 10-50µm between mask and wafer), less damage by dust particles, the low resolution of the order of 2-5µm due to the fringe.

Multiple Exposure: Step and Repeat Printing








Single Field Exposure:

Includes focus, align, expose, step, and repeat process

Wafer stage controls the position of the wafer in X, Y, Z, and θ

Contact/ Proximity Aligner






Used with permission from Canon USA,

Step-and-Repeat Projection Aligner







Resolution and its Critical Parameters

Resolution



The ability of an optical system to distinguish closely spaced objects.











More challenging to distinguish small pattern.

Minimum Linewidth/ Resolution for Proximity Aligner



- Resolution is the minimum linewidth achievable by the lithography equipment.
- Minimum linewidth (Resolution) for the proximity printer:


$$W_{min} \approx \sqrt{k_1 \lambda g}$$

 $k_1 = Constant$

 λ = Wavelength of the exposure source

g = Gap between the mask and the wafer surface (in the range of μm)

 k_1 factor has no well-defined physical meaning. It is an experimental parameter, depends on the lithography system and resist properties. Typical values are close to 1.



carefully

Practice Question 1



Determine the maximum allowable proximity gap for near and deep UV sources as a function of the feature size. $(k_1 = 1)$

Near UV: $\lambda = 0.405 \,\mu m$ Deep UV: $\lambda = 0.248 \,\mu m$ (Linewidth) $W_{min} \approx \sqrt{k_1 \lambda g}$



Linewidth (µm)	Maximum Gap for Near UV Source (μm)	Maximum Gap for Deep UV Source (μm)
2.5	15.43	25.2
2.0	9.88	16.13
1.0	2.47	4.03
0.5	0.62	1.01

- As feature size decreases, the maximum allowable gap decreases.
- A **light source of lower wavelength** is better to overcome the above constraints in the maximum allowable gap.


Minimum Linewidth/ Resolution for Projection Aligner



- In projection aligner (also called step-and-repeat aligners), the gap between mask and wafer is very large (in the range of cm).
- Minimum linewidth (resolution) for the projection printer can be calculated using:

$$W_{min} \approx k_1 \frac{\lambda}{NA}$$

Where NA is called the numerical aperture.



Projection Printing



Numerical Aperture

NANYANG TECHNOLOGICAL UNIVERSITY

- The numerical aperture (NA) of an optical system is a measure of the ability to collect light, which is a measure of the light gathering power.
- Numerical Aperture, (NA) can be defined as:

$$NA = n \sin \theta$$


Where n= refraction index (the medium in which the system is immersed, in this n=1 for air), and $\theta=$ one half the angle of acceptance of the objective lens.

When n = 1, the NA can be defined as

$$NA = \sin \theta \approx \tan \theta = \frac{d/2}{f} = \frac{d}{2f}$$


 $\tan \theta \simeq \sin \theta$ since θ is less than 12°

NA for projector objective is also the geometrical ratio between aperture and focal length.



Effect of Numerical Aperture on Imaging





Typical NA Values for Photolithography Tools



Type of Equipment	NA Value
Step-and-Repeat	0.60 - 0.68

Practice Question 2




A step-and-repeat aligner has an NA value of 0.6. By assuming $k_1=1$, which of the followings is/ are the most suitable UV source(s) to achieve resolution of **0.62 µm**?



Pause and try out this question







$$W_{min} \approx k_1 \frac{\lambda}{NA}$$

- The obtained λ value is 372 nm. UV sources with wavelengths smaller than 372 nm can be used. Both i-line and DUV can achieve such resolution.
- DUV has a lower intensity.
- Excimer laser which has a higher intensity can be used.

Lithography on Uneven Surface








Depth of focus: Range of focus error that a process can tolerate.

Depth of Focus – How to Deal With It?





Depth of focus:

$$\sigma = \pm \frac{w_{min/2}}{\tan \theta} \cong \pm \frac{k\lambda/2NA}{\sin \theta}$$



$$\sigma = \pm \frac{k\lambda/2NA}{NA/n} \cong \pm \frac{k_2\lambda}{(NA)^2}$$

 $\tan \theta \sim \sin \theta$ for $\theta < 12^{\circ}$

k and k_2 are constant, n = 1 (for air)

Again, like the case of resolution, we used k_2 factor as an experimental parameter. It has no well-defined physical meaning.

Depth of Focus for Projection Photolithography



$$DOF = \delta = \pm k_2 \frac{\lambda}{(NA)^2}$$

- Large NA gives smaller depth of focus.
- This is also true for the camera. A cheap camera takes photos that are always in focus no matter where the subject is. This is because it has small lenses.




Small DOF (Background Blurred) What one need here is a telephoto lens at its widest aperture.



Large DOF

A small aperture was used to ensure the foreground stones were as sharp as the ones in the distance.



Large Lens (Large NA), Small DOF


Small Lens (Small NA), Large DOF

Practice Question 3



We need to perform lithography patterning on a structure illustrated below using a stepand-repeat aligner (NA = 0.6, $k_2 = 1$). The exposure source is excimer laser (248 nm). To obtain a sharp image, what is the maximum thickness of the SiO₂ layer?





$$\sigma = \frac{k_2 \lambda}{(NA)^2}$$

$$\sigma = 688 \text{ nm}$$

Since titanium has a thickness of 44 nm, the total thickness of titanium and SiO_2 should not exceed 688 nm. Therefore, the SiO_2 layer should be \leq 600 nm.




Mask and Reticle

Mask and Reticle for Lithography




Mask
Single Exposure:
1:1 Mask



Pattern for a Complete Wafer






Reticle Multiple Exposure: Reticle (Typically 4:1) **Pattern for Only** Part of the Wafer **Reduced Size Pattern Achieve Higher** resolution **Reduction Stepper**

Mask and Reticle – Required Properties



- Flat and highly polished
- One surface of glass is patterned with opaque chromium
- High degree of transparency for optimal usage,
 better exposure, higher transmitted power to PR



Lithography Technology – Summary



Lithography technology:

- Lithography aligners can be single exposure or multiple exposures.
- The resolution of lithography determines the smallest feature size it can print, whereas the depth of focus determines the range of tolerable focus error.
- Masks are used in single exposure aligners, whereas reticles are used in multiple exposure aligners.