## ΕΘΝΙΚΌ ΜΕΤΣΟΒΙΟ ΠΟΛΥΤΕΧΝΕΙΟ ΣΧΟΛΗ ΗΛΕΚΤΡΟΛΟΓΩΝ ΜΗΧΑΝΙΚΩΝ ΚΑΙ ΜΗΧΑΝΙΚΩΝ ΥΠΟΛΟΓΙΣΤΩΝ

Συστήματα Μιχροϋπολογιστών 3η Ομάδα Ασκήσεων

> Αναστάσιος Λαγός - el13531 Κωνσταντίνος Βασιλάχης - el16504

Ο κώδικας είναι ο παρακάτω

```
DATA: MVI A,10H; Only middle segs should display
STA OBOOH
STA OBO1H
STA OBO4H
STA OBO5H
LXI B,0064H
MVI A,ODH
                        ; Unmask RST6.5 - Mask RST7.5, RST5.5
SIM
LXI D,OBOOH
                        ;Load address of digits for 7-seg display
ΕI
RESET1:
CALL BLNK
MVI A, FFH
OUT 30H
WAIT_LOOP:
                        ; Waiting for interrupt
JMP WAIT_LOOP
INTR_ROUTINE:
POP H
                        ;Don't need to return
MVI A,00H
                        ;Light LEDs
OUT 30H
LXI B,0064H
                        ;100ms
LXI D, OBOOH
                        ;Load address of digits for 7-seg display
RESET_TIMER:
LXI H,0600H
SHLD OBO2H
CALL DISPLAY_SEG
DECIMAL_CHECK:
MOV A,L
CPI OOH
              ; If L = 0 then we need to DCR the decimals.
JZ DCR_DECIMAL
DCR L
                       ;Else DCR L
SHLD OBO2H
CALL DISPLAY_SEG
JMP DECIMAL_CHECK
DCR_DECIMAL:
DCR H
MOV A, H
CPI OOH
               ; If H = 0 then we reached the final countdown.
MVI L,09H
SHLD OBO2H
```

```
CALL DISPLAY_SEG
JZ END_COND
JMP DECIMAL_CHECK
DISPLAY_SEG:
                      ; Routine that displays timer on screen
PUSH PSW
                       ; Need to store 8085 current state
                        ;to call STDM and DCD
PUSH H
PUSH D
PUSH B
CALL STDM
MVI A,OAH
                       ;10 * 100ms = 1 sec of displaying the
                        ; number on the screen
DISPLAY_LOOP:
                        ; If pair BC is loaded with 03E8 and we just
                       ; CALL DELB without looping the call to DCD
CALL DCD
                       ; then the numbers appear on the screen for
                       ; a brief moment before disappearing
POP B
CALL DELB
                      ; Note: 1 sec varies cause simulation
PUSH B
DCR A
CPI OOH
JNZ DISPLAY_LOOP
POP B
                       ;Retrive 8085 status
POP D
POP H
POP PSW
RET
END_COND:
                       ; If decimal is 0 then count down from 9
                        ; and be done.
MOV A,L
CPI OOH
DCR L
SHLD OBO2H
CALL DISPLAY_SEG
JNZ END_COND
JMP RESET1
END
```

Ο κώδικας είναι ο παρακάτω

```
EQU K1_VALUE, 10H
EQU K2_VALUE, 20H
START:
    ; Enable Rst 6.5 interrupt
   MVI A,ODH
   SIM
    ΕI
; Wait for the interrupt to happen
WAIT_INTR:
    JMP WAIT_INTR
INTR_ROUTINE:
   ; Save register state. HL are not used so
    ; they are not stored in the stack
   PUSH PSW
    PUSH B
    PUSH D
    LXI D,0B50H
                ; Arbitrary memory address we write
                    ; the screen data
    ; Get the first input and write it to the memory
    ; location OB50H (1st digit on the screen)
    CALL KIND
    MOV C, A
    STA OB50H
    ; Get the second input and write it to the memory
    ; location OB51H (2nd digit on the screen)
    CALL KIND
    STA OB51H
    ; Combine the second input (4 MSB) with the first (4 LSB) store
    ; it on C
    RLC
    RLC
    RLC
    RLC
    ADD C
    MOV C, A
    ; Make the rest of the screen bits zero
    MVI A,00H
    STA OB52H
    STA OB53H
    STA OB54H
```

```
STA OB55H
    ; Display the two inputs on the screen
    CALL STDM
    CALL DCD
    ; Get the combined 8 bit number
    MOV A,C
    STA OB26H
   MVI D, K1_VALUE
   MVI E, K2_VALUE
    ; Increase the value so the first and second intervals are
    ; K1 and K2 inclusive respectively
    INR D
    INR E
    ; Right led if for (0,K1]
   MVI B,01H
    CMP D
    JC SWITCH_LEDS_ON
    ; Middle led is for (K1,K2]
   MVI B,02H
    CMP E
    JC SWITCH_LEDS_ON
    ; Left led is for (K2,FFH)
   MVI B,04H
SWITCH_LEDS_ON:
   MOV A,B
    CMA
    STA 3000H
    ΕI
    ; Load previous register state
    POP B
    POP D
   POP PSW
    RET
END
```

#### $\alpha$ )

Η παραχάτω μαχροεντολή δουλεύει ως εξής. Αποθηχεύσει τον Α και τα flags στην στοίβα. Μεταφέρει τον Q στον Α και τον περιστρέφει 4 φορές και μετά τον αποθηχεύει πάλι πίσω στον Q. Αντίστοιχα αποθηχεύει τα περιεχόμενα του HL στον Α τα περιστρέφει 4 φορές και τα σώνει πάλι στην ίδια διεύθυνση. Τέλος αναχτά από την στοίβα τις αποθηχευμένες τιμές του Α και των flags.

```
SWAP Nimble MACRO Q
PUSH PSW
MOV A,Q
RLC
R.L.C
RLC
RLC
MOV Q,A
MOV A, M
RRC
RRC
RRC
RRC
MOV M, A
POP PSW
ENDM
```

### β)

Στην παρακάτω μαρκοεντολή αποθηκεύουμε τα περιεχόμενα των flags, A και Η στην στοίβα. Τοποθετούμε τον αριθμό των στοιχείων που θέλουμε να κάνουμε ίσα με Κ στον Α και μεταφέρουμε στο HL τις τιμές του RP. Γράφουμε Κ σε αυτήν τη θέση μνήμης και με ένα loop αυξάνουμε την θέση μνήμης κατά ένα και αφαιρούμε ένα από τον counter X που είναι στον Α μέχρι να γράψουμε τις απαιτούμενες τιμές. Τέλος ανακτάμε από την στοίβα τα H,Α και flags.

```
FILL MACRO RP,X,K

PUSH PSW
PUSH H

MOV A,X

MOV H,R

MOV L,P

LOOP:
```

```
MVI M,K
INR M
DCR A
JNZ LOOP
POP H
POP PSW
ENDM
```

### $\gamma$ )

Στην παρακάτω μαρκοεντολή αρχικά αποθηκεύουμε στην στοίβα τον A και flags. Κάνουμε με την σειρά ένα δεξιό rotate μέσα από το carry τον B και μετά τον B όσες φορές έχει επιλεγεί. Στο τέλος ο B έχει τις shifted τιμές και ο καταχωρητής B έχει την τιμή του carry.

```
RHLR MACRO n
PUSH PSW
MOV B,n
LOOP:
MOV A,B
CPI 00H
JZ STOP
MOV A,H
RAR
MOV H,A
MOV A,L
RAR
MOV L,A
DCR B
JMP LOOP
STOP:
JC STORE
MVI B,00H
JMP ENDING
STORE:
MVI B,01H
ENDING:
POP PSW
ENDM
```

Ο 8085 ως απάντηση σε μια διαχοπή αρχιχά ολοχληρώνει την τρέχουσα εντολή (CALL 0880H). Πριν την ολοχληρώσει οι PC,SP και η stack φαίνονται στην πρώτη στήλη. Με την εκτέλεση της CALL 0880H αποθυκεύεται στην stack το προηγούμενο PC και η κατάσταση του μΕ (PUSH PSW) ενώ το PC γίνεται 0880, όπως στην δεύτερη στήλη. Εδώ γίνεται η αναγνώριση της συσκευής που προχάλεσε την διαχοπή και αν υπήρχαν πολλαπλές διαχοπές η εκτέλεση του ISR θα γινόνταν με βάση την προτεραιότητα TRAP -> RST7.5 -> RST6.5 -> RST5.5. Όμως έχουμε μια διαχοπή οπότε απλώς θα εκτελεστεί η ISR. Στην συνέχεια θα αποθυκευτεί στην stack το PC και έπειτα θα μεταβεί στην διεύθυνση της υπορουτίνας της εκάστοτε διαχοπής. Στην συγκεκριμένη περίπτωση στην διεύθυνση 003C.Εδώ θα γίνει πάλι αποθύκευση της κατάστασης του μΕ και των καταχωρητων (B,C,D,E,H,L) στην stack.Θα εκτελεστεί το κύριο σώμα της ρουτίνας εξυπηρέτησης, θα ελευθερωθούν από την stack το PSW και οι καταχωρητές, θα γίνει επίτρεψη νέων διαχοπών και εν συνεχεία το PC θα επιστρέψει στην διεύθυνση που βρισκόταν πριν την διαχοπή(0880). Αντίστοιχα και για την εκτέλεση της ρουτίνας στην θέση 0880.

PC	0800	0880	003C
SP	00	PSW	80
SP + 1	30	00	08
SP + 2		08	PSW
SP + 3		00	00
SP + 4		30	08
SP + 5			00
SP + 6			30

#### $\alpha$ )

Στον παρακάτω κώδια περιμένουμε ένα interrupt 6.5. Όταν έρθει ανάλογα αν έχουμε LSB ή MSB στην είσοδο (το βρίσκουμε ανάλογα με το αν το counter που έχουμε είναι μονό ή ζυγό αφού αυτά έρχονται εναλλάξ) τα προσθέτουμε σε ένα ολικό άθροισμα στο HL επειδή οι αριθμοί είναι 8bit οπότε το συνολικό άθροισμα μπορεί να ξεπεράσει τα 8 bit. Στο τέλος διαιρούμε με 32 κάνοντας 4 shift right του HL. Το τελικό αποτέλεσμα θα βρίσκεται στον L. Γενικά στον παρακάτω κώδικα αφού η διακοπή μπορεί να γίνει οποτεδήποτε σώνουμε τα δεδομένα για ασφάλεια στην μνήμη μεταξύ των διακοπών και τα ανακτάμαι από εκεί για την επεξεργασία.

```
START:
   ; Store in memory the counter at OB10H and
   ; the current 16 bit sum in OB11H,OB12H to
   ; retrieve them between interrupts
    ; Counter starts from 64 = 40H
   MVI A,40H
    STA OB10H
    ; Sum starts from 0
   MVI A,00H
    STA OB11H
    STA OB12H
    ; Enable Rst 6.5 interrupt
    MVI A,ODH
    SIM
    ET
; Wait for the interrupt to happen
WAIT_INTR:
    JMP WAIT_INTR
RST6.5:
   ; Save register state
   PUSH PSW
   PUSH B
   PUSH D
    PUSH H
    JMP RST6.5_ROUTINE
    ; Load previous register state
    POP PSW
    POP B
    POP D
    POP H
RST6.5_ROUTINE:
    IN 20H ; Get input to A
```

```
ANI OFH
             ; Keep the 4 LSB
    MOV C,A
    ; Load Current Counter and save it to D
    LDA OB10H
    MOV D,A
    ; If it is even it is LSB bytes so no shift
    ; is needed
    ANI O1H
    CPI 01H
    JZ ADD_RESULTS
GET_4_MSB:
    MOV A, C
    RLC
    RLC
    RLC
    RLC
    MOV C,A
ADD_RESULTS:
   ; Load Current Sum
   LHLD OB11H
    ; 16 bit addition of BC to HL
    ; C containes the new bytes
   MVI B,00H
   DAD B
    ; Decrease the counter
    DCR D
    JZ FIND_MEAN
    ; If counter is not yet 0 update it in
    ; memory along with the current sum and
    ; return waiting for the next interrupt
    MOV A,D
    STA OB10H
    SHLD OB11H
    ΕI
    RET
FIND_MEAN:
   ; We shift 4 times to the right the register HL
    ; in order to divide the sum of the 32 numbers
    ; by 32 and find the mean value. We first set
    ; the carry to 0 and we rotate right the H and
    ; then the L registers. We do this 4 times
    STC
    CMC
   MOV A,H
    RAL
    MOV H, A
    MOV A,L
    RAL
    MOV L, A
```

```
STC
    CMC
    MOV A, H
    RAL
    MOV H,A
    MOV A,L
    RAL
    MOV L, A
    STC
    CMC
    MOV A, H
    RAL
    MOV H, A
    MOV A,L
    RAL
    MOV L, A
    STC
    \texttt{CMC}
    MOV A, H
    RAL
    MOV H,A
    MOV A,L
    RAL
    MOV L,A
    ; The result is in L. We also store it
    ; in OB13H and finish the program
    MOV A,L
    LDA OB13H
    ; Load previous register state
    POP PSW
    POP B
    POP D
    POP H
END
```

### β)

Ο παρακάτω κώδικας είναι παρόμοιος με αυτόν του ερωτήματος α. Έχουν αφαιρεθεί οι διακοπές και στην θέση τους έχει μπει μία λογική που ελέγχει αν έχουμε μετάβαση από 0 σε ένα στο x7. Αν ναι κάνουμε ένα κύκλο επεξεργασίας αλλιώς συνεχίζουμε το loop. Επίσης έχουν αφαιρεθεί οι αποθηκεύσεις στην μνήμη αφου τώρα το πρόγραμμα θα τρέξει συνεχόμενα και αν μία διακοπή ή άλλη διεργασία αναλάβει τον έλεγχο θα πρέπει να αποθηκεύσει τα δεδομένα στο stack πρώτα και να τα ανακτήσει όταν επιστρέψει.

```
; Initialization of counter in D and sum in HL
   MVI D,40H
   MVI H,00H
   MVI L,00H
    ; C has the new bytes
   MVI C,00H
    ; E has the previous x7 value
    MVI E,00H
   MVI B,00H
PROCESS_DATA:
    ; Update previous x7 value
    MOV E,B
    IN 20H
              ; Get input to A
    ; Temporarily store A to C
   MOV C,A
    ANI 80H
    ; Temporarily store current x7 value to B
    MOV B, A
    CPI 01H
    ; If x7 = 0 continue looping
    JNZ PROCESS_DATA
    ; If x7 = 1 check x7 previous value
    ; stored in E
   MOV A,E
    CPI OOH
    ; If previous value is also 1 continue looping
    ; else process new data
    JNZ PROCESS_DATA
CONTINUE_PROCESSING:
    MOV A, C
    ANI OFH
              ; Keep the 4 LSB
    MOV C,A
    ; If it is even it is LSB bytes so no shift
    ; is needed
    ANI O1H
    CPI 01H
    JZ ADD_RESULTS
GET_4_MSB:
   MOV A,C
    RLC
    RLC
   RLC
   RLC
   MOV C, A
ADD_RESULTS:
    ; 16 bit addition of BC to HL
    ; C containes the new bytes
```

```
MVI B,00H
    DAD B
    ; Decrease the counter
    DCR D
    JZ FIND_MEAN
    ; If counter is not yet 0 update loop
    JMP PROCESS_DATA
FIND_MEAN:
   ; We shift 4 times to the right the register HL
    ; in order to divide the sum of the 32\ \text{numbers}
   ; by 32 and find the mean value. We first set
    ; the carry to 0 and we rotate right the H and
    ; then the L registers. We do this 4 times
    STC
    CMC
    MOV A,H
    RAL
    MOV H,A
    MOV A,L
    RAL
    MOV L, A
    STC
    CMC
    MOV A,H
    RAL
    MOV H,A
    MOV A,L
    RAL
    MOV L,A
    STC
    CMC
    MOV A,H
    RAL
    MOV H, A
    MOV A,L
    RAL
    MOV L,A
    STC
    CMC
    MOV A,H
    RAL
    MOV H, A
    MOV A,L
    RAL
    MOV L,A
    ; The result is in L. We also store it
    ; in OB13H and finish the program
    MOV A,L
    LDA OB13H
END
```