Suitable for age 6 and above

SMART DOG
MULTIFUNCTIONAL TOY

specification

TIP: PLEASE DO NOT OPERATE ON THE CARPET, SO AS NOT TO COMPLETE THE ACTION.

⚠Warning:

* Please follow the instructions or packaging instructions for proper installation and use. Some parts are assembled by adults.
* The product contains small parts that may pose a risk of ingestion or suffocation.
* Please put away the packaging materials in time to avoid harm to children.
* It is necessary to check the charger, wire, plug, housing and other parts regularly. If it is found to be damaged, it should be stopped until it is repaired..
* The charger, battery case and other charging devices should be plugged into the specified power supply as indicated on the product.
* Only the original charger can be used, the charger is not a toy.
* Non-rechargeable batteries are not rechargeable.
* The toy should be disconnected from the charger before cleaning.
* Do not mix old and new batteries or different types of batteries, exhausted batteries should be taken out in time.
* Do not short-circuit, disintegrate, drop or put the battery into a fire.
* If you do not control the product for a long time, please remove the battery.
* To avoid personal injury, do not touch rotating parts with your hands.
* Users have the responsibility to ensure that the product will not cause harm to themselves or others, due to improper operation of their own or others safety and property damage, manufacturers and dealers shall not assume any responsibility.
* This package and instruction manual contain important product information, please keep it.

Charging and switching introduction:



Includes 600mAh 3.7V 13A rechargeable lithium battery

Switch:

First turn the switch button at the bottom to the power position, then the pet will have a sound prompt.If there is no remote control for a long time, the pet will power off by itself, and it needs to be turned back on when playing again.

Charging instructions:

1. Insert the TYPE-C connector of the charging cable into the charging port on the body.
2. Insert the other end of the charging cable into the USB charging connector. The charging light on the body is red, indicating that the charging state is in.
3. About 1.5 hours of charging, the charging light of the fuselage is off, indicating that the charging is complete, please disconnect all connections and put in a safe position.

Note on the use of lithium batteries:

A. When charging, personnel should not leave and the charging time is not easy to be too long. If the battery is found hot during the charging process, please stop charging immediately to avoid battery damage or fire.
B. Do not put the battery next to flammable and explosive items to charge, when the battery in use or charging process once the smell or battery sudden heat, deformation, discoloration and other abnormal phenomena, please immediately stop using the battery.
C. If the battery leaks, avoid liquid contact with skin and eyes. In case of contact with skin or eyes, rinse immediately with plenty of cold water and seek medical attention immediately.
D. Only use the original charger to charge the product, and make sure that the voltage of the charger meets your local standards.
E. Do not put the battery in the fire, microwave oven or pressure canner.
F. Do not use solvents, industrial alcohol or other flammable solvents to clean the product and charger.
G. The product contains plastic, electronic components and batteries, do not treat such items as daily garbage disposal, please follow the local garbage recycling requirements, separate and dispose.

Remote control introduction:

Use a screwdriver to unscrew the back cover of the remote control, install the battery in the correct positive and negative directions, and then install the battery cover
Remote control uses 3 1.5 "AAA" batteries (required)

BATTERY PRECAUTIONS

1. The smart dog uses a non-replaceable 3.7V lithium battery, and the remote control uses three 1.5V "AAA" non-rechargeable batteries;
2. The battery should be taken out and loaded correctly according to the polarity and voltage signs on the toy battery room, and the battery should not be short-circuited;
3. Non-rechargeable batteries cannot be charged;
4. Rechargeable batteries must be charged under adult supervision;
5. When the rechargeable battery is charging, the toy switch should be turned off;
6. Different types of batteries or old and new batteries can not be mixed;
7. Only batteries with the same or equivalent recommended battery can be used;
8. The exhausted battery should be removed from the toy. If it is not used for a long time, please remove the battery from the toy.
9. Do not short circuit the power terminal;
10. Do not connect to more than the recommended amount of power supply. USB cable in the process of use, should regularly check its wire, plug, If the shell and other parts are damaged, the use should be stopped when the damage is found until the repair is complete.

Smart dog function introduction:

Press the button of the remote control and the pet will act accordingly.

1. Basic functions -- forward, left, right turn
2. Action - swimming sit down to act petulant handstand push up patrol shake hands pee attack hello sleep programming surrender
3. Entertainment -- Kung fu dance chat story songs



APP Download:

Scan the QR code below to download the APP

You can also search for the URL on the website to download
http://yw.cy979.com/site-dis-dl.php?app_id=18

APP function introduction:



1. After the download is complete, tap the APP icon to enter.
2. After entering the home screen, you can select the Chinese and English voice switch in the Settings, the default Chinese. Then click the - Start button to enter.
3. Select the purchased product.

Function introduction:

The APP has 5 functions ----

1. Voice command 2. Feeding 3. Control 4. Programming 5. Content



Voice command introduction:

Press the microphone button on the screen, speak the command in "English", and the pet will make the corresponding action. Motion and entertainment on the remote controller can be controlled by voice.

Voice command: forward. turn left. turn right. stop. swimming. sit down. greetings. get down. act cute. handshake. attack. surrender. urinate. somersault handstand. patrol. kungfu. push-up. dance. story. music songs. sleep.

Special reminder: If the surrounding environment is too noisy, or the instruction is not correct, there is no text in the prompt box, you will not make an action.



Control, content interface introduction:

Click a button on the interface with your finger, and the pet will act accordingly.



Feeding interface introduction:

Click the food icon on the interface with your finger, and the pet will eat the corresponding food.



Programming interface introduction:

1. After entering the programming interface, (Figure 1) select the action of the foot that you want the pet to do
2. After completing the modeling to be performed by each foot, click the following action to save (Figure 2), and then program the next action.
3. If you are not satisfied with the programming of the action, you can click the action empty (Figure 3) to rearrange the action.
4. After the action programming is completed, click Execute (Figure 4), and the pet will act according to the action you programmed.



Figure1



Figure2



Figure3



Figure4

APP DOWNLOAD METHOD

1.FIRST SCAN THE QR CODE AND ENTER THE DOWNLOAD WEBSITE.

ANDROID

Download on the App Store

TWO KINDS OF SYSTEM MOBILE APP
UNIVERSAL DOWNLOAD

2.AFTER ENTERING THE WEBSITE, CLICK THE ICON TO DOWNLOAD THE APP.

3.CLICK INSTALL AND WAIT FOR THE INSTALLATION TO COMPLETE.

4.AFTER THE INSTALLATION IS COMPLETE, CLICK THE ICON TO ENTER THE APP OPERATION INTERFACE.