GMMK Pro Cheatsheet

7/20/2022

Basic Shortcuts

Key Combo	Function
Capslock (hold)	Numpad (while held)*
Capslock (double tap)	Numpad layer toggle*
L+R Shift	Capitalize next word only
Left Shift (double tap)	Capslock
Fn + P	Paddle Game (toggle)
Shift + Backspace	Insert*
Fn + PGUP	Home
Fn + PGDN	End
Fn + Winkey	WinKey lock out (for gaming)
FN + [or]	Move active window to next monitor
Fn + .	Macro: ".com"
Fn + G	Macro: "gmail.com"
Fn + O	Macro: "outlook.com"
Fn + H	Macro: "hotmail.com"
Fn + Y	Macro: "yahoo.com"

Fn-Function Key Shortcuts

Function
My Computer
Open new browser tab
Calculator
My Music
Media Previous track
Media Next track
Media Play
Media Stop
Volume Down
Volume Up
Print Screen
Scroll Lock
Pause

^{* =} Customizable function -- see Advanced Toggles

Numpad Layer

Key Combo	Function
M,J,K,L,U,I,O,7,8,9,0	0,1,2,3,4,5,6,7,8,9,0
Space or Enter	Enter (numpad)
P or +	Add (+)
-	Subtract (-)
;	Multiply (*)
,	00
	Decimal
/	Divide (/)
W,A,S,D	Arrow keys
Arrow keys	Mouse movement
Right Shift	Mouse button 1
End	Mouse button 2
Right CTRL	Mouse button 3

RGB Functionality

Key Combo	Function
Fn + - or =	RGB backlight timeout up/down
Fn + Z	RGB night mode (backlight off)
Fn + A or D	RGB hue up/down
Fn + Q or E	RGB saturation up/down
Fn + W or S	RGB value (brightness) up/down
Fn + Up or Down	RGB effect next/previous
Fn + Left or Right	RGB animation slower/faster
Fn + Del	RGB sleep (until next keystroke)

Rotary Encoder

Key Combo	Function
Rotate	Volume Up/Dn (paddle in Game)
Push	Mute*
LShift + Rotate	Cycle layers
RShift + Rotate	PgUp/PgDn
LCtrl + Rotate	Navigate prev/next word
RCtrl + Rotate	RGB hue up/down
LAlt-Rotate	Media prev/next track
Fn + Push	Sleep PC

Advanced Functions

Key Combo	Function
Esc (double tap)	Revert to BASE layer*
Fn + L	Lock PC
Fn + /	Ctrl-Alt-Delete
Fn + N	System Numlock toggle
Fn + Push encoder	Sleep PC
Fn + R	NKRO toggle
Fn + Esc	Clear EEPROM
Fn + \ or Fn + B	Bootloader mode

Advanced Toggles

Key Combo	Function
Fn + `(tilde)	Print toggle statuses (in text editor)
Fn + 1	CapsLock RGB highlight alpha keys
Fn + 2	Numpad RGB highlight layer keys
Fn + 3	Dbl-tap ESC to revert to BASE layer
Fn + 4	Swap DEL & HOME key locations

key Combo	Function
Fn + 5	Numpad on CapsLock (double tap LSHIFT for CapsLock) or Standard CapsLock
Fn + 6	Encoder button functions as Mute or Media Play/Pause
Fn + 7	Insert function accessed with [SHIFT]-[BKSPC] or [SHIFT]-[DEL]
Fn + 8	Force SHIFT- & CTRL-SPACE to function like standard SPACE
Fn + 9	Toggle AutoCorrect