GMMK Pro Cheatsheet

Feb 4, 2022

Shortcuts

5110110413		
Key Combo	Function	
Capslock	Hold = numpad; Double tap = numpad toggle	
Left Shift	Double press = Capslock	
Shift + Backspace	Insert	
Invader (F13)	Home	
Fn + PGUP	Home	
Fn + PGDN	End	
Fn + Winkey	Windows key locked out (for gaming)	
Fn + N	Numlock (system)	
Fn + I	Scroll Lock	
Fn + U	Print Screen	
Fn + P	Pause	
Fn + Space	Backspace	
Fn + \	Bootloader mode	

Function Key Row

Key Combo	Function	
Fn + F1	My Computer	
Fn + F2	Open new browser tab	
Fn + F3	Calculator	
Fn + F4	My Music	
Fn + F5	Media Previous track	
Fn + F6	Media Next track	
Fn + F7	Media Play	
Fn + F8	Media Stop	
Fn + F9	Volume Down	
Fn + F10	Volume Up	
Fn + F11	Print Screen	
Fn + F12	Scroll Lock	
Fn + Invader	Pause	

RGB Functionality

Fn + , or .	RGB lights timeout up/down
Fn + Z	RGB night mode
Fn + A or D	RGB hue up/down
Fn + Q or E	RGB saturation up/down
Fn + W or S	RGB value (brightness) up/down
Fn + Up or Down	RGB effect next/previous
Fn + Left or Right	RGB animation slower/faster
Fn + Home	RGB temporary off

Rotary Encoder

LShift + Encoder	Cycle layers
RShift + Encoder	PgUp/PgDn
LCtrl + Encoder	Navigate prev/next word
RCtrl + Encoder	RGB hue up/down
LAlt-Encoder	Media prev/next track