## **Case Light Guide**



= connected to Bluetooth (BT) while searching for RF channel

- = pairing with headset

= paired with headset, no audio

= paired with headset, streaming BT audio

- = case's internal battery is less than 10%

 = case is plugged in and charging the headset and/or its own internal battery

 = when the case is plugged in, a white LED means the headset and case are both fully charged

## **Headset Light Guide**

- = pairing with case - = low battery

= paired with case = charging

When the headset reaches a full charge, its amber light goes OFF.