





GNU GPLv3
Copyright 2018
Purism SPC
Sheet: /Battery/
File: battery.sch

Title: Battery
Size: A4 Date: 2018-05-23 Rev: v0.1.0
KiCad E.D.A. kicad 4.0.7 Id: 3/23














TODO:
add parallel 100nF bulk caps!
& spread all over the power plane












































Proximity & Ambient Light



Reference: http://www.rohm.com/web/global/sensor-shield-support/ps-als-sensor



9-Axis IMU



Reference:

https://store.invensense.com/datasheets/invensense/AN-IVS-0001EVB-00%20v1%202.pdf

ADO sets the slave address's LSB (110100X)

INT1_ACTL sets if IMU_INT is active—high or active—low

"FSYNC - Connect to GND if unused"

12C's VIH=1.8V






Figure 12. Orientation of Axes of Sensitivity and Polarity of Rotation



Figure 13. Orientation of Axes of Sensitivity for Magnetometr

GNU GPLv3
Copyright 2018
Purism SPC
Sheet: /Sensors/
File: sensors.sch
Title: Sensors

 ITIE: Sensors

 Size: A4
 Date: 2018-05-23
 Rev: v0.1.0

 KiCad E.D.A. kicad 4.0.7
 Id: 20/23

