




GNU GPLv3
Copyright 2018
Purism SPC
Sheet: /Battery/
File: battery.sch

Title: Battery
Size: A4 Date: 2018-05-18 Rev: v0.1.0
KiCad E.D.A. kicad 4.0.6 Id: 3/21







TODO: add parallel 100nF bulk caps! & spread all over the power plane


> GNU GPLv3 Copyright 2018 **Purism SPC**


Sheet: /Power/ File: power.sch


Title: Power


 Size: A4
 Date: 2018-05-18
 Rev: v0.1.0


 KiCad E.D.A. kicad 4.0.6
 Id: 4/21






















Г	1	 2] 3	3	4	5	[6]
A							A
				×D CSI_P1_DP0 ×D CSI_P1_DN0			
В				*D CSI_P1_DP1 *D CSI_P1_DN1 *D DSI_P1_DP2			В
				*DCSI_P1_DN2 *DCSI_P1_DP3 *DCSI_P1_DN3 *DCSI_P1_CKP *GCSI_P1_CKN			
				*GCSI_PI_CKN			
С							c
					Charle (MIDL CC) (
D					Sheet: /MIPI CSI/ File: mipi_csi.sch Title:		D
	1	 2	I 3	3	Size: A4 Date: KiCad E.D.A. kicad 4.0.6	 5	Rev:

















Proximity & Ambient Light



http://www.rohm.com/web/global/sensor-shield-support/ps-als-sensor



9-Axis IMU




https://store.invensense.com/datasheets/invensense/AN-IVS-0001EVB-00%20v1%202.pdf

ADO sets the slave address's LSB (110100X)

INT1_ACTL sets if IMU_INT is active—high or active—low

"FSYNC - Connect to GND if unused"

12C's VIH=1.8V







GNU GPLv3 Copyright 2018 Purism SPC Sheet: /Sensors/ File: sensors.sch Title: Sensors

Size: A4 Date: 2018-05-18 Rev: v0.1.0 KiCad E.D.A. kicad 4.0.6 ld: 19/21

