#### **Power**

Dr Peadar Grant

Data Centre Infrastructure

## **Electrical quantities**

Quantity	Symbol	Unit	
Voltage	V	Volt	٧
Current	1	Ampere	Α
Resistance	R	Ohm	Ω
Power	Р	Watt	W

Table: Key electrical quanities

Voltage is difference between *two* points. One point often common earth / ground.

#### Ohm's law

Voltage, current and resistance are related by Ohm's law, which can be written in terms of V, I or R. Re-arrange to calculate required quantity.

$$V = R \cdot I \tag{1}$$

$$\Rightarrow I = \frac{V}{R} \tag{2}$$

$$\Rightarrow R = \frac{V}{I} \tag{3}$$

#### Power

Power quantifies how much energy is converted from one form to another per unit time. Units:  $Js^{-1} = W$ .

$$P = V \cdot I \tag{4}$$

$$\Rightarrow V = \frac{P}{I}$$

$$\Rightarrow I = \frac{P}{V}$$
(5)

$$\Rightarrow I = \frac{P}{V} \tag{6}$$

# Mains electricity

Nominal mains in Ireland is 230 V 50 Hz.

Three conductors:

- **Live (or hot, or phase)** carries a 230 V RMS AC voltage.
  - **Neutral** provides the return path for current on the live conductor, and under normal conditions will be the negative of that.
    - **Earth** is connected to earth and bonded to metal casings.


## **Circuit protection**

```
Fuses: thin wire
           Melts if I > I_{rated}.
Circuit Breakers (MCB):
           trips when I > I_{\text{rated}}.
Residual current device (RCD):
           protects against electric shock
           Trips if |I_1 - I_N| > \Delta I
           Normally \Delta_I = 30 \, \text{mA}.
Residual Current Breaker Overload (RCBO):
           MCB and RCD in single device
```

# Alternating current (AC)

Mains in most parts of world is **alternating current** (AC). This means that the instantaneous voltage v(t) varies sinusoidally with respect to time.

$$v(t) = V_{\text{max}} \sin(2\pi f t) \tag{7}$$



# **AC** waveform properties

Amplitude V<sub>max</sub>

**Peak-to-peak** amplitude from  $-V_{\text{max}}$  to  $V_{\text{max}}$ .

$$V_{\mathsf{PK-PK}} = V_{\mathsf{max}} - (-V_{\mathsf{max}}) \tag{8}$$

$$=2V_{\mathsf{max}} \tag{9}$$

Root Mean Square (RMS)


$$V_{\text{max}} = \sqrt{2}V_{\text{RMS}} \tag{10}$$

**Period** *T* related to Frequency *f* 

$$T = \frac{1}{f} \tag{11}$$

## Three-phase supply

Mains power is generated and distributed in three-phase form, with 3 live conductors and one neutral conductor. The sine wave is shifted by 120 degrees, or  $\frac{2\pi}{3}$  radians in any phase relative to one of the two other phases.



Let  $v_n(t)$  be the voltage in phase n of a three-phase supply. Phase 1 same as any AC waveform:

$$v_1(t) = V_{\text{max}} \sin(2\pi f t) \tag{12}$$

Phase 2 lags phase 1 by 120 degrees.

$$v_2(t) = V_{\text{max}} \sin\left(2\pi f t - \frac{2\pi}{3}\right) \tag{13}$$

Similarly, phase 3 leads phase 1 by 120 degrees.

$$v_3(t) = V_{\text{max}} \sin\left(2\pi f t + \frac{2\pi}{3}\right) \tag{14}$$

## Line and phase voltages

Three-phase power := two voltages to consider:

Phase voltage between any phase and neutral.


Line voltage between any two phases.

Related by  $\sqrt{3}$ :

$$V_{\text{line}} = \sqrt{3} \times V_{\text{phase}}$$
 (15)

$$\Rightarrow V_{\text{phase}} = \frac{V_{\text{line}}}{\sqrt{3}} \tag{16}$$

# **Distribution path**



# Power distribution unit (PDU)

Each rack has PDU, like multiplug adapter:

- PDU mounted:
  - vertically in the back of rack, or
  - in a rack space (facing in or out)
- May include surge protection.
- Maximum current depends on connector type on input to PDU.
- "Smart" PDUs: remote measurement and on/off sockets.

### **Common connectors**

Туре	<i>I</i> max	Male	Female
BS 1363	13 A		
IEC C13/14	10 A	C14	C13
IEC C19/20	16 A	C20	C19
IEC 60309	16 A		

Table: Common connector types

# **Disturbance types**

**Blackout:** total power loss.


```
Surge/sag: short-term (0.5 of a cycle up to 1 minute)
          voltage variations:
          Surge or spike high-voltage > 110\%
                Sag low-voltage
Over and under-voltage persisting minutes to days:
          Over-voltage
          Under-voltage (Formerly: brownout)
Frequency fluctuations where f \neq 50 \,\mathrm{Hz}
Waveform distortion: no longer is a sinusoid.
```

#### **CBEMA** curve

Undesirable conditions are generally less disruptive the shorter that they persist for:

- This includes disturbances in the power supply.
- The Computer Business Equipment Manufacturers
  Association (CBEMA) in the 1970s generated a
  curve that partitioned voltage events and times into
  acceptable and unacceptable region.

#### ITI (CBEMA) Curve (Revised 2000)



#### Form factors

UPS units are available in various form factors:

Freestanding / tower similar to PC powering a single device or multiple devices via a PDU. Usually located adjacent to the IT equipment.

**Rackmount** powering a single device or multiple devices via a PDU. Usually co-located inside the same rack as the IT equipment.

Floor-standing UPS devices located within the IT environment itself or in another part of the facility. These normally supply multiple IT loads and are often managed by facilities rather than IT personnel.

