
Dynamics - Motivation

- System design and analysis often begin with a simple model
- Use a model to probe the system's sensitivities and response to inputs to inform design modifications or the control system
- Determine power requirements and size components
- Knowing what a simple model should (and should not) include requires experience - it all starts with being able to perform dynamic analysis





4


Example - Ship Drivetrain Vibration

Possible Analysis Objectives

- Specify the properties of the Torsional Elastic Coupling such that propeller vibration, due to engine firing, is below some threshold
- Specify the Misalignment Coupling angular range due to the vertical vibration of the engine and/or specify the elastic engine mount properties.

Possible Analysis Approach

- Declare assumptions (different for each analysis objective)
- Postulate a lumped parameter model and generate differential equations
- Develop an understanding of the sensitivities of motion outputs to force/torque inputs
- Evolve a simulation start simple, add complexity as needed






https://www.geislinger.com/en/products/product/coupling


Example - Ship Drivetrain Vibration

Lumped Parameter Model - An approximate model of a physical system/device where its numerous parts are replaced with a few, idealized ones based on stated assumptions.

constrained to vertical only












https://www.geislinger.com/en/products/product/coupling


Lumped Model Samples

Translation Only











Objectives and Skills

- 1. Recognize a lumped parameter model
- 2. Review concepts and terminology from MEEM 2700, dynamics
- 3. Develop a slightly different method for FBDs
- 4. Create a FBD of a hanging rod, maybe generate its DEQ model


 Reference frame - A right-hand set of 3-axes that is either fixed (inertial) or moving/rotating




2. Plane Motion - All motion occurs in a single, fixed plane



3. Particle - A conceptual "body" with mass but no dimensions, thus no inertia



 Rigid body - A real body with mass properties - mass, inertia, and center of mass. Sometimes we can represent rigid bodies as particles during analysis.




Kinematics - Equations that relate motions within or between bodies

Statics ZF = O

Dynamics







(planar motion)
Absolute angular

of inertia, c.m.

 Absolute position vector (m) - A vector from a fixed point to some point of interest, usually a center of mass




v is tangent to the path.




9. Absolute velocity and acceleration $(m/s, m/s^2)$ - Time rate of change of the position and velocity vectors respectively


10. Relative position (m) - A vector from one moving point to another



11. Relative velocity and acceleration $(m/s, m/s^2)$ - The velocity and acceleration of some point as viewed by an observer fixed at another point




12. Rotation - A situation where two reference frames are not aligned



13. Angular Velocity (rad/s) - A vector that describes the rate of change of a body's rotation. NOTE: It is defined and NOT the derivative of a "rotation vector," and thus is unlike velocity which is the derivative of a defined absolute position vector. Rigid bodies can have angular velocity. We never say a point on the body has an angular velocity

14. Angular Acceleration (rad/s^2) - The time rate of change of the angular velocity vector

15. Linear Momentum $(kg \cdot m/s)$ Product of mass and velocity





mass is a measure of resistance to accelerate.

16. Angular Momentum $(kg \cdot m^2/s)$, Product of mass moment of inertia and angular velocity

Inertia is a measure of resistance to augular acc.










17. Mass Moment of Inertia $(kg \cdot m^2)$ - A property of a rigid body

Tables, CAD

Move the reference point using the parallel axis theorem.

why do it ?? Makes KE easier to calculate. Makes rotational DEQs easier too when there is rotation about a fixed pt.

EM. : I, 8




Given: m = 40 kg Ic2 = . 2 Mg·m Find: Ioz


Ing = I = + md2 we need d ... Ioz = . 2 + 4042


Note: Whenever you move the ref. pt. for I, its value increases ...

18. Force $(N, kg \cdot m/s^2)$. For us, divided into two categories: contact and field. Several ways to describe it: (1) if there's a force, there's the possibility of motion, (2) if there's motion, there is or was a force, (3) product of mass and acceleration



19. Moment $(N \cdot m, kg \cdot m^2/s^2)$. Created by a force, so the comments above apply to moments too. Regardless of where a moment is applied to a rigid body, its effect on its motion is the same.





20. Work $(N \cdot m, kg \cdot m^2/s^2)$. If a body is moving, and there is an external force present, then work is being done. If the force is in the direction of motion then the work is positive. If the force is opposing the motion, then the work is negative. We never say a body "has work."

21. Kinetic Energy $(kg \cdot m^2/s^2)$. Defined at any instant in time as: $T = \frac{1}{2}m\mathbf{v} \cdot \mathbf{v}$

Note: Dot product of 2 vecs

Concepts and Terminology 6:4.6743 x10" Nm2, M:5.9722 x10 kg, R:6.3750 x103m (Houghton, effective)

22. Potential Energy $(kg \cdot m^2/s^2)$. Energy associated with some very special forces, called **conservative forces**, that have the properties: (1) they are functions of position only, not time, not speed and (2) the work done on a body by a conservative force as it moves from configuration A to configuration B only depends on the description of these two end points and has nothing to do with how it moved between them. An interesting result that relates a conservative force and PE is:

$$F = -\left(\frac{\partial V}{\partial x}i + \frac{\partial V}{\partial y}j + \frac{\partial V}{\partial z}k\right)$$

$$G^{*} = \frac{-MmG}{r^{2}} = \frac{-MmG}{(R+h)^{2}}$$

$$= \frac{-MmG}{R^{2}}(1-2^{h}/R)$$


$$\approx -mg \left(h^{4}R\right)$$

$$q = MG/R^{2} \approx 9.808$$

$$V_{*} = \frac{-MmG}{r} = \frac{-MmG}{R^{4}h} \approx \frac{-MmG}{R}(1-\frac{h}{R})$$


$$\approx -mgR(1-\frac{h}{R}) \approx -mgR + mgh$$

$$V = V_{0} + mgR \approx mgh \left(h^{4}R\right)$$



24. Power $(W, N \cdot m/s)$. Time rate of change of energy. Used for sizing mixed physics components.

Related to work ...



Same concept for M & w (wind torbins).

P: M. w : F. v = (Volt)(current) = i R2 = etc.

Example: A battery operated motor must generate .4 N·m @ 1000 rpm. The battery is 12 v. How much current will it draw? $P = .4 \cdot 1000 \cdot 2\pi \, rad \approx 2.5 \, kW = (12)(i)$, i \$ 200 amps battery would rev

(2,3 ft·16)

Key Principles

Starting from Newton's Law of Motion, we can derive and exploit the principles of ...

- 1. Work and Kinetic Energy
- 2. Conservation of Mechanical Energy
- 3. Linear Impulse and Momentum
- 4. Conservation of Linear Impulse
- 5. Angular Momentum and Impulse
- 6. Conservation of Angular Momentum

Free Body Diagrams - A Checklist

- 1. Sketch out one or more coordinate frames and define the motion variables, x, y, θ, ϕ , etc. Take care to define what positive means for each
- Separate each body from the system and sketch it in roughly the same location as it was in the system, but with room to annotate it with vectors
- 3. Immediately label each with appropriate translation and rotation inertial forces (i.e. $m\ddot{x}, m\ddot{y}, I\ddot{\theta}, I\ddot{\phi}$, etc.) with the vector point in the OPPOSITE direction of what you declared as positive in Step #1.
- 4. If the motion is in a vertical plane (gravity) then immediately annotate each body with its weight vector, $\mathbf{w} = m\mathbf{g}$
- Identify all forces and moments that are shared between bodies, e.g. springs, cords, dampers, normal forces, etc. Apply them as vectors and include equal and opposite on affected bodies
- 6. Assign normal forces between bodies and/or fixed surfaces ALWAYS normal to their interface surface
- 7. Assign externally applied forces and moments, e.g. thrusters, motor torques, etc. Classify: Conservative, nonconservative
- 8. If any body can slide or roll relative to another body or surface, then assign a friction force. If between bodies, then make sure you apply equal and opposite vectors. NOTE: you can always set any of these to zero if there is no friction
- 9. If there are joints with reaction forces and moments, then assign them, e.g. pins, cantilever, etc.


Free Body Diagram - One Figure, Not Two - Translation


Newton's Law of Motion

$$\sum \mathbf{F} = m \mathbf{a}$$



B)
$$T \in \Theta - F_F - F_S - m \times = 0$$
 Block on a guide $T = 0 + N - m = 0$







Free Body Diagram - One Figure, Not Two - Rotation


Euler's Equation


$$\sum \mathbf{M} = I\dot{\omega} + \omega \times I\omega$$

$$\sum M = I\ddot{\theta}$$










Pulley Only

Example 1

Create the DEQ model, using an FBD, of a hanging rod.



L, m, Ic, r

Uniform p

I : 12 (3r + L2)

Take 2 derivs ... lots of terms. a(0,0,0)

Kinematics

Important if we want of Rx & Ry.

x) Rx-max=0 } y) Ry-w-may=0 6) use 0, not c, easier

IM. : 1.0

Example 1

Create the DEQ model, using an FBD, of a hanging rod.

or,
$$I_0\ddot{\theta} + \frac{mgL}{2} \circ \theta = 0$$
 Nonlinear DEQ...


$$T_c : \frac{1}{12}(3r+L^2)$$
 | $T_c : \frac{1}{12}(3r+L^2)$ | $T_c : \frac{1}{12}(3r+L$

Example 1

Create the DEQ model, using an FBD, of a hanging rod.

Summary

1. Simulate Eq. 3 ->



2. Sub 3 into 1 & 2

Summary

You can (with a little more practice)

- Distinguish the difference between a real dynamic system and a lumped parameter representation/model
- Create a FBD of a plane motion, rigid body including declaring variables of motion and coordinate frames
- Use 1-sketch FBDs

Summary

You can (with a little more practice)

- Distinguish the difference between a real dynamic system and a lumped parameter representation/model
- Create a FBD of a plane motion, rigid body including declaring variables of motion and coordinate frames
- Use 1-sketch FBDs

Summary

You can (with a little more practice)

- Distinguish the difference between a real dynamic system and a lumped parameter representation/model
- Create a FBD of a plane motion, rigid body including declaring variables of motion and coordinate frames
- Use 1-sketch FBDs