


A

A

Remove R20-R22, R26-R28, and install Q7-Q12 for use with dumb coils



B

B

C

C

D


D

Sheet: /Ignition/  
File: IGN6.kicad\_sch

**Title:**

Size: A4 | Date:  
KiCad E.D.A. 8.0.9

**Rev:**  
Id: 2/5



1 2 3 4 5 6

A

A

B


B

C

C

D

D



Sheet: /EGT/  
File: egt.kicad\_sch

**Title:**

Size: A4 | Date:  
KiCad E.D.A. 8.0.9

**Rev:**  
Id: 4/5

1 2 3 4 5 6

1 2 3 4 5 6

A

A

B


B

C

C

D

D



Sheet: /LOW\_SIDE/  
File: LOW\_SIDE.kicad\_sch


**Title:**

Size: A4 Date:  
KiCad E.D.A. 8.0.9


**Rev:**  
Id: 5/5

1 2 3 4 5 6


A




B



C



D




Sheet: /  
File: hellen1-vr-discrete.kicad\_sch

**Title:**

Size: A4 | Date:  
KiCad E.D.A. kicad (6.0.8)

**Rev:**  
Id: 1/1

A



B

C

D

A

A

B



B


C


C

D

D







A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B

C

C

D

D



A

A

B


B


C


C

D

D







A

A

B


B

C


C

D

D



A



A

B

C

D

A

A

B


B


C

C

D

D





A

A

B

B


C

C


D

D

More accurate threshold for "raw" connection of VR sensors



A




Title

Size	Number	Revision
A4		
Date:	2.15.2025	Sheet of
File:	C:\Work...\power.SchDoc	Drawn By:


A

A



B

B



C

C

D

D