USER'S Manual

HAOO 633 Vox Super Mini Walkie Talkie

CAUTION

This HAOO Greenwolf Super Mini Walkie Talkie Pro features an excellent design and advanced technology, The following information will help you understand the warranty terms, as well as the basic usage and safety guidelines for operating your walkie-talkie.

1. Don't try to disassemble the walkie-talkie. Unauthorized disassemble may cause damage to the walkie-talkie.
2. This machine can use universal qualified mobile phone charger (5V).
3. Don't expose the machine to sun for a long time or put it on a overheated place.
4. Don't use strong chemicals, cleaning agents or strong lotions to clean walkie-talkie.
5. If it is found to emit peculiar smell or smoke, place it on the open ground to avoid injury, and contact the distributor in time.
6. Don't use the machine inflammable, explosive or other place where walkie-talkie is prohibited.
7. Please abide the local wireless management regulations, contact with the distributor if you have any questions.
8. Package includes : Mini Walkie Talkie, Headset, Type-C Charger, Charging Cable, Adapter, and English Manual.
9. This mini walkie-talkie is rainproof, protecting it from rain and sweat to prevent damage. but not designed for direct soaking or full submersion in water.
10. As our uniquely patented design, this mini walkie-talkie must be used with our designated earphones, to achieve this min size, the external speaker was removed and the antenna built into the earphones.
11. AI Environmental Noise Cancellation : This function reduces back ground noise at the transmitting end only, It effectively filters out surrounding environmental sounds while preserving the clarity and purity of the speaker's voice (Note: this is not receiver-side noise cancellation).
12. Vox Handsfree Function : Built-in VOX function automatically transmits your voice without pressing the PTT button, simply speak to communicate, keeping your hands free.
13. For any quality and after sales-issues, please check support team : **greenwolftech66@gmail.com**

LED Icon

Icon	Name	Description
	Channel / Volume Level	1 : Offer 22 Channels (Uses standard GMRS General Mobile Radio Service) and 9 Volumes levels. 2 : Displaying channel while Transmitting / Receiving.
	Battery Level	1 : The more latin is there are, the more electricity there is. 2 : Charge for 2 hours and stand by for 48 -96 hours, continuous use about 12 hours to provide excellent work performance.

	Transmitting / Receiving Led	1 : The Green led is lighted on while receiving signal. 2 : The Red led is lighted on while transmitting signal.
	Lock Indicator	1 : The light is on : Walkie Talkie is locked up. 2 : The light is off : Walkie Talkie is locked off.
	Vox Handsfree Mode	1 : The letter "V" next to the channel / volume number indicates that the device is currently in VOX hands-free mode. 2 : The letter "Vo" indicates that the device is ready into VOX hands-free mode.

Part Description



No.	Name	Description
①	Power Button	Turn On : Press the key for 2 seconds in power off mode. Turn Off : Press the key for 2 seconds in power on mode.
②	P key	Press P key for 2 seconds to lock / unlock.
③	PTT	Push to Talk key.
① & ② & ③ & ④	Vox Mode	1 : Turning on the device, then press and hold the P button (2 seconds) to unlock the device. 2 : quickly press the power button once and letters "Vo " will appear on the LED display to prepare enter VOX mode. 3 : Use the " + / - " buttons to adjust the VOX level (sensitivity levels 1 - 4 are available). 4 : Press PTT button to save and confirm the setting, after saving, a letter "V " will appear on the screen (Press PTT Button again to turn off the VOX function).
④	+ (Up key)	1. Please unlock mini walkie talkies first, then quick-press the " + " key to enter the channel setting mode to change the channel, long press " + " the key to enter the volume setting mode to change the volume. 2. In the channel / volume setting mode, press the " + " key to increase channel / volume.
⑤	– (DOWN key)	1.Please unlock mini walkie talkies first, then quick press the " - " key to enter the channel setting mode to change the channel, long press " - " the key to enter the volume setting mode to change the volume. 2. In the channel / volume setting mode, press the " - " key to decrease channel / volume.
⑥	TYPE-C Socket	Multi-function interface, charge, earphone and program.
⑦	Microphone	Built in Microphone.

Operation Guide

1.Power ON / OFF

① Power On: Keep pressing power key about 2 seconds, " Di " will be sounded and LED will be lighted on and the machine entered in standby mode.

② Power Off: Keep pressing power key about 2 seconds, " Di " will be sounded and LED will be lighted off and the machine enters power off mode.

2.Channel Setting

① After press p key for 2 seconds to unlock mini walkie talkie and going into Standby mode.

② After In Standby mode, quick press " + " / " - " key. The led will display " CH " about 1 second, then the digit number 2 **(Default setting: the device starts on channel 2 after powering on)** will Blink, press " + " / " - " key repeatedly to adjust to desired channel, press " PTT " key to saving the settings and exit.

3.Volume Setting

① After press p key for 2 seconds to unlock mini walkie talkie and going into Standby mode.

② After In Standby mode, long press " + " / " - " key. The led will display "VL" about 1 second, then the digit number 5 **(Default setting: the device starts on volume 5 after powering on)** will Blink, Press " + " / " - " key repeatedly to adjust to desired volume, Press " PTT " key to saving the settings and exit.



4.Key lock setting

① Auto Lock: The key will be locked automatically when no key is pressed for about 40 seconds.

② Lock on: Press " P " key about 2 seconds and " 🔒 " icon will be turned on, the other functions are locked except (power on / off) function and the PTT function.

③ Lock off: Press " P " key about 2 seconds and " 🔓 " icon will be turned off, all function can be used.

5.Vox handsfree mode

① Turning on the device, then press and hold the P button (2 seconds) to unlock the device.

② Quickly press the power button once and letters " Vo " will appear on the LED display to prepare enter VOX mode.

③ Use the " + / - " buttons to adjust the VOX level (sensitivity levels 1 - 4 are available).

④ Press PTT button to save and confirm the setting, after saving, a letter "V " will appear on the screen (Press PTT Button again to turn off the VOX function).

6.PTT prohibited while signal received

This function was set to on / off by PC programming.
If this function is active, we cannot transmitting voice while receiving the signals.
If the channel is free, we can send the voice normally and " Di " tone will heard.
If the channel is busy, we cannot send the voice normally and " Di-Di " tone will be heard, then wait a moment and try again.

7.One key frequency match function

This function allows pairing and compatible with different models or other brands of walkie-talkies. Please follow the 4 steps of below :

① Press p key for 2 seconds to unlock mini walkie talkie.

② Quick (Shortly) press " + " / " - " key and Letter " CH " flashed rapidly, then long press p key to enter pairing model and there will have a letter " F " flashed rapidly in the LED display is mean we are in pairing mode.

③ Talk out another models of walkie talkies, press Call key (PTT Key) transmit the signal.

④ When the letter " F " stops flashing rapidly and this icon " 📶 " appears in the LED display, it means the pairing has been successful.

Beep Prompt Design

❶ The purpose of the audible prompt is to clearly alert users in noisy or busy work environments, Beep prompt volume is fixed and cannot be adjusted, Some users may find the beep sensitive, while others find it helpful.

① The purpose of this audible prompt is to clearly alert users in noisy or busy work environments.

② Built-in beep prompt helps users know when to start speaking, even in noisy environments.

③ During a call, a beep sound is triggered when the PTT button is pressed. This feature is intentionally designed to notify the user that the channel is open and voice transmission has started, helping prevent overlapping conversations and ensuring clear, orderly communication.

④ **This mini walkie talkie is commonly used in noisy environments such as restaurants, hotels, and events. The beep prompt is designed to clearly notify users when communication begins. For any questions about this feature, please contact us.**

AI Noise Cancellation

❷ Equipped with a new-generation noise cancellation chip, the AI Noise Reduction function is designed for environmental noise reduction on the transmitting side (The person who is speaking), not active noise cancellation for the listener.

① This means noise reduction on the transmit side, not the receive side. It reduces ambient noise picked up by the mic while you're speaking.

② This device features AI-powered noise cancellation on the transmitting side. An integrated AI chip analyzes surrounding sounds in real time and distinguishes human speech from common background noises.

③ The AI chip applies trained algorithms to analyze the frequency characteristics of environmental noise, including hammering, piling noise, high-pitched sounds, desk tapping, and wind noise. These noise patterns are identified and suppressed to improve voice clarity.

④ Since human voices occupy similar frequency ranges, background speech from other people may not be fully eliminated. The system prioritizes the primary speaker's voice to maintain natural communication.

⑤ This technology is designed to enhance the main speaker's voice while reducing typical environmental noise. However, voices from other nearby people may not be completely eliminated.

⚠ Please note

① **This feature does not function as Active Noise Cancellation (ANC) for the listener. It does not remove background noise from the receiver's environment. Instead, it improves voice clarity during transmission by reducing noise around the speaker.**

② Background voices from other people may not be completely filtered.

Battery Information & Charging note

❸ Built-in 680 mAh lithium battery, Charges via Type-C cable and fully charges in about 2 hours. Standby time up to 48-96 hours, with 18-24 hours of continuous use. Actual usage may vary depending on operating frequency.

① Before first use, or after long periods of inactivity, fully charge new or unused rechargeable batteries.

② Battery meter will roll while charging. The rolling meter will be stopped when the battery is full.

③ It is recommended to use the original charger supplied with the device. You may also use certified brand mobile chargers available on the market. The manufacturer is not responsible for any damage caused by using inferior chargers.

Range & Electromagnetic Interference

❹ The communication range reaches 3 miles under open area (No Electromagnetic interference), the range may be reduced and effected by walls, buildings, trees.

① In open areas, the communication range can reach up to 1-3 miles.

② In environments with obstacles, the communication range is 1-2 miles.

③ Electromagnetic interference (Static) It's a common issue for all 2-way radios, When strong electromagnetic signals (from wireless devices or motors) are near the electronic device, it will cause signal interference, noise and will affect the communication range.

CTCSS Information Note

❺ CTCSS is fixed in the radio during manufacturing and cannot be modified. Only professional user (regular users ignore it) can change CTCSS/DCS via computer and professional program cable. Uses standard GMRS (General Mobile Radio Service) frequencies. For further questions about this function, please contact us first.

① To prevent accidental operation, each channel's CTCSS / DCS is preset to 67.1 Hz during manufacturing.

② The CTCSS / DCS menu is hidden on the device and cannot be changed manually.

③ To use a different CTCSS / DCS, it must be set via computer software by professional program cable.

④ If using this feature, please set CTCSS / DCS in your other walkie-talkie to 67.1Hz.

CTCSS Table (Hz)

Silent code	FREQ	Silent code	FREQ	Silent code	FREQ	Silent code	FREQ
1	67.0	11	97.4	21	136.5	31	192.8
2	71.9	12	100.0	22	141.3	32	203.5
3	74.4	13	103.5	23	146.2	33	210.7
4	77.0	14	107.2	24	151.4	34	218.1
5	79.7	15	110.9	25	156.7	35	225.7
6	82.5	16	114.8	26	162.2	36	233.6
7	85.4	17	118.8	27	167.9	37	241.8
8	88.5	18	123	28	173.8	38	250.3
9	91.5	19	127.3	29	179.9		
10	94.8	20	131.8	30	186.2		

DCS Table

Silent code	DCS CODE	Silent code	DCS CODE	Silent code	DCS CODE	Silent code	DCS CODE
38	023D	47	071D	55	131D	64	172D
39	025D	48	072D	56	132D	65	174D
40	026D	49	073D	57	134D	66	205D
41	031D	50	074D	58	143D	67	172D
42	032D	51	114D	59	152D	68	174D
43	043D	52	115D	60	155D	69	205D
44	051D	53	116D	61	156D	70	212D
45	054D	54	125D	62	162D	71	223D
46	065D	55	131D	63	165D	72	225D

Silent code	DCS CODE	Silent code	DCS CODE	Silent code	DCS CODE	Silent code	DCS CODE
73	226D	80	263D	87	315D	94	356D
74	243D	81	265D	88	325D	95	371D
75	244D	82	266D	89	331D	96	411D
76	251D	83	271D	90	332D	97	412D
77	252D	84	274D	91	343D	98	413D
78	255D	85	306D	92	346D	99	423D
79	261D	86	311D	93	351D		

Specification

Overall

Channel	Up to 22
Volume	Up to 8
Working tempeature:	-20~+60°
Standard Voltage:	DC 3.8V
Capacity of Battery	680 mAh
Channel Spacing	12.5 K/25KHz
Outline Size	2.56*0.6*1.2 inches
Weight	26g
Antenna Impedance	50Ω

Transmitting Part

Freq Stability	≤±2.5 ppm
RF power	<1W
Modulation	F3E
Residual	≤-35 dB
Audio distortion	≤3%

Receiving Part

Sensitivity	≤-120 dBm
Adjacent selection:	≥60dB
modulaion Rejection:	≥60dB
SNR	≥48dB
Audio Distortion:	≤3%

Product Usage Guide Video

❻ After reading this manual, if you find it difficult to understand how to operate the device or you would like to watch a quick start tutorial video, including instructions on the button functions, general operation, and how to pair same frequencies with other models of walkie talkie, we recommend the following options to view the instructional videos:

① Watch the instructional video available on the product detail page on Amazon.

② Visit our official YouTube channel " HAOO Greenwolf ", where additional tutorial videos are available.

③ You may also find tutorial videos in our Amazon Brand Store.

④ We also provide a detail " How to Use " video and " Use Manual " PDF on the product page, and we recommend watching it online to learn how to get the best experience. For any other issues you face to, our professional team with 24 / 7 support is here for you.