

Левая боковина (продолжение на листе 1)

		45		
		46		
		47		
		48		
		49		
		50		
		51		
		52		
		○ 53	X-53	UZ1-4
		○ 54	X-54	A1-M6.XB-28
	Цены сигнализации выключателя/ТТ			X
		○ 55	X-55	A1-M5.XB-15
		○ 56		
		57	X-56	A1-M5.XB-17
		58	X-57	A1-M5.XB-19
		59	X-58	A1-M5.XB-21
		60	X-59	A1-M5.XB-23
		61	X-60	A1-M5.XB-25
		62	X-61	A1-M5.XB-27
		63	X-62	A1-M5.XB-29
		64	X-63	A1-M5.XB-31
		65	X-64	A1-M3.XB-2
		66	X-65	A1-M3.XB-32
		67		
		68		
		69		
		70		
		71		
		○ 72	X-72	A1-M5.XB-30
		○ 73		
	Цены ЭМВ и ЭМ01			X
		○ 74	X-74	A1-M2.XB-2
		○ 75		
		○ 76		
		○ 77		
		○ 78		
		79		
		○ 80	X-80	KA1-A
		○ 81	X-81	A1-M6.XB-2
		82	X-82	KA1-B
		83		
		○ 84	X-84	SA1-6
		○ 85		
		○ 86		
		○ 87		
		○ 88		
		○ 89	X-89	KA2-A
		○ 90	X-90	A1-M6.XB-4
		91	X-91	KA2-B
		92		
		93	X-93	A1-M6.XB-32
	Цены ЭМ02			X
		○ 94	X-94	A1-M6.XB-9
		○ 95		
		○ 96		
		○ 97		
		○ 98		
		99		
		○ 100	X-100	SA1-8
		○ 101		
		○ 102		
		○ 103		
		○ 104	X-104	KA3-A
		○ 105	X-105	A1-M6.XB-10
		106	X-106	KA3-B
		107		
		108	X-108	A1-M6.XB-14

Правая боковина (продолжение на листе 1)

		159		
		160		
		161		
		162		
		163		
		164		
		165		
		166		
		167		
		168		
X	Цены сигнализации			
A1-M1.XP-2	X-169	169	○	
		170	○	
		171	○	
		172	○	
		173		
		174		
		175		
		176		
		177		
		178		
		179		
		180		
HL1-2	X-181	181	○	
		182	○	
X	Цены PAC			
A1-M1.XP-5	X-183	183	○	
		184	○	
		185		
A1-M1.XP-4	X-186	186		
A1-M1.XP-14	X-187	187		
X	Цены освещения			
SQ1-11	X-188	188	○	
		189	○	
SQ1-21	X-190	190	○	
		191	○	
X	Резерв/Транзит			
		192		
		193		
		194		
		195		
		196		
		197		
		198		
		199		
		200		
		201		