

Левая боковина (начало)				
	Цепи переменного тока /ЭП			X
		1	X:1	SG1:2
		2	X:2	SG1:4
		3	X:3	SG1:6
		4	X:4	SG1:8
		5	X:5	SG1:10
		6	X:6	SG1:12
		7		
		8		
	Цепи переменного тока 3/о /ЭП			X
		9	X:9	SG2:2
		10	X:10	SG2:4
	Цепи переменного напряжения			X
		11	X:11	SG3:2
		12	X:12	SG3:4
		13	X:13	SG3:6
		14	X:14	SG3:8
		15	X:15	SG4:2
		16	X:16	SG4:4
		17	X:17	SG4:6
		18	X:18	SG4:8
	Цепи отбора напряжения /ЭП			X
		19	X:19	SG5:2
		20	X:20	SG5:4
		21	X:21	SG5:6
	Цепи оперативного тока			X
		22	X:22	UZ1:1
		23	X:23	SG1:14
		24		
		25		
		26		
		27		
		28		
		29	X:29	A1-M4.XB:1
		30	X:30	A1-M4.XB:3
		31	X:31	A1-M4.XB:5
		32	X:32	A1-M4.XB:7
		33	X:33	A1-M4.XB:9
		34	X:34	A1-M4.XB:11
		35	X:35	A1-M4.XB:13
		36	X:36	A1-M4.XB:15
		37	X:37	A1-M4.XB:17
		38	X:38	A1-M4.XB:19
		39	X:39	A1-M4.XB:21
		40	X:40	A1-M4.XB:23
		41	X:41	A1-M4.XB:25

Левая боковина (продолжение на листе 2)

Условные обозначения

