

Левая доковина (начало)				
	Цепи переменного тока /ЛЭП			X
		1	X:1	SG1:2
		2	X:2	SG1:4
		3	X:3	SG1:6
		4	X:4	SG1:8
		5	X:5	SG1:10
		6	X:6	SG1:12
		7		
		8		
	Цепи оперативного тока			X
		9	X:9	UZ1:1
		10	X:10	SG1:14
		11		
		12		
		13		
		14		
		15		
		16		
		17		
		18		
		19	X:19	A1-M7.XB:1
		20		
		21	X:21	A1-M7.XB:3
		22		
		23	X:23	A1-M7.XB:5
		24		
		25		
		26	X:26	A1-M7.XB:7
		27		
		28		
		29	X:29	A1-M7.XB:9
		30	X:30	A1-M7.XB:11
		31	X:31	A1-M7.XB:13
		32		
		33	X:33	A1-M7.XB:15
		34	X:34	A1-M7.XB:17
		35	X:35	A1-M7.XB:19
		36	X:36	A1-M7.XB:21
		37	X:37	A1-M7.XB:23
		38	X:38	A1-M7.XB:25
		39		
		40		
		41		
		42		
		43		
		44		
		45		
		46		
		47		
		48		
		49	X:49	UZ1:4
		50	X:50	A1-M7.XB:26

Левая доковина (продолжение на листе 2)

Правая доковина (начало)				
X	Выходные цепи			
A1-M2.XB:20	X:146	146		
A1-M2.XB:22	X:147	147		
A1-M2.XB:24	X:148	148		
A1-M2.XB:26	X:149	149		
A1-M2.XB:28	X:150	150		
A1-M2.XB:30	X:151	151		
A1-M2.XB:32	X:152	152		
A1-M3.XB:2	X:153	153		
A1-M3.XB:12	X:154	154		
A1-M3.XB:14	X:155	155		
A1-M3.XB:16	X:156	156		
A1-M3.XB:18	X:157	157		
A1-M3.XB:20	X:158	158		
A1-M3.XB:22	X:159	159		
A1-M3.XB:24	X:160	160		
A1-M3.XB:26	X:161	161		
A1-M3.XB:28	X:162	162		
A1-M3.XB:30	X:163	163		
SA8:9	X:164	164		
SA8:13	X:165	165		
SA8:17	X:166	166		
A1-M3.XB:8	X:167	167		
A1-M3.XB:10	X:168	168		
K4:9	X:169	169		
K4:10	X:170	170		
K4:14	X:171	171		
K5:9	X:172	172		
A1-M3.XB:32	X:173	173		
A1-M4.XB:2	X:174	174		
		175		
		176		
		177		
		178		
		179		
		180		
		181		
		182		
		183		
		184		
		185		
SA2:4	X:186	186		
SA2:6	X:187	187		
SA3:4	X:188	188		
SA3:6	X:189	189		
SA3:8	X:190	190		
SA4:4	X:191	191		
SA4:6	X:192	192		
SA4:8	X:193	193		
SA5:4	X:194	194		
SA5:6	X:195	195		

Правая доковина (продолжение на листе 2)

Условные обозначения

