

Левая доковина (продолжение на листе 1)

	Цепи сигнализации выключателя/ТТ		Х
	51	X:51	A1-M7.XB:27
	52		
	53		
	54	X:54	A1-M7.XB:29
	55	X:55	A1-M7.XB:31
	56	X:56	A1-M8.XB:1
	57	X:57	A1-M8.XB:3
	58	X:58	A1-M8.XB:5
	59	X:59	A1-M8.XB:7
	60	X:60	A1-M8.XB:9
	61	X:61	A1-M8.XB:11
	62	X:62	A1-M8.XB:13
	63	X:63	A1-M8.XB:15
	64	X:64	A1-M8.XB:17
	65	X:65	A1-M8.XB:19
	66	X:66	A1-M8.XB:21
	67	X:67	A1-M8.XB:23
	68	X:68	A1-M8.XB:25
	69	X:69	A1-M8.XB:27
	70	X:70	A1-M8.XB:29
	71	X:71	A1-M8.XB:31
	72	X:72	A1-M9.XB:1
	73	X:73	A1-M9.XB:3
	74	X:74	A1-M9.XB:5
	75	X:75	A1-M9.XB:7
	76	X:76	A1-M3.XB:6
	77	X:77	A1-M3.XB:4
	78		
	79	X:79	A1-M7.XB:28
	80		
	Цепи ЭМВ и ЭМ01		Х
	81	X:81	A1-M2.XB:14
	82	X:82	A1-M2.XB:16
	83	X:83	A1-M2.XB:18
	84		
	85		
	86		
	87		
	88		
	89		
	90	X:90	KA1A
	91	X:91	A1-M9.XB:9
	92	X:92	KA1B
	93	X:93	KA2-A
	94	X:94	A1-M9.XB:11
	95	X:95	KA2-B
	96	X:96	KA3-A
	97	X:97	A1-M9.XB:13
	98	X:98	KA3-B
	99	X:99	SA1:10
	100	X:100	KA4-A
	101	X:101	A1-M9.XB:15
	102		
	103		
	104	X:104	KA4-B
	105	X:105	SA1:12
	106	X:106	KA5-A
	107	X:107	A1-M9.XB:17
	108		
	109		
	110	X:110	KA5-B
	111	X:111	SA1:14
	112	X:112	KA6-A
	113	X:113	A1-M9.XB:19
	114		
	115		
	116	X:116	KA6-B
	117	X:117	A1-M9.XB:22

Левая доковина (продолжение на листе 3)

Правая доковина (продолжение на листе 1)

	SA6:4	X:196	196		
	SA6:6	X:197	197		
	SA6:8	X:198	198		
	SA6:10	X:199	199		
	SA7:4	X:200	200		
	SA7:6	X:201	201		
	SA7:8	X:202	202		
	SA7:10	X:203	203		
	SA8:10	X:204	204		
	SA8:14	X:205	205		
	SA8:18	X:206	206		
	A1-M3.XB:7	X:207	207		
	A1-M3.XB:10	X:208	208		
	K4:11	X:209	209		
	K4:12	X:210	210		
	K4:16	X:211	211		
	K5:11	X:212	212		
	A1-M3.XB:31	X:213	213		
	A1-M4.XB:1	X:214	214		
			215		
			216		
			217		
			218		
			219		
			220		
			221		
			222		
			223		
			224		
			225		
	Х	Цепи сигнализации			
	A1-M1.XP:2	X:226	226		
			227		
			228		
			229		
			230		
			231		
			232		
			233		
			234		
			235		
			236		
			237		
	HL1:2	X:238	238		
			239		
	Х	Цепи РАС			
	A1-M1.XP:5	X:240	240		
	A1-M1.XP:15	X:241	241		
			242		
	A1-M1.XP:4	X:243	243		
	A1-M1.XP:14	X:244	244		
	Х	Цепи освещения			
кч	SQ1:11	X:245	245		
			246		
с	SQ1:21	X:247	247		
			248		
	Х	Резерв/Транзит			
			249		
			250		
			251		
			252		
			253		
			254		
			255		
			256		
			257		
			258		

Правая доковина (продолжение на листе 3)