

[illegible]

The diagram illustrates a three-phase control system (A1) for a transformer, showing three identical phase sections (A, B, C) connected to a common busbar. Each section includes a control unit (KS4, KS5, KS6) and a set of terminal blocks (M6, M8) connected to various control and isolation points. The diagram is labeled 'A1' and includes a 'Питание' (Power) section for each phase.

**Phase A (KS4):**

- Control unit KS4 is connected to phases X-86, X-87, and X-88.
- Terminal blocks M6.XB-9, M6.XB-10 are connected to 'Ср. сизн. конт. ДТм ШР фА 1 цепь'.
- Terminal blocks M6.XB-3, M6.XB-4 are connected to 'Ср. авар. конт. ДТм ШР фА 1 цепь'.
- Terminal blocks M8.XB-11, M8.XB-12 are connected to 'Изол. ДТм ШР фА авар 1 цепь'.

**Phase B (KS5):**

- Control unit KS5 is connected to phases X-89, X-90, and X-91.
- Terminal blocks M6.XB-11, M6.XB-12 are connected to 'Ср. сизн. конт. ДТм ШР фВ 1 цепь'.
- Terminal blocks M6.XB-5, M6.XB-6 are connected to 'Ср. авар. конт. ДТм ШР фВ 1 цепь'.
- Terminal blocks M8.XB-13, M8.XB-14 are connected to 'Изол. ДТм ШР фВ авар 1 цепь'.

**Phase C (KS6):**

- Control unit KS6 is connected to phases X-92, X-93, and X-94.
- Terminal blocks M6.XB-13, M6.XB-14 are connected to 'Ср. сизн. конт. ДТм ШР фС 1 цепь'.
- Terminal blocks M6.XB-7, M6.XB-8 are connected to 'Ср. авар. конт. ДТм ШР фС 1 цепь'.
- Terminal blocks M8.XB-15, M8.XB-16 are connected to 'Изол. ДТм ШР фС авар 1 цепь'.

The diagram also shows a common busbar for the three phases, labeled 'A1', and a 'Питание' (Power) section for each phase.