

Левая доковина (продолжение на листе 1)

		○ 49	X:49	A1-M5.XB-1
		○ 50		
		○ 51	X:51	A1-M5.XB-3
		○ 52		
		53	X:53	A1-M5.XB-5
		54	X:54	A1-M5.XB-7
		55	X:55	A1-M5.XB-9
		56	X:56	A1-M5.XB-11
		57	X:57	A1-M5.XB-13
		58		
		59		
		60		
		61		
		62		
		63		
		○ 64	X:64	A1-M8.XB-24
		○ 65	X:65	UZ14
	Цепи оперативного тока ГЗ			X
		○ 66	X:66	KS1-X1:1
		○ 67	X:67	A1-M6.XB-1
		○ 68		
		○ 69		
		70	X:70	A1-M5.XB-15
		71	X:71	KS1-X1:12
		72	X:72	A1-M5.XB-17
		73	X:73	KS2-X1:12
		74	X:74	A1-M5.XB-19
		75	X:75	KS3-X1:12
		76		
		77		
		78		
		79		
		○ 80	X:80	A1-M5.XB-16
		○ 81	X:81	R12
	Цепи оперативного тока ТЗ			X
		○ 82	X:82	KS4-X1:1
		○ 83	X:83	A1-M8.XB-17
		○ 84		
		○ 85		
		86	X:86	A1-M6.XB-9
		87	X:87	KS4-X1:12
		88	X:88	A1-M6.XB-11
		89	X:89	KS5-X1:12
		90	X:90	A1-M6.XB-13
		91	X:91	KS6-X1:12
		92	X:92	A1-M6.XB-21
		93	X:93	KS7-X1:12
		94	X:94	A1-M6.XB-23
		95	X:95	KS8-X1:12
		96	X:96	A1-M6.XB-25
		97	X:97	KS9-X1:12
		98	X:98	A1-M6.XB-27
		99	X:99	A1-M6.XB-29
		100	X:100	A1-M6.XB-31
		101	X:101	A1-M7.XB-1
		102	X:102	A1-M7.XB-3
		103	X:103	A1-M7.XB-5
		104	X:104	A1-M7.XB-7
		105	X:105	A1-M7.XB-9
		106	X:106	A1-M7.XB-11
		107	X:107	A1-M7.XB-13
		108	X:108	A1-M7.XB-15
		109	X:109	A1-M7.XB-17
		110	X:110	A1-M7.XB-19
		111	X:111	A1-M7.XB-21
		112	X:112	A1-M7.XB-23
		113	X:113	A1-M7.XB-25
		114	X:114	A1-M7.XB-27
		115	X:115	A1-M7.XB-29

Левая доковина (продолжение на листе 3)

Левая доковина (продолжение на листе 1)

		SA3-10	X:179	179		
		SA3-12	X:180	180		
		SA3-14	X:181	181		
		SA3-16	X:182	182		
		SA4-4	X:183	183		
		SA5-4	X:184	184		
		SA6-4	X:185	185		
		SA6-6	X:186	186		
		SA6-8	X:187	187		
		SA6-10	X:188	188		
		SA7-4	X:189	189		
		SA7-6	X:190	190		
		SA7-8	X:191	191		
		SA8-4	X:192	192		
		SA8-6	X:193	193		
		SA8-8	X:194	194		
		SA8-10	X:195	195		
		A1-M3.XB-25	X:196	196		
		A1-M3.XB-27	X:197	197		
		A1-M3.XB-29	X:198	198		
		A1-M3.XB-31	X:199	199		
		A1-M4.XB-1	X:200	200		
		A1-M4.XB-3	X:201	201		
		A1-M4.XB-5	X:202	202		
		A1-M4.XB-7	X:203	203		
		A1-M4.XB-9	X:204	204		
		A1-M4.XB-11	X:205	205		
		A1-M4.XB-13	X:206	206		
		A1-M4.XB-15	X:207	207		
		A1-M4.XB-17	X:208	208		
		X	Цепи сигнализации			
		A1-M1.XP-2	X:209	209○		
				210○		
				211○		
				212○		
				213		
				214		
				215		
				216		
				217		
				218		
				219		
				220		
		HL1:2	X:221	221○		
				222○		
		X	Цепи РАС			
		A1-M1.XP-5	X:223	223○		
		A1-M1.XP-15	X:224	224○		
				225		
		A1-M1.XP-4	X:226	226		
		A1-M1.XP-14	X:227	227		
		X	Цепи освещения			
		SQ1:11	X:228	228○		
				229○		
		SQ1:21	X:230	230○		
				231○		
		X	Резерв/Транзит			
				232		
				233		
				234		
				235		
				236		
				237		
				238		
				239		
				240		
				241		

Правая доковина (продолжение на листе 3)