

Левая доковина 2 секции (продолжение на листе 1)

	Цепи переменного тока В6			X	
		41	X:41	SG6:2	#
		42	X:42	SG6:4	#
		43	X:43	SG6:6	#
		44	X:44	SG6:8	#
		45	X:45	SG6:10	#
		46	X:46	SG6:12	#
			47		
			48		
	Цепи переменного тока В7			X	
		49	X:49	SG7:2	#
		50	X:50	SG7:4	#
		51	X:51	SG7:6	#
		52	X:52	SG7:8	#
		53	X:53	SG7:10	#
		54	X:54	SG7:12	#
			55		
			56		
	Цепи переменного тока В8			X	
		57	X:57	SG8:2	#
		58	X:58	SG8:4	#
		59	X:59	SG8:6	#
		60	X:60	SG8:8	#
		61	X:61	SG8:10	#
		62	X:62	SG8:12	#
			63		
			64		
	Цепи переменного тока В9			X	
		65	X:65	SG9:2	#
		66	X:66	SG9:4	#
		67	X:67	SG9:6	#
		68	X:68	SG9:8	#
		69	X:69	SG9:10	#
		70	X:70	SG9:12	#
			71		
			72		
	Цепи переменного тока В10 (СВ)			X	
		73	X:73	SG10:2	#
		74	X:74	SG10:4	#
		75	X:75	SG10:6	#
		76	X:76	SG10:8	#
		77	X:77	SG10:10	#
		78	X:78	SG10:12	#
			79		
			80		
	Цепи переменного напряжения 1 секции			X	
		81	X:81	SG11:2	+
		82	X:82	SG11:4	+
		83	X:83	SG11:6	+
		84	X:84	SG11:8	+
	Цепи переменного напряжения 2 секции			X	
		85	X:85	SG12:2	+
		86	X:86	SG12:4	+
		87	X:87	SG12:6	+
		88	X:88	SG12:8	+

Левая доковина 2 секции (продолжение на листе 3)

Правая доковина 2 секции (начало)

	SA1:4	X:185	185		
	SA1:6	X:186	186		
	SA1:8	X:187	187		
	SA1:10	X:188	188		
	SA2:4	X:189	189		
	SA2:6	X:190	190		
	SA2:8	X:191	191		
	SA2:10	X:192	192		
	SA3:4	X:193	193		
	SA3:6	X:194	194		
	SA3:8	X:195	195		
	SA3:10	X:196	196		
	SA4:4	X:197	197		
	SA4:6	X:198	198		
	SA4:8	X:199	199		
	SA4:10	X:200	200		
	SA5:4	X:201	201		
	SA5:6	X:202	202		
	SA5:8	X:203	203		
	SA5:10	X:204	204		
	SA6:4	X:205	205		
	SA6:6	X:206	206		
	SA6:8	X:207	207		
	SA6:10	X:208	208		
	SA7:4	X:209	209		
	SA7:6	X:210	210		
	SA7:8	X:211	211		
	SA7:10	X:212	212		
	SA8:4	X:213	213		
	SA8:6	X:214	214		
	SA8:8	X:215	215		
	SA8:10	X:216	216		
	SA9:4	X:217	217		
	SA9:6	X:218	218		
	SA9:8	X:219	219		
	SA9:10	X:220	220		
	SA10:4	X:221	221		
	SA10:6	X:222	222		
	SA10:8	X:223	223		
	SA10:10	X:224	224		
		X:225	225		
		X:226	226		
		X:227	227		
		X:228	228		
		X:229	229		
		X:230	230		
		X:231	231		
		X:232	232		
		X:233	233		
		X:234	234		
	X	Цепи сигнализации			
	A1-M1XP:2	X:235	235 		
			236 		
			237 		
			238 		
			239		
			240		
			241		
			242		
			243		
			244		
			245		
			246		
	HL1:2	X:247	247 		
			248 		

Правая доковина 2 секции (продолжение на листе 2)