

Левая боковина 2 секции (продолжение на листе 2)				
	Цепи оперативного тока			X
		○ 89	X:89	UZ1:1
		○ 90	X:90	SQ1:33
		○ 91		
		○ 92		
		○ 93		
		○ 94		
		○ 95		
		○ 96		
		○ 97		
		○ 98		
		○ 99		
		○ 100		
		○ 101		
		○ 102		
		○ 103	X:103	A1-M7.XB:1
		○ 104		
		○ 105		
		○ 106		
		○ 107		
		○ 108		
		○ 109	X:109	A1-M7.XB:2
		○ 110		
		○ 111		
		○ 112		
		○ 113		
		○ 114		
		115	X:115	A1-M7.XB:3
		116	X:116	A1-M7.XB:4
		117	X:117	A1-M7.XB:5
		118	X:118	A1-M7.XB:6
		119	X:119	A1-M7.XB:7
		120	X:120	A1-M7.XB:9
		121	X:121	A1-M7.XB:10
		122	X:122	A1-M7.XB:11
		123	X:123	A1-M7.XB:12
		124	X:124	A1-M7.XB:13
		125	X:125	A1-M7.XB:14
		126	X:126	A1-M7.XB:15
		127		
		128		
		139		
		130		
		131		
		132		
		○ 133	X:133	A1-M7.XB:8
		○ 134	X:134	UZ1:4

Правая боковина 2 секции (продолжение на листе 1)					
X	Цепи регистрации				
A1-M1.XP:5	X:249	249			
A1-M1.XP:15	X:250	250			
		251			
A1-M1.XP:4	X:252	252			
A1-M1.XP:14	X:253	253			
X	Освещение				
SQ1:11	X:254	254	○		
SQ3:11	X:255	255	○		
SQ1:21	X:256	256	○		
SQ3:21	X:257	257	○		
X	Резерв/Транзит				
		258			
		259			
		260			
		261			
		262			
		263			
		264			
		265			
		266			
		267			
		268			
		269			
		270			
		271			
		272			
		273			
		274			
		275			
		276			
		277			
		278			
		279			
		280			
		281			
		282			
		283			
		284			
		285			
		286			
		287			