

Левая доковина (начало)

	Цепи переменного тока группы 1 (B1)		X	
		1 X:1	SG1:2	#
		2 X:2	SG1:4	#
		3 X:3	SG1:6	#
		4 X:4	SG1:8	#
		5 X:5	SG1:10	#
		6 X:6	SG1:12	#
		7		
		8		
	Цепи переменного тока группы 2 (B2)		X	
		9 X:9	SG2:2	#
		10 X:10	SG2:4	#
		11 X:11	SG2:6	#
		12 X:12	SG2:8	#
		13 X:13	SG2:10	#
		14 X:14	SG2:12	#
		15		
		16		
	Цепи переменного тока 3 группы		X	
		17 X:17	SG3:2	#
		18 X:18	SG3:4	#
		19 X:19	SG3:6	#
		20 X:20	SG3:8	#
		21 X:21	SG3:10	#
		22 X:22	SG3:12	#
		23		
		24		
	Цепи переменного напряжения ошиновки		X	
		25 X:25	SG4:2	+
		26 X:26	SG4:4	+
		27 X:27	SG4:6	+
		28 X:28	SG4:8	+
	Цепи переменного напряжения элемента сети, расположенного за B1 (сторона Э1)		X	
		29 X:29	SG5:2	+
		30 X:30	SG5:4	+
		31 X:31	SG5:6	+
		32 X:32	SG5:8	+
	Цепи переменного напряжения элемента сети, расположенного за B2 (сторона Э2)		X	
		33 X:33	SG6:2	+
		34 X:34	SG6:4	+
		35 X:35	SG6:6	+
		36 X:36	SG6:8	+
	Резерв		X	
		37		
		38		
		39		
		40		

Левая доковина (продолжение на листе 2)

Условные обозначения

