

Левая боковина (начало)				
	Цепи переменного тока В1			X
		1	X:1	SG1:2
		2	X:2	SG1:4
		3	X:3	SG1:6
		4	X:4	SG1:8
		5	X:5	SG1:10
		6	X:6	SG1:12
		7		
		8		
	Цепи переменного тока В2(ОВ)			X
		9	X:9	SG2:2
		10	X:10	SG2:4
		11	X:11	SG2:6
		12	X:12	SG2:8
		13	X:13	SG2:10
		14	X:14	SG2:12
		15		
		16		
	Цепи переменного тока 310 параллельной линии			X
		17	X:17	SG3:2
		18	X:18	SG3:4
	Цепи переменного напряжения СШ/ЛЭП			X
		19	X:19	SG4:2
		20	X:20	SG4:4
		21	X:21	SG4:6
		22	X:22	SG4:8
		23	X:23	SG5:2
		24	X:24	SG5:4
		25	X:25	SG5:6
		26	X:26	SG5:8
	Цепи переменного напряжения ОВ			X
		27	X:27	SG6:2
		28	X:28	SG6:4
		29	X:29	SG6:6
		30	X:30	SG6:8
		31	X:31	SG7:2
		32	X:32	SG7:4
		33	X:33	SG7:6
		34	X:34	SG7:8

Левая боковина (окончание)				
	Цепи отбора напряжения ЛЭП			X
		35	X:35	SG8:2
		36	X:36	SG8:4
		37	X:37	SG8:6
	Цепи отбора напряжения Э1			X
		38	X:38	SG9:2
		39	X:39	SG9:4
		40	X:40	SG9:6
	Цепи отбора напряжения Э2			X
		41	X:41	SG10:2
		42	X:42	SG10:4
		43	X:43	SG10:6
	Цепи питания терминала			X
		44	X:44	UZ1:1
		45	X:45	SG1:14
		46	X:46	UZ1:4
		47	X:47	A1-M6.XB:2
	Цепи сигнализации			X
		48	X:48	A1-M1.XP:2
		49		
		50	X:50	HL1:2
		51		
	Освещение			X
		52	X:52	SQ1:11
		53		
		54	X:54	SQ1:21
		55		

