

Левая боковина (начало)					
	Цепи переменного тока В1			X	
		1	X:1	SG1:2	#
		2	X:2	SG1:4	#
		3	X:3	SG1:6	#
		4	X:4	SG1:8	#
		5	X:5	SG1:10	#
		6	X:6	SG1:12	#
		 7			
		 8			
	Цепи переменного тока В2			X	
		9	X:9	SG2:2	#
		10	X:10	SG2:4	#
		11	X:11	SG2:6	#
		12	X:12	SG2:8	#
		13	X:13	SG2:10	#
		14	X:14	SG2:12	#
		 15			
		 16			
	Цепи переменного тока 310 параллельной линии			X	
		17	X:17	SG3:2	#
		18	X:18	SG3:4	#
	Цепи переменного напряжения шин/ЛЭП			X	
		19	X:19	SG4:2	+
		20	X:20	SG4:4	+
		21	X:21	SG4:6	+
		22	X:22	SG4:8	+
		23	X:23	SG5:2	+
		24	X:24	SG5:4	+
		25	X:25	SG5:6	+
		26	X:26	SG5:8	+
	Цепи переменного напряжения ОВ			X	
		27	X:27	SG6:2	+
		28	X:28	SG6:4	+
		29	X:29	SG6:6	+
		30	X:30	SG6:8	+
		31	X:31	SG7:2	+
		32	X:32	SG7:4	+
		33	X:33	SG7:6	+
		34	X:34	SG7:8	+
	Цепи отбора напряжения ЛЭП			X	
		 35	X:35	SG8:2	+
		 36	X:36	SG8:4	+
		37	X:37	SG8:6	+
	Цепи отбора напряжения З1			X	
		 38	X:38	SG9:2	+
		 39	X:39	SG9:4	+
		40	X:40	SG9:6	+
Левая боковина (продолжение)					

Левая боковина (продолжение)					
	Цепи отбора напряжения З2			X	
		41	X:41	SG10:2	+
		42	X:42	SG10:4	+
		43	X:43	SG10:6	+
	Цепи питания терминала			X	
		44	X:44	UZ1:8	+
		45	X:45	A11-X4:1	—
		46	X:46	UZ1:11	+
		47	X:47	A11-X4:2	—
	Цепи сигнализации			X	
		48	X:48	A1-M1.XB:2	—
		49			
		50	X:50	HL1:2	—
		51			
	Цепи освещения			X	
		52	X:52	SQ1:11	КЧ WE2
		53	X:53		
		54	X:54	SQ1:21	С
		55	X:55		

Условные обозначения

