

Левая боковина (продолжение на листе 2)

Цепи оперативного тока			X
97	X:97	UZ11	
98	X:98	SG114	
99	X:99	SA11	
100	X:100	SQ133	
101			
102			
103			
104			
105			
106			
107			
108			
109	X:109	A1-M7.XB-1	
110	X:110	A1-M7.XB-3	
111	X:111	A1-M7.XB-5	
112	X:112	A1-M7.XB-7	
113	X:113	A1-M7.XB-9	
114	X:114	A1-M7.XB-11	
115	X:115	A1-M7.XB-13	
116	X:116	A1-M7.XB-15	
117	X:117	A1-M7.XB-17	
118	X:118	A1-M7.XB-19	
119	X:119	A1-M7.XB-21	
120	X:120	A1-M7.XB-23	
121	X:121	A1-M7.XB-25	
122	X:122	A1-M7.XB-27	
123	X:123	A1-M7.XB-29	
124	X:124	A1-M7.XB-31	
125	X:125	A1-M8.XB-1	
126	X:126	A1-M8.XB-3	
127	X:127	A1-M8.XB-5	
128	X:128	A1-M8.XB-7	
129	X:129	A1-M8.XB-9	
130			
131			
132			
133			
134	X:134	UZ14	
135	X:134	A1-M9.XB-18	

Правая боковина (продолжение на листе 2)

SA7:8	X:251	251		
SA7:10	X:252	252		
SA8:4	X:253	253		
SA8:6	X:254	254		
SA8:8	X:255	255		
SA8:10	X:256	256		
SA9:4	X:257	257		
SA9:6	X:258	258		
SA9:8	X:259	259		
SA9:10	X:260	260		
SA10:4	X:261	261		
SA10:6	X:262	262		
SA10:8	X:263	263		
SA10:10	X:264	264		
		265		
		266		
		267		
		268		
		269		
		270		
		271		
		272		
		273		
		274		
X	Цепи сигнализации			
A1-M1XP-2	X:275	275		
		276		
		277		
		278		
		279		
		280		
		281		
		282		
		283		
		284		
		285		
		286		
HL12	X:287	287		
		288		
X	Цепи регистрации			
A1-M1XP-5	X:289	289		
A1-M1XP-15	X:290	290		
A1-M1XP-4	X:291	291		
A1-M1XP-14	X:292	292		
		293		
X	Освещение			
SQ1:11		294		
SQ3:11		295		
SQ1:21		296		
SQ3:21		297		

Правая боковина (продолжение на листе 4)

WE2
WE4

кч
кч
с
с