

2 секция. Левая баковина (продолжение на листе 2)

	Цепи переменного тока В13		X	
	97	X-97	SG13-2	#
	98	X-98	SG13-4	#
	99	X-99	SG13-6	#
	100	X-100	SG13-8	#
	101	X-101	SG13-10	#
	102	X-102	SG13-12	#
	103			
	104			
	Цепи переменного тока В14		X	
	105	X-105	SG14-2	#
	106	X-106	SG14-4	#
	107	X-107	SG14-6	#
	108	X-108	SG14-8	#
	109	X-109	SG14-10	#
	110	X-110	SG14-12	#
	111			
	112			
	Цепи переменного тока В15		X	
	113	X-113	SG15-2	#
	114	X-114	SG15-4	#
	115	X-115	SG15-6	#
	116	X-116	SG15-8	#
	117	X-117	SG15-10	#
	118	X-118	SG15-12	#
	119			
	120			
	Цепи переменного тока СВ1		X	
	121	X-121	SG16-2	#
	122	X-122	SG16-4	#
	123	X-123	SG16-6	#
	124	X-124	SG16-8	#
	125	X-125	SG16-10	#
	126	X-126	SG16-12	#
	127			
	128			
	Цепи переменного тока СВ2		X	
	129	X-129	SG17-2	#
	130	X-130	SG17-4	#
	131	X-131	SG17-6	#
	132	X-132	SG17-8	#
	133	X-133	SG17-10	#
	134	X-134	SG17-12	#
	135			
	136			
	Цепи переменного тока ОВ		X	
	137	X-137	SG18-2	#
	138	X-138	SG18-4	#
	139	X-139	SG18-6	#
	140	X-140	SG18-8	#
	141	X-141	SG18-10	#
	142	X-142	SG18-12	#
	143			
	144			
	Цепи переменного тока ШСВ стороны 1 секции		X	
	145	X-145	SG19-2	#
	146	X-146	SG19-4	#
	147	X-147	SG19-6	#
	148	X-148	SG19-8	#
	149	X-149	SG19-10	#
	150	X-150	SG19-12	#
	151			
	152			

2 секция. Левая баковина (продолжение на листе 4)

2 секция. Правая баковина (продолжение на листе 2)

KL14-31	X-357	357		
A1-M3.XB-24	X-358	358		
KL15-11	X-359	359		
KL15-21	X-360	360		
KL15-31	X-361	361		
A1-M3.XB-28	X-362	362		
KL16-11	X-363	363		
KL16-21	X-364	364		
KL16-31	X-365	365		
A1-M3.XB-32	X-366	366		
KL17-11	X-367	367		
KL17-21	X-368	368		
KL17-31	X-369	369		
A1-M4.XB-4	X-370	370		
KL18-11	X-371	371		
KL18-21	X-372	372		
KL18-31	X-373	373		
A1-M4.XB-8	X-374	374		
KL19-11	X-375	375		
KL19-21	X-376	376		
KL19-31	X-377	377		
A1-M4.XB-12	X-378	378		
		379		
		380		
		381		
		382		
		383		
		384		
		385		
		386		
		387		
SA14	X-388	388		
SA16	X-389	389		
SA18	X-390	390		
SA110	X-391	391		
SA24	X-392	392		
SA26	X-393	393		
SA28	X-394	394		
SA210	X-395	395		
SA34	X-396	396		
SA36	X-397	397		
SA38	X-398	398		
SA310	X-399	399		
SA44	X-400	400		
SA46	X-401	401		
SA48	X-402	402		
SA410	X-403	403		
SA54	X-404	404		
SA56	X-405	405		
SA58	X-406	406		
SA510	X-407	407		
SA64	X-408	408		
SA66	X-409	409		
SA68	X-410	410		
SA610	X-411	411		
SA74	X-412	412		
SA76	X-413	413		
SA78	X-414	414		
SA710	X-415	415		
SA84	X-416	416		
SA86	X-417	417		
SA88	X-418	418		
SA810	X-419	419		
SA94	X-420	420		
SA96	X-421	421		
SA98	X-422	422		
SA910	X-423	423		
SA104	X-424	424		
SA106	X-425	425		
SA108	X-426	426		

2 секция. Правая баковина (продолжение на листе 4)