

Левая боковина 1 секции

X		Цепи сигнализации		
—	A1-M1.XP:2	X:383	383 ○	
			384 ○	
			385 ○	
			386 ○	
			387	
			388	
			389	
			390	
			391	
			392	
			393	
			394	
—	HL1:2	X:395	395 ○	
			396 ○	
X		Цепи регистрации		
—	A1-M1.XP:5	X:397	397	
—	A1-M1.XP:15	X:398	398	
			399	
—	A1-M1.XP:4	X:400	400	
—	A1-M1.XP:14	X:401	401	
X		Освещение		
WE2	КЧ	SQ1:11	X:402	402 ○
WE4	КЧ	SQ3:11	X:403	403 ○
	С	SQ1:21	X:404	404 ○
	С	SQ3:21	X:405	405 ○
X		Резерв/Транзит		
			406	
			407	
			408	
			409	
			410	
			411	
			412	
			413	
			414	
			415	
			416	
			417	
			418	
			419	
			420	
			421	
			422	
			423	
			424	
			425	
			426	
			427	
			428	
			429	
			430	
			431	
			432	
			433	
			434	
			435	