

Левая баковина (продолжение на листе 1)

	Цепи переменного напряжения (НН, СН)			X
		49	X:49	SG9-2
		50	X:50	SG9-4
		51	X:51	SG9-6
		52		
	Цепи переменного напряжения (НН, СН)			X
		53	X:53	SG10-2
		54	X:54	SG10-4
		55	X:55	SG10-6
		56		
	Цепи оперативного тока терминала А1			X
+EC1		57	X:57	SQ1-33
		58	X:58	UZ1-1
		59		
X:310	X:60	60		
		61	X:61	A1-M5.XB-1
		62		
X:314	X:63	63		
		64	X:64	A1-M5.XB-3
		65		
		66	X:66	A1-M5.XB-5
		67	X:67	A1-M5.XB-7
		68	X:68	A1-M5.XB-9
		69	X:69	A1-M5.XB-11
		70	X:70	A1-M5.XB-13
		71	X:71	A1-M5.XB-15
		72	X:72	A1-M5.XB-17
		73		
		74		
		75		
		76		
		77		
		78		
		79		
		80		
-EC1		81	X:81	K1-A2
		82	X:82	UZ1-4
	Цепи оперативного тока ГЗ Т			X
+EC2		83	X:83	KS1-X1-1
		84	X:84	A1-M5.XB-29
		85		
		86	X:86	A1-M5.XB-19
		87	X:87	KS1-X1-12
		88	X:88	KS2-X1-12
		89		
		90		
-EC2		91	X:91	A1-M5.XB-20
		92	X:92	R2-2
	Цепи оперативного тока ТЗ Т			X
+EC3		93	X:93	KS3-X1-1
		94	X:94	A1-M6.XB-29
		95		
		96		
		97		
		98	X:98	A1-M6.XB-1
		99	X:99	KS3-X1-12
		100	X:100	A1-M6.XB-5
		101	X:101	KS4-X1-12
		102	X:102	A1-M6.XB-7
		103	X:103	A1-M6.XB-9
		104	X:104	A1-M6.XB-11
		105	X:105	A1-M6.XB-13
		106	X:106	A1-M6.XB-15
		107	X:107	A1-M6.XB-17
		108	X:108	A1-M6.XB-19
		109	X:109	A1-M6.XB-21
		110	X:110	A1-M6.XB-23

Левая баковина (продолжение на листе 3)

Правая баковина (продолжение на листе 1)

	SA2-4	X:215	215		
	SA2-6	X:216	216		
	SA3-4	X:217	217		
	SA3-6	X:218	218		
	SA3-8	X:219	219		
	SA4-4	X:220	220		
	SA4-6	X:221	221		
	SA5-4	X:222	222		
	SA5-6	X:223	223		
	SA5-8	X:224	224		
	SA6-4	X:225	225		
	SA6-6	X:226	226		
	SA7-4	X:227	227		
	SA7-6	X:228	228		
	SA7-8	X:229	229		
	SA8-4	X:230	230		
	SA8-6	X:231	231		
	SA9-4	X:232	232		
	SA9-6	X:233	233		
	SA9-8	X:234	234		
	SA10-4	X:235	235		
	SA10-6	X:236	236		
	SA10-8	X:237	237		
	SA11-4	X:238	238		
	SA12-4	X:239	239		
	SA13-4	X:240	240		
	SA14-4	X:241	241		
	SA15-4	X:242	242		
	SA15-6	X:243	243		
	SA16-4	X:244	244		
	A1-M4.XB-3	X:245	245		
	A1-M4.XB-5	X:246	246		
	A1-M4.XB-7	X:247	247		
	A1-M4.XB-9	X:248	248		
	A1-M4.XB-11	X:249	249		
	A1-M4.XB-13	X:250	250		
	A1-M4.XB-15	X:251	251		
			252		
			253		
			254		
			255		
			256		
			257		
			258		
			259		
			260		
			261		
			262		
	X	Цепи сигнализации А1			
A1-M1.XP-2	X:263	263		+EH1	
		264			
		265		(+)EH1	
		266			
		267			
		268			
A1-M1.XP-3	X:269	269	X:269	X:326	
		270			
		271			
		272			
		273			
		274			
HL1-2	X:275	275		-EH1	
		276	X:276	X:333	

Правая баковина (продолжение на листе 3)