

Левая баковина (продолжение на листе 1)

	Цепи переменного тока В6			X	
		41	X:41	SG6:2	#
		42	X:42	SG6:4	#
		43	X:43	SG6:6	#
		44	X:44	SG6:8	#
		45	X:45	SG6:10	#
		46	X:46	SG6:12	#
		47			
		48			
	Цепи переменного тока В7			X	
		49	X:49	SG7:2	#
		50	X:50	SG7:4	#
		51	X:51	SG7:6	#
		52	X:52	SG7:8	#
		53	X:53	SG7:10	#
		54	X:54	SG7:12	#
		55			
		56			
	Цепи переменного тока В8			X	
		57	X:57	SG8:2	#
		58	X:58	SG8:4	#
		59	X:59	SG8:6	#
		60	X:60	SG8:8	#
		61	X:61	SG8:10	#
		62	X:62	SG8:12	#
		63			
		64			
	Цепи переменного тока В9 (ОВ)			X	
		65	X:65	SG9:2	#
		66	X:66	SG9:4	#
		67	X:67	SG9:6	#
		68	X:68	SG9:8	#
		69	X:69	SG9:10	#
		70	X:70	SG9:12	#
		71			
		72			
	Цепи переменного тока СВ стороны 1 секции			X	
		73	X:73	SG10:2	#
		74	X:74	SG10:4	#
		75	X:75	SG10:6	#
		76	X:76	SG10:8	#
		77	X:77	SG10:10	#
		78	X:78	SG10:12	#
		79			
		80			
	Цепи переменного тока СВ стороны 2 секции			X	
		81	X:81	SG11:2	#
		82	X:82	SG11:4	#
		83	X:83	SG11:6	#
		84	X:84	SG11:8	#
		85	X:85	SG11:10	#
		86	X:86	SG11:12	#
		87			
		88			
	Цепи переменного напряжения 1 секции			X	
		89	X:89	SG12:2	+
		90	X:90	SG12:4	+
		91	X:91	SG12:6	+
		92			

Левая баковина (продолжение на листе 3)

Правая баковина (продолжение на листе 1)

		201		
		202		
—	SA1:4	X:203	203	
—	SA1:6	X:204	204	
—	SA1:8	X:205	205	
—	SA1:10	X:206	206	
—	SA2:4	X:207	207	
—	SA2:6	X:208	208	
—	SA2:8	X:209	209	
—	SA2:10	X:210	210	
—	SA3:4	X:211	211	
—	SA3:6	X:212	212	
—	SA3:8	X:213	213	
—	SA3:10	X:214	214	
—	SA4:4	X:215	215	
—	SA4:6	X:216	216	
—	SA4:8	X:217	217	
—	SA4:10	X:218	218	
—	SA5:4	X:219	219	
—	SA5:6	X:220	220	
—	SA5:8	X:221	221	
—	SA5:10	X:222	222	
—	SA6:4	X:223	223	
—	SA6:6	X:224	224	
—	SA6:8	X:225	225	
—	SA6:10	X:226	226	
—	SA7:4	X:227	227	
—	SA7:6	X:228	228	
—	SA7:8	X:229	229	
—	SA7:10	X:230	230	
—	SA8:4	X:231	231	
—	SA8:6	X:232	232	
—	SA8:8	X:233	233	
—	SA8:10	X:234	234	
—	SA9:4	X:235	235	
—	SA9:6	X:236	236	
—	SA9:8	X:237	237	
—	SA9:10	X:238	238	
—	SA10:4	X:239	239	
—	SA10:6	X:240	240	
—	SA10:8	X:241	241	
—	SA10:10	X:242	242	
		243		
		244		
		245		
		246		
		247		
		248		
		249		
		250		
		251		
		252		
	X	Цепи сигнализации		
—	A1-M1.XP:2	X:253	253 	
			254 	
			255 	
			256 	
			257	
			258	
			259	
			260	
			261	
			262	
			263	
			264	

Правая баковина (продолжение на листе 3)