

Левая баковина (продолжение на листе 1)

	Цепи переменного тока В6			X	
		41	X:41	SG6-2	#
		42	X:42	SG6-4	#
		43	X:43	SG6-6	#
		44	X:44	SG6-8	#
		45	X:45	SG6-10	#
		46	X:46	SG6-12	#
		47			
		48			
	Цепи переменного тока В7			X	
		49	X:49	SG7-2	#
		50	X:50	SG7-4	#
		51	X:51	SG7-6	#
		52	X:52	SG7-8	#
		53	X:53	SG7-10	#
		54	X:54	SG7-12	#
		55			
		56			
	Цепи переменного тока В8			X	
		57	X:57	SG8-2	#
		58	X:58	SG8-4	#
		59	X:59	SG8-6	#
		60	X:60	SG8-8	#
		61	X:61	SG8-10	#
		62	X:62	SG8-12	#
		63			
		64			
	Цепи переменного тока В9 (ОВ)			X	
		65	X:65	SG9-2	#
		66	X:66	SG9-4	#
		67	X:67	SG9-6	#
		68	X:68	SG9-8	#
		69	X:69	SG9-10	#
		70	X:70	SG9-12	#
		71			
		72			
	Цепи переменного тока СВ стороны 1 секции			X	
		73	X:73	SG10-2	#
		74	X:74	SG10-4	#
		75	X:75	SG10-6	#
		76	X:76	SG10-8	#
		77	X:77	SG10-10	#
		78	X:78	SG10-12	#
		79			
		80			
	Цепи переменного тока СВ стороны 2 секции			X	
		81	X:81	SG11-2	#
		82	X:82	SG11-4	#
		83	X:83	SG11-6	#
		84	X:84	SG11-8	#
		85	X:85	SG11-10	#
		86	X:86	SG11-12	#
		87			
		88			
	Цепи переменного напряжения 1 секции			X	
		89	X:89	SG12-2	+
		90	X:90	SG12-4	+
		91	X:91	SG12-6	+
		92			

Левая баковина (продолжение на листе 3)

Правая баковина (продолжение на листе 1)

		201		
		202		
SA1-4	X:203	203		
SA1-6	X:204	204		
SA1-8	X:205	205		
SA1-10	X:206	206		
SA2-4	X:207	207		
SA2-6	X:208	208		
SA2-8	X:209	209		
SA2-10	X:210	210		
SA3-4	X:211	211		
SA3-6	X:212	212		
SA3-8	X:213	213		
SA3-10	X:214	214		
SA4-4	X:215	215		
SA4-6	X:216	216		
SA4-8	X:217	217		
SA4-10	X:218	218		
SA5-4	X:219	219		
SA5-6	X:220	220		
SA5-8	X:221	221		
SA5-10	X:222	222		
SA6-4	X:223	223		
SA6-6	X:224	224		
SA6-8	X:225	225		
SA6-10	X:226	226		
SA7-4	X:227	227		
SA7-6	X:228	228		
SA7-8	X:229	229		
SA7-10	X:230	230		
SA8-4	X:231	231		
SA8-6	X:232	232		
SA8-8	X:233	233		
SA8-10	X:234	234		
SA9-4	X:235	235		
SA9-6	X:236	236		
SA9-8	X:237	237		
SA9-10	X:238	238		
SA10-4	X:239	239		
SA10-6	X:240	240		
SA10-8	X:241	241		
SA10-10	X:242	242		
		243		
		244		
		245		
		246		
		247		
		248		
		249		
		250		
		251		
		252		
X	Цепи сигнализации			
A1-M1.XP-2	X:253	253 		
		254 		
		255 		
		256 		
		257		
		258		
		259		
		260		
		261		
		262		
		263		
		264		

Правая баковина (продолжение на листе 3)