

Левая баковина (продолжение на листе 2)

	Цепи переменного напряжения 2 секции		X
	93	X:90	SG12-2
	94	X:94	SG12-4
	95	X:95	SG12-6
	96		
	Цепи оперативного тока		X
	97	X:97	UZ1:1
	98	X:98	SG1:14
	99		
	100		
	101		
	102		
	103		
	104		
	105		
	106		
	107		
	108		
	109		
	110		
	111	X:111	A1-M7.XB-1
	112		
	113		
	114		
	115		
	116		
	117	X:117	A1-M7.XB-3
	118		
	119		
	120		
	121		
	122		
	123	X:123	A1-M7.XB-5
	124	X:124	A1-M7.XB-7
	125	X:125	A1-M7.XB-9
	126	X:126	A1-M7.XB-11
	127	X:127	A1-M7.XB-13
	128	X:128	A1-M7.XB-15
	129	X:129	A1-M7.XB-17
	130	X:130	A1-M7.XB-19
	131	X:131	A1-M7.XB-21
	132	X:132	A1-M7.XB-23
	133	X:133	A1-M7.XB-25
	134	X:134	A1-M7.XB-27
	135		
	136		
	137		
	138		
	139		
	140		
	141	X:141	UZ1:4
	142	X:142	A1-M8.XB-4
	Цепи фиксации ОБ		X
	143	X:143	A1-M8.XB-1
	144		
	145		
	146	X:146	A1-M7.XB-29
	147	X:147	A1-M7.XB-31
	148		
	149		
	150		
	151	X:151	A1-M8.XB-2
	152		

Правая баковина (продолжение на листе 2)

	HL1:2	X:265	265		
			266		
	X	Цепи регистрации			
	A1-M1.XP-5	X:267	267		
	A1-M1.XP-15	X:268	268		
			269		
	A1-M1.XP-4	X:270	270		
	A1-M1.XP-14	X:271	271		
	X	Освещение			
WE2	SQ1:11	X:272	272		
WE4	SQ3:11	X:273	273		
	SQ1:21	X:274	274		
	SQ3:21	X:275	275		
	X	Резерв/Транзит			
			276		
			277		
			278		
			279		
			280		
			281		
			282		
			283		
			284		
			285		
			286		
			287		
			288		
			289		
			290		
			291		
			292		
			293		
			294		
			295		
			296		
			297		
			298		
			299		
			300		
			301		
			302		
			303		
			304		
			305		