

Левая боковина 2 секции (продолжение на листе 1)

	Цепи переменного тока В6			X	
		41	X:41	SG6-2	#
		42	X:42	SG6-4	#
		43	X:43	SG6-6	#
		44	X:44	SG6-8	#
		45	X:45	SG6-10	#
		46	X:46	SG6-12	#
		47			
		48			
	Цепи переменного тока В7			X	
		49	X:49	SG7-2	#
		50	X:50	SG7-4	#
		51	X:51	SG7-6	#
		52	X:52	SG7-8	#
		53	X:53	SG7-10	#
		54	X:54	SG7-12	#
		55			
		56			
	Цепи переменного тока В8			X	
		57	X:57	SG8-2	#
		58	X:58	SG8-4	#
		59	X:59	SG8-6	#
		60	X:60	SG8-8	#
		61	X:61	SG8-10	#
		62	X:62	SG8-12	#
		63			
		64			
	Цепи переменного тока В9			X	
		65	X:65	SG9-2	#
		66	X:66	SG9-4	#
		67	X:67	SG9-6	#
		68	X:68	SG9-8	#
		69	X:69	SG9-10	#
		70	X:70	SG9-12	#
		71			
		72			
	Цепи переменного тока В10			X	
		73	X:73	SG10-2	#
		74	X:74	SG10-4	#
		75	X:75	SG10-6	#
		76	X:76	SG10-8	#
		77	X:77	SG10-10	#
		78	X:78	SG10-12	#
		79			
		80			
	Цепи переменного тока В11			X	
		81	X:81	SG11-2	#
		82	X:82	SG11-4	#
		83	X:83	SG11-6	#
		84	X:84	SG11-8	#
		85	X:85	SG11-10	#
		86	X:86	SG11-12	#
		87			
		88			
	Цепи переменного тока В12			X	
		89	X:81	SG12-2	#
		90	X:82	SG12-4	#
		91	X:83	SG12-6	#
		92	X:84	SG12-8	#
		93	X:85	SG12-10	#
		94	X:86	SG12-12	#
		95			
		96			

Левая боковина 2 секции (продолжение на листе 3)

Правая боковина 2 секции (начало)

A1-M7.XB-17	X:211	211		
A1-M7.XB-18	X:212	212		
A1-M7.XB-19	X:213	213		
A1-M7.XB-20	X:214	214		
A1-M7.XB-21	X:215	215		
A1-M7.XB-22	X:216	216		
A1-M7.XB-23	X:217	217		
A1-M7.XB-25	X:218	218		
		219		
		220		
UZ1:4	X:221	221		
A1-M7.XB-8	X:222	222		
X	Цепи фиксации ОБ			
A1-M9.XB-15	X:223	223		
		224		
		225		
A1-M9.XB-11	X:226	226		
A1-M9.XB-13	X:227	227		
		228		
		229		
		230		
A1-M9.XB-12	X:231	231		
		232		
X	Выходные цепи			
A1-M2.XB-2	X:233	233		
A1-M2.XB-4	X:234	234		
A1-M2.XB-6	X:235	235		
A1-M2.XB-8	X:236	236		
A1-M2.XB-10	X:237	237		
A1-M2.XB-12	X:238	238		
A1-M2.XB-14	X:239	239		
A1-M2.XB-16	X:240	240		
A1-M2.XB-18	X:241	241		
A1-M2.XB-20	X:242	242		
A1-M2.XB-22	X:243	243		
A1-M2.XB-24	X:244	244		
A1-M2.XB-26	X:245	245		
A1-M2.XB-28	X:246	246		
A1-M2.XB-30	X:247	247		
A1-M2.XB-32	X:248	248		
A1-M3.XB-2	X:249	249		
A1-M3.XB-4	X:250	250		
A1-M3.XB-6	X:251	251		
A1-M3.XB-8	X:252	252		
A1-M3.XB-10	X:253	253		
A1-M3.XB-12	X:254	254		
A1-M3.XB-14	X:255	255		
A1-M3.XB-16	X:256	256		
A1-M3.XB-18	X:257	257		
A1-M3.XB-20	X:258	258		
A1-M3.XB-22	X:259	259		
A1-M3.XB-24	X:260	260		
A1-M3.XB-26	X:261	261		
A1-M3.XB-28	X:262	262		
A1-M3.XB-30	X:263	263		
A1-M3.XB-32	X:264	264		
A1-M4.XB-2	X:265	265		
A1-M4.XB-4	X:266	266		
A1-M4.XB-6	X:267	267		
A1-M4.XB-8	X:268	268		
A1-M4.XB-10	X:269	269		
A1-M4.XB-12	X:270	270		
A1-M4.XB-14	X:271	271		
A1-M4.XB-16	X:272	272		
A1-M4.XB-18	X:273	273		
A1-M4.XB-20	X:274	274		
A1-M4.XB-22	X:275	275		
A1-M4.XB-24	X:276	276		

Правая боковина 2 секции (продолжение на листе 2)