

Левая боковина (продолжение на листе 1)

		41		
		42		
		43		
		44		
		45		
		46		
		47		
		48		
		49		
		50		
		51		
		52		
		53		
		54	X2-54	UZ2-4
		55	X2-55	A2-M6.XB-8
	Выходные цепи		X2	
		56	X2-56	A2-M2.XB-2
		57	X2-57	A2-M3.XB-14
		58	X2-58	A2-M3.XB-16
		59	X2-59	A2-M2.XB-4
		60	X2-60	A2-M3.XB-18
		61	X2-61	A2-M3.XB-20
		62	X2-62	A2-M2.XB-6
		63	X2-63	A2-M2.XB-8
		64	X2-64	A2-M2.XB-10
		65	X2-65	A2-M3.XB-22
		66	X2-66	A2-M3.XB-24
		67	X2-67	A2-M2.XB-12
		68	X2-68	A2-M3.XB-26
		69	X2-69	A2-M3.XB-28
		70	X2-70	A2-M2.XB-14
		71	X2-71	A2-M2.XB-16
		72	X2-72	A2-M2.XB-18
		73	X2-73	A2-M3.XB-30
		74	X2-74	A2-M3.XB-32
		75	X2-75	A2-M2.XB-20
		76	X2-76	A2-M4.XB-2
		77	X2-77	A2-M4.XB-4
		78	X2-78	A2-M2.XB-22
		79	X2-79	A2-M2.XB-24
		80	X2-80	A2-M2.XB-26
		81	X2-81	A2-M4.XB-6
		82	X2-82	A2-M4.XB-8
		83	X2-83	A2-M2.XB-28
		84	X2-84	A2-M4.XB-10
		85	X2-85	A2-M4.XB-12
		86	X2-86	A2-M2.XB-30
		87	X2-87	A2-M2.XB-32
		88	X2-88	A2-M3.XB-2
		89	X2-89	A2-M3.XB-4
		90	X2-90	A2-M3.XB-6
		91	X2-91	A2-M3.XB-8
		92	X2-92	A2-M3.XB-10
		93	X2-93	A2-M3.XB-12
		94		
		95		
		96	X2-96	SA11-4
		97	X2-97	SA11-6
		98	X2-98	SA11-8
		99	X2-99	SA11-10
		100	X2-100	SA11-12
		101	X2-101	SA11-14
		102	X2-102	SA11-16
		103	X2-103	SA12-4
		104	X2-104	SA13-4
		105	X2-105	SA13-6
		106	X2-106	SA13-8
		107	X2-107	SA13-10
		108	X2-108	SA13-12
		109	X2-109	SA13-14

Левая боковина (продолжение на листе 3)

Правая боковина (продолжение на листе 1)

		41		
		42		
		43		
		44		
		45		
		46		
		47		
		48		
		49		
		50		
		51		
		52		
		53		
UZ1-4	X1-54	54		
A1-M6.XB-8	X1-55	55		
X1	Выходные цепи			
A1-M2.XB-2	X1-56	56		
A1-M3.XB-14	X1-57	57		
A1-M3.XB-16	X1-58	58		
A1-M2.XB-4	X1-59	59		
A1-M3.XB-18	X1-60	60		
A1-M3.XB-20	X1-61	61		
A1-M2.XB-6	X1-62	62		
A1-M2.XB-8	X1-63	63		
A1-M2.XB-10	X1-64	64		
A1-M3.XB-22	X1-65	65		
A1-M3.XB-24	X1-66	66		
A1-M2.XB-12	X1-67	67		
A1-M3.XB-26	X1-68	68		
A1-M3.XB-28	X1-69	69		
A1-M2.XB-14	X1-70	70		
A1-M2.XB-16	X1-71	71		
A1-M2.XB-18	X1-72	72		
A1-M3.XB-30	X1-73	73		
A1-M3.XB-32	X1-74	74		
A1-M2.XB-20	X1-75	75		
A1-M4.XB-2	X1-76	76		
A1-M4.XB-4	X1-77	77		
A1-M2.XB-22	X1-78	78		
A1-M2.XB-24	X1-79	79		
A1-M2.XB-26	X1-80	80		
A1-M4.XB-6	X1-81	81		
A1-M4.XB-8	X1-82	82		
A1-M2.XB-28	X1-83	83		
A1-M4.XB-10	X1-84	84		
A1-M4.XB-12	X1-85	85		
A1-M2.XB-30	X1-86	86		
A1-M2.XB-32	X1-87	87		
A1-M3.XB-2	X1-88	88		
A1-M3.XB-4	X1-89	89		
A1-M3.XB-6	X1-90	90		
A1-M3.XB-8	X1-91	91		
A1-M3.XB-10	X1-92	92		
A1-M3.XB-12	X1-93	93		
		94		
		95		
SA1-4	X1-96	96		
SA1-6	X1-97	97		
SA1-8	X1-98	98		
SA1-10	X1-99	99		
SA1-12	X1-100	100		
SA1-14	X1-101	101		
SA1-16	X1-102	102		
SA2-4	X1-103	103		
SA3-4	X1-104	104		
SA3-6	X1-105	105		
SA3-8	X1-106	106		
SA3-10	X1-107	107		
SA3-12	X1-108	108		
SA3-14	X1-109	109		

Правая боковина (продолжение на листе 3)