

Левая боковина (начало)					
	Цепи переменного тока /ЛЭП			X	
		1	X:1	SG1:2	#
		2	X:2	SG1:4	#
		3	X:3	SG1:6	#
		4	X:4	SG1:8	#
		5	X:5	SG1:10	#
		6	X:6	SG1:12	#
		○ 7			
		○ 8			
	Цепи переменного тока 3Io /ЛЭП			X	
		9	X:9	SG2:2	#
		10	X:10	SG2:4	#
	Цепи переменного напряжения			X	
		11	X:11	SG3:2	+
		12	X:12	SG3:4	+
		13	X:13	SG3:6	+
		14	X:14	SG3:8	+
		15	X:15	SG4:2	+
		16	X:16	SG4:4	+
		17	X:17	SG4:6	+
		18	X:18	SG4:8	+
	Цепи отбора напряжения /ЛЭП			X	
		○ 19	X:19	SG5:2	+
		○ 20	X:20	SG5:4	+
		21	X:21	SG5:6	+
	Цепи оперативного тока			X	
		○ 22	X:22	UZ1:1	+
		○ 23	X:23	SG1:14	—
		○ 24			
		○ 25			
		○ 26			
		○ 27			
		○ 28			
		29	X:29	A1-M5.XB:1	—
		30	X:30	A1-M5.XB:3	—
		31	X:31	A1-M5.XB:5	—
		32	X:32	A1-M5.XB:7	—
		33	X:33	A1-M5.XB:9	—
		34	X:34	A1-M5.XB:11	—
		35	X:35	A1-M5.XB:13	—
		36	X:36	A1-M5.XB:15	—
		37	X:37	A1-M5.XB:17	—
		38	X:38	A1-M5.XB:19	—
		39			
		40			
		41			

Левая боковина (продолжение на листе 2)

Условные обозначения

