

Левая боковина (начало)					
	Цепи переменного тока ВН			X	
		1	X:1	SG1:2	#
		2	X:2	SG1:4	#
		3	X:3	SG1:6	#
		4	X:4	SG1:8	#
		5	X:5	SG1:10	#
		6	X:6	SG1:12	#
		○ 7			
		○ 8			
	Цепи переменного тока СН			X	
		9	X:9	SG2:2	#
		10	X:10	SG2:4	#
		11	X:11	SG2:6	#
		12	X:12	SG2:8	#
		13	X:13	SG2:10	#
		14	X:14	SG2:12	#
		○ 15			
		○ 16			
	Цепи переменного напряжения НН1 (НН)			X	
		17	X:17	SG3:2	+
		18	X:18	SG3:4	+
		19	X:19	SG3:6	+
		20			
	Цепи переменного напряжения НН2			X	
		21	X:21	SG4:2	+
		22	X:22	SG4:4	+
		23	X:23	SG4:6	+
		24			
	Цепи переменного напряжения НН3 (СН)			X	
		25	X:25	SG5:2	+
		26	X:26	SG5:4	+
		27	X:27	SG5:6	+
		28			
	Цепи переменного напряжения НН4			X	
		29	X:29	SG6:2	+
		30	X:30	SG6:4	+
		31	X:31	SG6:6	+
		32			
	Цепи оперативного тока			X	
		○ 33	X:33	UZ1:1	+
		○ 34	X:34	SG1:14	—
		○ 35			
		○ 36			
		○ 37	X:37	A1-M5.XB:1	—
		○ 38			
		○ 39			
		○ 40			

Левая боковина (продолжение на листе 2)

Условные обозначения

