

Левая боковина (продолжение на листе 2)

	Цепи оперативного тока			X
	○ 97	X:97	UZ1:1	
	○ 98	X:98	SG1:14	
	○ 99	X:99	SA1:1	
	○ 100	X:100	SQ1:33	
	○ 101			
	○ 102			
	○ 103			
	○ 104			
	○ 105			
	○ 106			
	○ 107			
	○ 108			
	109	X:109	A1-M7.XB:1	
	110	X:110	A1-M7.XB:3	
	111	X:111	A1-M7.XB:5	
	112	X:112	A1-M7.XB:7	
	113	X:113	A1-M7.XB:9	
	114	X:114	A1-M7.XB:11	
	115	X:115	A1-M7.XB:13	
	116	X:116	A1-M7.XB:15	
	117	X:117	A1-M7.XB:17	
	118	X:118	A1-M7.XB:19	
	119	X:119	A1-M7.XB:21	
	120	X:120	A1-M7.XB:23	
	121	X:121	A1-M7.XB:25	
	122	X:122	A1-M7.XB:27	
	123	X:123	A1-M7.XB:29	
	124	X:124	A1-M7.XB:31	
	125	X:125	A1-M8.XB:1	
	126	X:126	A1-M8.XB:3	
	127	X:127	A1-M8.XB:5	
	128	X:128	A1-M8.XB:7	
	129	X:129	A1-M8.XB:9	
	130			
	131			
	132			
	133			
	○ 134	X:134	UZ1:4	
	○ 135	X:134	A1-M9.XB:18	

Правая боковина (продолжение на листе 2)

	SA7:8	X:251	251		
	SA7:10	X:252	252		
	SA8:4	X:253	253		
	SA8:6	X:254	254		
	SA8:8	X:255	255		
	SA8:10	X:256	256		
	SA9:4	X:257	257		
	SA9:6	X:258	258		
	SA9:8	X:259	259		
	SA9:10	X:260	260		
	SA10:4	X:261	261		
	SA10:6	X:262	262		
	SA10:8	X:263	263		
	SA10:10	X:264	264		
			265		
			266		
			267		
			268		
			269		
			270		
			271		
			272		
			273		
			274		
	X	Цепи сигнализации			
	A1-M1.XP:2	X:275	275 ○		
			276 ○		
			277 ○		
			278 ○		
			279 ○		
			280 ○		
			281 ○		
			282 ○		
			283 ○		
			284 ○		
			285 ○		
			286 ○		
	HL1:2	X:287	287 ○		
			288 ○		
	X	Цепи регистрации			
	A1-M1.XP:5	X:289	289 ○		
	A1-M1.XP:15	X:290	290 ○		
	A1-M1.XP:4	X:291	291		
	A1-M1.XP:14	X:292	292		
			293		
	X	Освещение			
	SQ1:11		294 ○		
	SQ3:11		295 ○		
	SQ1:21		296 ○		
	SQ3:21		297 ○		

Правая боковина (продолжение на листе 4)