

		41		
		42		
		43		
		44		
		45		
		46		
		47		
		48		
		49		
		50		
		51		
		52		
		53		
		54	X2:54	UZ2:4
		55	X2:55	A2-M6.XB-8
	Выходные цепи		X2	
		56	X2:56	A2-M2.XB-2
		57	X2:57	A2-M3.XB-14
		58	X2:58	A2-M3.XB-16
		59	X2:59	A2-M2.XB-4
		60	X2:60	A2-M3.XB-18
		61	X2:61	A2-M3.XB-20
		62	X2:62	A2-M2.XB-6
		63	X2:63	A2-M2.XB-8
		64	X2:64	A2-M2.XB-10
		65	X2:65	A2-M3.XB-22
		66	X2:66	A2-M3.XB-24
		67	X2:67	A2-M2.XB-12
		68	X2:68	A2-M3.XB-26
		69	X2:69	A2-M3.XB-28
		70	X2:70	A2-M2.XB-14
		71	X2:71	A2-M2.XB-16
		72	X2:72	A2-M2.XB-18
		73	X2:73	A2-M3.XB-30
		74	X2:74	A2-M3.XB-32
		75	X2:75	A2-M2.XB-20
		76	X2:76	A2-M4.XB-2
		77	X2:77	A2-M4.XB-4
		78	X2:78	A2-M2.XB-22
		79	X2:79	A2-M2.XB-24
		80	X2:80	A2-M2.XB-26
		81	X2:81	A2-M4.XB-6
		82	X2:82	A2-M4.XB-8
		83	X2:83	A2-M2.XB-28
		84	X2:84	A2-M4.XB-10
		85	X2:85	A2-M4.XB-12
		86	X2:86	A2-M2.XB-30
		87	X2:87	A2-M2.XB-32
		88	X2:88	A2-M3.XB-2
		89	X2:89	A2-M3.XB-4
		90	X2:90	A2-M3.XB-6
		91	X2:91	A2-M3.XB-8
		92	X2:92	A2-M3.XB-10
		93	X2:93	A2-M3.XB-12
		94		
		95		
		96	X2:96	SA11:4
		97	X2:97	SA11:6
		98	X2:98	SA11:8
		99	X2:99	SA11:10
		100	X2:100	SA11:12
		101	X2:101	SA11:14
		102	X2:102	SA11:16
		103	X2:103	SA12:4
		104	X2:104	SA13:4
		105	X2:105	SA13:6
		106	X2:106	SA13:8
		107	X2:107	SA13:10
		108	X2:108	SA13:12
		109	X2:109	SA13:14

		41		
		42		
		43		
		44		
		45		
		46		
		47		
		48		
		49		
		50		
		51		
		52		
		53		
UZ1:4	X1:54	54		
A1-M6.XB-8	X1:55	55		
X1	Выходные цепи			
A1-M2.XB-2	X1:56	56		
A1-M3.XB-14	X1:57	57		
A1-M3.XB-16	X1:58	58		
A1-M2.XB-4	X1:59	59		
A1-M3.XB-18	X1:60	60		
A1-M3.XB-20	X1:61	61		
A1-M2.XB-6	X1:62	62		
A1-M2.XB-8	X1:63	63		
A1-M2.XB-10	X1:64	64		
A1-M3.XB-22	X1:65	65		
A1-M3.XB-24	X1:66	66		
A1-M2.XB-12	X1:67	67		
A1-M3.XB-26	X1:68	68		
A1-M3.XB-28	X1:69	69		
A1-M2.XB-14	X1:70	70		
A1-M2.XB-16	X1:71	71		
A1-M2.XB-18	X1:72	72		
A1-M3.XB-30	X1:73	73		
A1-M3.XB-32	X1:74	74		
A1-M2.XB-20	X1:75	75		
A1-M4.XB-2	X1:76	76		
A1-M4.XB-4	X1:77	77		
A1-M2.XB-22	X1:78	78		
A1-M2.XB-24	X1:79	79		
A1-M2.XB-26	X1:80	80		
A1-M4.XB-6	X1:81	81		
A1-M4.XB-8	X1:82	82		
A1-M2.XB-28	X1:83	83		
A1-M4.XB-10	X1:84	84		
A1-M4.XB-12	X1:85	85		
A1-M2.XB-30	X1:86	86		
A1-M2.XB-32	X1:87	87		
A1-M3.XB-2	X1:88	88		
A1-M3.XB-4	X1:89	89		
A1-M3.XB-6	X1:90	90		
A1-M3.XB-8	X1:91	91		
A1-M3.XB-10	X1:92	92		
A1-M3.XB-12	X1:93	93		
		94		
		95		
SA1:4	X1:96	96		
SA1:6	X1:97	97		
SA1:8	X1:98	98		
SA1:10	X1:99	99		
SA1:12	X1:100	100		
SA1:14	X1:101	101		
SA1:16	X1:102	102		
SA2:4	X1:103	103		
SA3:4	X1:104	104		
SA3:6	X1:105	105		
SA3:8	X1:106	106		
SA3:10	X1:107	107		
SA3:12	X1:108	108		
SA3:14	X1:109	109		