

		110	X2:110	SA13:16	
		111	X2:111	SA14:4	
		112	X2:112	SA15:4	
		113	X2:113	SA15:6	
		114	X2:114	SA15:8	
		115	X2:115	SA15:10	
		116	X2:116	SA15:12	
		117	X2:117	SA15:14	
		118	X2:118	SA15:16	
		119	X2:119	SA16:4	
		120	X2:120	SA17:4	
		121	X2:121	SA17:6	
		122	X2:122	SA17:8	
		123	X2:123	SA17:10	
		124	X2:124	SA17:12	
		125	X2:125	SA17:14	
		126	X2:126	SA17:16	
		127	X2:127	SA18:4	
		128	X2:128	SA19:4	
		129	X2:129	SA19:6	
		130	X2:130	SA19:8	
		131	X2:131	SA20:4	
		132	X2:132	A2-M3.XB:9	
		133	X2:133	A2-M3.XB:11	
		134			
		135			
	Цепи сигнализации			X2	
		136	X2:136	A2-M1.XP:2	
X1:137	X2:137	137			
		138			
X1:139	X2:139	139			
		140			
		141			
		142			
		143			
		144			
		145			
		146			
		147			
		148			
X1:149	X2:149	149			
	Цепи регистрации			X2	
		150	X2:150	A2-M1.XP:5	
		151	X2:151	A2-M1.XP:15	
		152	X2:152		
		153	X2:153	A2-M1.XP:4	
		154	X2:154	A2-M1.XP:14	
	Цепи освещения			X2	
		155	X2:155	SQ1:11	кч
		156			WE2
		157	X2:157	SQ1:21	с
		158			
	Резерв/Транзит			X2	
		159			
		160			
		161			
		162			
		163			
		164			
		165			
		166			
		167			
		168			
		169			
		170			
		171			
		172			

	SA3:16	X1:110	110		
	SA4:4	X1:111	111		
	SA5:4	X1:112	112		
	SA5:6	X1:113	113		
	SA5:8	X1:114	114		
	SA5:10	X1:115	115		
	SA5:12	X1:116	116		
	SA5:14	X1:117	117		
	SA5:16	X1:118	118		
	SA6:4	X1:119	119		
	SA7:4	X1:120	120		
	SA7:6	X1:121	121		
	SA7:8	X1:122	122		
	SA7:10	X1:123	123		
	SA7:12	X1:124	124		
	SA7:14	X1:125	125		
	SA7:16	X1:126	126		
	SA8:4	X1:127	127		
	SA9:4	X1:128	128		
	SA9:6	X1:129	129		
	SA9:8	X1:130	130		
	SA10:4	X1:131	131		
	A1-M3.XB:9	X1:132	132		
	A1-M3.XB:11	X1:133	133		
			134		
			135		
	X1	Цепи сигнализации			
	A1-M1.XP:2	X1:136	136		
			137	X1:137	X2:137
			138		
			139	X1:139	X2:139
			140		
			141		
			142		
			143		
			144		
			145		
			146		
			147		
	HL1:2	X1:148	148		
			149	X1:149	X2:149
	X1	Цепи регистрации			
	A1-M1.XP:5	X1:150	150		
	A1-M1.XP:15	X1:151	151		
		X1:152	152		
	A1-M1.XP:4	X1:153	153		
	A1-M1.XP:14	X1:154	154		

