

Левая доковина (начало)

	Цепи переменного тока /ЭП			X
		1	X:1	SG1:2
		2	X:2	SG1:4
		3	X:3	SG1:6
		4	X:4	SG1:8
		5	X:5	SG1:10
		6	X:6	SG1:12
		7		
		8		
	Цепи напряжения рабочей СШ			X
		9	X:9	SG2:2
		10	X:10	SG2:4
		11	X:11	SG2:6
		12	X:12	SG2:8
		13	X:13	SG3:2
		14	X:14	SG3:4
		15	X:15	SG3:6
		16	X:16	SG3:8
	Цепи напряжения ОСШ			X
		17	X:17	SG4:2
		18	X:18	SG4:4
		19	X:19	SG4:6
		20	X:20	SG4:8
	Цепи оперативного тока			X
		21	X:21	UZ1:1
		22	X:22	SG1:14
		23		
		24		
		25		
		26		
		27		
		28	X:28	A1-M5.XB:1
		29		
		30	X:30	A1-M5.XB:3
		31		
		32	X:32	A1-M5.XB:5
		33		
		34		
		35		
		36	X:36	A1-M5.XB:7
		37		
		38		
		39		
		40	X:40	A1-M5.XB:9
		41	X:41	A1-M5.XB:11
		42		
		43		
		44		

Левая доковина (продолжение на листе 2)

Правая доковина (начало)

X	Выходные цепи			
A1-M2.XB:8	X:109	109		
A1-M2.XB:10	X:110	110		
A1-M2.XB:12	X:111	111		
A1-M2.XB:14	X:112	112		
A1-M2.XB:16	X:113	113		
A1-M2.XB:18	X:114	114		
A1-M2.XB:20	X:115	115		
A1-M2.XB:22	X:116	116		
A1-M2.XB:24	X:117	117		
A1-M2.XB:26	X:118	118		
SA5:9	X:119	119		
SA5:13	X:120	120		
SA5:17	X:121	121		
A1-M2.XB:32	X:122	122		
A1-M3.XB:2	X:123	123		
K2:9	X:124	124		
K2:10	X:125	125		
K2:14	X:126	126		
K3:9	X:127	127		
A1-M3.XB:4	X:128	128		
A1-M3.XB:6	X:129	129		
		130		
		131		
		132		
		133		
		134		
		135		
		136		
		137		
SA2:4	X:138	138		
SA2:6	X:139	139		
SA2:8	X:140	140		
SA2:10	X:141	141		
SA3:4	X:142	142		
SA3:6	X:143	143		
SA4:4	X:144	144		
SA4:6	X:145	145		
SA4:8	X:146	146		
SA4:10	X:147	147		
SA5:10	X:148	148		
SA5:14	X:149	149		
SA5:18	X:150	150		
A1-M2.XB:31	X:151	151		
A1-M3.XB:1	X:152	152		
K2:11	X:153	153		
K2:12	X:154	154		
K2:16	X:155	155		
K3:11	X:156	156		
A1-M3.XB:3	X:157	157		
A1-M3.XB:5	X:158	158		

Правая доковина (продолжение на листе 2)

Условные обозначения

