

Левая доковина (начало)

	Цепи переменного тока /ЭЗП			X	
		1	X:1	SG1:2	≠
		2	X:2	SG1:4	≠
		3	X:3	SG1:6	≠
		4	X:4	SG1:8	≠
		5	X:5	SG1:10	≠
		6	X:6	SG1:12	≠
		7			
		8			
	Цепи оперативного тока			X	
		9	X:9	UZ1:1	+
		10	X:10	SG1:14	—
		11			
		12			
		13			
		14			
		15			
		16			
		17			
		18			
		19	X:19	A1-M7.XB:1	—
		20			
		21	X:21	A1-M7.XB:3	—
		22			
		23	X:23	A1-M7.XB:5	—
		24			
		25			
		26	X:26	A1-M7.XB:7	—
		27			
		28			
		29	X:29	A1-M7.XB:9	—
		30	X:30	A1-M7.XB:11	—
		31	X:31	A1-M7.XB:13	—
		32			
		33	X:33	A1-M7.XB:15	—
		34	X:34	A1-M7.XB:17	—
		35	X:35	A1-M7.XB:19	—
		36	X:36	A1-M7.XB:21	—
		37	X:37	A1-M7.XB:23	—
		38	X:38	A1-M7.XB:25	—
		39			
		40			
		41			
		42			
		43			
		44			
		45			
		46			
		47			
		48			
		49	X:49	UZ1:4	+
		50	X:50	A1-M7.XB:26	—

Левая доковина (продолжение на листе 2)

Правая доковина (начало)

	X	Выходные цепи			
	A1-M2.XB:20	X:146	146		
	A1-M2.XB:22	X:147	147		
	A1-M2.XB:24	X:148	148		
	A1-M2.XB:26	X:149	149		
	A1-M2.XB:28	X:150	150		
	A1-M2.XB:30	X:151	151		
	A1-M2.XB:32	X:152	152		
	A1-M3.XB:2	X:153	153		
	A1-M3.XB:12	X:154	154		
	A1-M3.XB:14	X:155	155		
	A1-M3.XB:16	X:156	156		
	A1-M3.XB:18	X:157	157		
	A1-M3.XB:20	X:158	158		
	A1-M3.XB:22	X:159	159		
	A1-M3.XB:24	X:160	160		
	A1-M3.XB:26	X:161	161		
	A1-M3.XB:28	X:162	162		
	A1-M3.XB:30	X:163	163		
	SA8:9	X:164	164		
	SA8:13	X:165	165		
	SA8:17	X:166	166		
	A1-M3.XB:8	X:167	167		
	A1-M3.XB:10	X:168	168		
	K4:9	X:169	169		
	K4:10	X:170	170		
	K4:14	X:171	171		
	K5:9	X:172	172		
	A1-M3.XB:32	X:173	173		
	A1-M4.XB:2	X:174	174		
			175		
			176		
			177		
			178		
			179		
			180		
			181		
			182		
			183		
			184		
			185		
	SA2:4	X:186	186		
	SA2:6	X:187	187		
	SA3:4	X:188	188		
	SA3:6	X:189	189		
	SA3:8	X:190	190		
	SA4:4	X:191	191		
	SA4:6	X:192	192		
	SA4:8	X:193	193		
	SA5:4	X:194	194		
	SA5:6	X:195	195		

Правая доковина (продолжение на листе 2)

Условные обозначения

